



Service Manual

Serial Number Range

<i>S-60</i>	from S6010-21001 to S6013-26295
<i>S-65</i>	from S6010-21001 to S6013-26295
<i>S-60X</i>	from S60X10-21001 to S60X13-26295 and S60X13-26340
<i>S-60XC</i>	from S60XC10-21001 to S60XC13-26295
<i>S-60 HC</i>	from S60HC10-21001 to S60HC13-26295
<i>S-60 TraX</i>	from S60TX10-21001 to S60TX13-26295
<i>S-65 TraX</i>	from S65TX10-21001 to S65TX13-26295

Part No. 147753

Rev D

December 2013

Introduction

Important

Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine before attempting any maintenance or repair procedure.

This manual provides detailed scheduled maintenance information for the machine owner and user. It also provides troubleshooting fault codes and repair procedures for qualified service professionals.

Basic mechanical, hydraulic and electrical skills are required to perform most procedures. However, several procedures require specialized skills, tools, lifting equipment and a suitable workshop. In these instances, we strongly recommend that maintenance and repair be performed at an authorized Genie dealer service center.

Compliance

Machine Classification

Group B/Type 3 as defined by ISO 16368

Machine Design Life

Unrestricted with proper operation, inspection and scheduled maintenance.

Technical Publications

Genie has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy. Therefore, product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and all other manuals.

Contact Us:

<http://www.genielift.com>
e-mail: awp.techpub@terex.com

Serial Number Information


Genie offers the following Service Manuals for these models:

Title	Part No.
S-60 and S-65 Service Manual (before serial number 2575)	34476
S-60 and S-65 Service Manual (from serial number 2575 to 6623)	48412
S-60 and S-65 Service Manual (from serial number 6624 to 9153)	65196
S-60, S-65 and S-60 HC Service Manual (from serial number 9154 to 14781)	77828
S-60, S-65, S-60HC and TRAX Service Manual (from serial number 14782 to 21000)	139188
S-60/65, S-60HC, S-60X/XC, and TRAX Service Manual (from serial number 26296)	825591

Copyright © 2012 Terex Corporation

147753 Rev D December 2013
Sixth Edition, Fourth Printing

"Genie" and "S" are registered trademarks of Terex South Dakota, Inc. in the USA and many other countries.

 Printed on recycled paper

Printed in U.S.A.



Revision History

Revision	Date	Section	Procedure / Schematic Page / Description
A	9/2010		New release
A1	1/2011	2 - Spec.	Machine Specifications
		4 - Repair	1-2
		6-Schem.	6-96
A2	10/2011	4 - Repair	1-2
B	2/2012	Introduction	Revision History Added
		3 - Maint.	3-1
C	10/2012		Added Ford MSG-425 Engine to all sections. Added Deutz TD201 1L04i Engine to all sections.
		2 - Spec.	Ford MSG-425, Deutz TD201 1L04i
		4 - Repair	7-12, 7-13, 7-15,
		5 - Faults	Updated Fault Codes
		6 - Schem.	6 - 1 Revised all schematics and grouped by Markets. ANSI/CSA, CE, AS Added Options Section
C1	12/2012	2 - Spec.	Machine Torque Spec.
		5 - Faults	Separated Ford Fault Codes Updated Ford DSG-423 Fault Codes Updated Ford MSG-425 Fault Codes
C2	1/2013	3 - Maint.	3-6, E-4
D	12/2013	4 - Repair	7-4, 7-5
		6 - Schem.	6-25, 6-29
REFERENCE EXAMPLES:			
Kubota Engine_Section 2_Specifications. A-6,B-3,C-7_Section 3_Maintenance Procedure. 3-2, 6-4, 9-1_Section 4_Repair Procedure. Fault Codes_Section 5. 6-35, 6-56, 6-104_Section 6_Schematic Page #.			<p style="text-align: center;">Electronic Version</p> <p>Click on any procedure or page number highlighted in blue to view the update.</p>




REVISION HISTORY, CONTINUED

Revision	Date	Section	Procedure / Schematic Page / Description
REFERENCE EXAMPLES:			
<p>Kubota Engine_Section 2_Specifications. A-6,B-3,C-7_Section 3_Maintenance Procedure. 3-2, 6-4, 9-1_Section 4_Repair Procedure. Fault Codes_Section 5. 6-35, 6-56, 6-104_Section 6_Schematic Page #.</p>			<p style="text-align: center;"><u>Electronic Version</u></p> <p>Click on any procedure or page number highlighted in blue to view the update.</p>



Serial Number Legend




Genie
A TEREX BRAND



Model: S-60
Serial number: S6010-12345
Model year: 2010 **Manufacture date:** 04/12/05
Electrical schematic number: E0396
Machine unladen weight: 20,736lbs / 9,406kg
Foam Tires add 764 lbs/347 kg to weight

Rated work load (including occupants): 500 lb / 227 kg
Maximum number of platform occupants: 2
Maximum allowable side force : 150 lb / 670 N
Maximum allowable inclination of the chassis:
Air Tires 2 deg / Foam Tires 4.5 deg
Maximum wind speed : 28 mph/ 12.5 m/s
Maximum platform height : 60 ft 2 in/ 18.3 m
Maximum platform reach : 50 ft 4 in/ 15.3 m
Gradeability: 45%
Country of manufacture: USA
This machine complies with:

Terex South Dakota
500 Oak Wood Road
PO Box 1150
Watertown, SD 57201
USA



PN - 77055



Safety Rules



Danger

Failure to obey the instructions and safety rules in this manual, and the appropriate operator's manual on your machine will result in death or serious injury.

Many of the hazards identified in the operator's manual are also safety hazards when maintenance and repair procedures are performed.

Do Not Perform Maintenance Unless:

- ☑ You are trained and qualified to perform maintenance on this machine.
- ☑ You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - applicable governmental regulations
- ☑ You have the appropriate tools, lifting equipment and a suitable workshop.

Personal Safety

Any person working on or around a machine must be aware of all known safety hazards. Personal safety and the continued safe operation of the machine should be your top priority.



Read each procedure thoroughly. This manual and the decals on the machine, use signal words to identify the following:



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.



Indicates a potentially hazardous situation which, if not avoided, may result in property damage.



Be sure to wear protective eye wear and other protective clothing if the situation warrants it.



Be aware of potential crushing hazards such as moving parts, free swinging or unsecured components when lifting or placing loads. Always wear approved steel-toed shoes.

SAFETY RULES

Workplace Safety



Be sure to keep sparks, flames and lighted tobacco away from flammable and combustible materials like battery gases and engine fuels. Always have an approved fire extinguisher within easy reach.



Be sure that all tools and working areas are properly maintained and ready for use. Keep work surfaces clean and free of debris that could get into machine components and cause damage.



Be sure any forklift, overhead crane or other lifting or supporting device is fully capable of supporting and stabilizing the weight to be lifted. Use only chains or straps that are in good condition and of ample capacity.



Be sure that fasteners intended for one time use (i.e., cotter pins and self-locking nuts) are not reused. These components may fail if they are used a second time.



Be sure to properly dispose of old oil or other fluids. Use an approved container. Please be environmentally safe.



Be sure that your workshop or work area is properly ventilated and well lit.

Table of Contents

Introduction

Important Information	<i>ii</i>
Serial Number Information	<i>ii</i>
Revision History	<i>iii</i>
Serial Number Legend	<i>v</i>

Section 1

Safety Rules

General Safety Rules	<i>vi</i>
----------------------------	-----------

Section 2

Specifications

Machine Specifications	2 - 1
Performance Specifications	2 - 2
Hydraulic Specifications	2 - 3
Manifold Component Specifications	2 - 4
Ford DSG-423 EFI Engine Specifications	2 - 5
Ford MSG-425 EFI Engine Specifications	2 - 6
Deutz D2011L03i Engine Specifications	2 - 7
Deutz TD2011L04i Engine Specifications	2 - 9
Perkins 404-22 Engine Specifications	2 - 11
Machine Torque Specifications	2 - 12
Trax Torque Specifications	2 - 13
Hydraulic Hose and Fitting Torque Specifications	2 - 14
SAE and Metric Fasteners Torque Charts	2 - 16

Section 3	Scheduled Maintenance Procedures	
	Introduction	3 - 1
	Pre-Delivery Preparation	3 - 3
	Maintenance Inspection Report	3 - 5
	Checklist A Procedures	
	A-1 Inspect the Manuals and Decals	3 - 7
	A-2 Perform Pre-operation Inspection	3 - 8
	A-3 Perform Function Tests	3 - 8
	A-4 Perform Engine Maintenance	3 - 9
	A-5 Check the High Pressure Hydraulic Filter Condition Indicator	3 - 9
	A-6 Test the Oscillate Axle (if equipped)	3 - 10
	A-7 Inspect the Track Components and Fastener Torque, S-60 TRAX and S-65 TRAX	3 - 10
	A-8 Perform 30 Day Service	3 - 11
	A-9 Check the Track Tension, S-60 TRAX and S-65 TRAX	3 - 11
	A-10 Perform Engine Maintenance - Ford and Perkins Models	3 - 13
	A-11 Inspect the Fuel Filter/Water Separator - Diesel Models	3 - 13
	A-12 Check and Adjust the Engine RPM - Perkins Models	3 - 15
	A-13 Grease the Turntable Rotation Bearing and Rotate Gear	3 - 16
	A-14 Replace the Drive Hub Oil	3 - 17
	A-15 Perform Engine Maintenance - Ford Models	3 - 19
	A-16 Perform Engine Maintenance - Perkins Models	3 - 19

 TABLE OF CONTENTS

Section 3	Scheduled Maintenance Procedures, continued	
	Checklist B Procedures	
B-1	Inspect the Battery	3 - 20
B-2	Inspect the Electrical Wiring	3 - 21
B-3	Check the Exhaust System	3 - 22
B-4	Inspect the Engine Air Filter - Ford, Deutz and Perkins Models	3 - 23
B-5	Check the Oil Cooler and Cooling Fins - Deutz Models	3 - 23
B-6	Inspect the Tires, Wheels and Lug Nut Torque, S-60, S-65, S-60 HC, S-60X and S-60XC	3 - 24
B-7	Confirm the Proper Brake Configuration	3 - 25
B-8	Check the Drive Hub Oil Level and Fastener Torque	3 - 25
B-9	Check and Adjust the Engine RPM - Ford and Deutz Models	3 - 28
B-10	Test the Ground Control Override	3 - 29
B-11	Check the Oscillate Directional Valve Linkage	3 - 29
B-12	Test the Platform Self-leveling	3 - 30
B-13	Test the Engine Idle Select	3 - 30
B-14	Test the Fuel Select Operation - Ford Models	3 - 31
B-15	Test the Drive Brakes	3 - 32
B-16	Test the Drive Speed - Stowed Position	3 - 32
B-17	Test the Drive Speed - Raised or Extended Position	3 - 33
B-18	Test the Alarm Package - Optional Equipment	3 - 34
B-19	Perform Hydraulic Oil Analysis	3 - 35
B-20	Inspect the Fuel and Hydraulic Tank Cap Venting Systems	3 - 35
B-21	Replace the Fuel Filter Element - Perkins Models	3 - 36
B-22	Inspect the Boom Extend/Retract Cables	3 - 38
B-23	Perform Engine Maintenance - Deutz Models	3 - 39
B-24	Perform Engine Maintenance - Ford Models	3 - 40
B-25	Replace the Engine Air Filter Element - Ford Models	3 - 40
B-26	Perform Engine Maintenance - Perkins Models	3 - 41

Section 3 **Scheduled Maintenance Procedures, continued**

Checklist C Procedures

C-1 Perform Engine Maintenance - Deutz Models 3 - 42

C-2 Grease the Platform Overload Mechanism (if equipped),
S-60, S-65, S-60 TRAX and S-65 TRAX 3 - 42

C-3 Test the Platform Overload System, S-60 and S-65 (if equipped),
S-60, S-65, S-60 TRAX and S-65 TRAX 3 - 43

C-4 Test the Platform Load Sense System, S60 HC 3 - 46

C-5 Replace the Fuel Filter/Water Separator Element - Perkins Models 3 - 48

C-6 Replace the Engine Air Filter Element - Deutz and Perkins Models 3 - 50

C-7 Check the Safety Envelope Limit Switches and Angle Sensor,
S-60X and S-60XC 3 - 50

C-8 Perform Engine Maintenance - Perkins Models 3 - 53

C-9 Perform Engine Maintenance - Ford Models 3 - 53

Checklist D Procedures

D-1 Check the Boom Wear Pads 3 - 54

D-2 Check the Turntable Rotation Bearing Bolts 3 - 55

D-3 Inspect for Turntable Bearing Wear 3 - 56

D-4 Replace the Drive Hub Oil 3 - 57

D-5 Check the Free-wheel Configuration 3 - 59

D-6 Replace the Hydraulic Filters 3 - 61

D-7 Perform Engine Maintenance - Deutz Models 3 - 63

Checklist E Procedures

E-1 Test or Replace the Hydraulic Oil 3 - 64

E-2 Perform Engine Maintenance - Deutz Models 3 - 66

E-3 Perform Engine Maintenance - Deutz Models 3 - 66

E-4 Replace the Boom Extend/Retract Cables 3 - 67

 TABLE OF CONTENTS

Section 4	Repair Procedures	
	Introduction	4 - 1
	Platform Controls	
	1-1 ALC-500 Circuit Board	4 - 2
	1-2 Joysticks	4 - 3
	Platform Components	
	2-1 Platform Leveling Slave Cylinder	4 - 9
	2-2 Platform Rotator	4 - 10
	2-3 Platform Overload System, S-60, S-65, S-60 TRAX and S-65 TRAX (if equipped)	4 - 12
	2-4 Platform Load Sense System, S-60 HC	4 - 14
	Jib Boom Components, S-65 and S-65 TRAX	
	3-1 Jib Boom	4 - 18
	3-2 Jib Boom Lift Cylinder	4 - 19
	Boom Components	
	4-1 Cable Track	4 - 20
	4-2 Boom	4 - 25
	4-3 Boom Lift Cylinder	4 - 28
	4-4 Boom Extension Cylinder	4 - 29
	4-5 Boom Extend/Retract Cables	4 - 32
	4-6 Platform Leveling Master Cylinder	4 - 35
	4-7 Primary Boom Angle Sensor - S-60X and S-60XC	4 - 36
	Engines	
	5-1 RPM Adjustment - Ford and Deutz Models	4 - 37
	5-2 RPM Adjustment - Perkins Models	4 - 37
	5-3 Flex Plate	4 - 37
	5-4 Engine Fault Codes - Ford Models	4 - 42

Section 4	Repair Procedures, continued	
	Hydraulic Pumps	
6-1	Function Pump	4 - 43
6-2	Drive Pump	4 - 44
	Manifolds	
7-1	Function Manifold Components	4 - 46
7-2	Valve Adjustments - Function Manifold	4 - 49
7-3	Jib Boom / Platform Rotate Manifold Components	4 - 50
7-4	Brake/Two-speed Manifold Components (to SN 25201)	4 - 51
7-5	Brake/Two-speed Manifold Components (from SN 25202)	4 - 52
7-6	Turntable Rotation Manifold Components	4 - 53
7-7	Oscillate Directional Valve Components	4 - 54
7-8	Valve Adjustments - Oscillate Relief Valve	4 - 56
7-9	Drive Oil Diverter Manifold (welder option)	4 - 57
7-10	Traction Manifold Components, 2WD	4 - 58
7-11	Valve Adjustments, 2WD Traction Manifold	4 - 59
7-12	Traction Manifold Components, 4WD (from SN 21001 to 21231)	4 - 60
7-13	Traction Manifold Components, 4WD (after SN 21231)	4 - 62
7-14	Valve Adjustments, 4WD Traction Manifold	4 - 64
7-15	Hydraulic Generator Manifold Components, 3kW (after SN 21396)	4 - 65
7-16	Valve Coils	4 - 66
	Turntable Rotation Components	
8-1	Turntable Rotation Assembly	4 - 68
	Axle Components	
9-1	Oscillate Axle Cylinders	4 - 70
	Track Components	
10-1	Track Assembly, S-60 TRAX and S-65 TRAX	4 - 71

TABLE OF CONTENTS

Section 5	Fault Codes	
	Introduction	5 - 1
	Fault Codes - Control System	5 - 2
	Fault Codes - Ford DSG-423 EFI Engine	5 - 8
	Fault Codes - Ford MSG-425 EFI Engine	5 - 15
	Fault Codes - Platform Load Sense System, S-60 HC	5 - 21

Section 6	Schematics	
	Introduction	6 - 1
	Electrical Symbols Legend	6 - 2
	Hydraulic Symbols Legend	6 - 3
	Limit Switch Location Legend	6 - 4
	Ford Engine Relay Layout	6 - 5
	Ford DSG-423 Engine Wire Harness	6 - 8
	Ford MSG-425 Engine Wire Harness	6 - 9
	Electrical Schematic, Options (All Models)	6 - 12
	Wiring Diagram, Belt Driven Generator	6 - 13
	Wiring Diagram, 3kW Hydraulic Generator	6 - 16
	Wiring Diagram, 12kW Hydraulic Generator - Welder Option	6 - 17
	Electrical Schematic, 12kW Hydraulic Generator - Welder Option	6 - 20
	Hydraulic Schematic, 12kW Hydraulic Generator - Welder Option	6 - 21
	Hydraulic Schematic, 2WD Models (from SN 21001 to 21396)	6 - 24
	Hydraulic Schematic, 2WD Models (after SN 21396)	6 - 25
	Hydraulic Schematic, 4WD Models (from SN 21001 to 21396)	6 - 28
	Hydraulic Schematic, 4WD Models (after SN 21396)	6 - 29

Section 6	Schematics, continued	
	Electrical Schematics - ANSI/CSA	
	Electrical Schematic, S-65 Ford Engine Models (ANSI / CSA)	6 - 32
	Ground Control Box Terminal Strip Wiring Diagram, S-65 Ford Engine Models (ANSI / CSA)	6 - 36
	Ground Control Box Switch Panel Wiring Diagram, S-65 Ford Engine Models (ANSI / CSA)	6 - 37
	Platform Control Box Wiring Diagram, S-65 Ford Engine Models (ANSI/CSA)	6 - 40
	Platform Control Box Switch Panel Wiring Diagram, S-65 Ford Engine Models (ANSI / CSA)	6 - 41
	Electrical Schematic, S-65/S60 TRAX/S65 TRAX Deutz D2011L03i Models (ANSI / CSA)	6 - 44
	Electrical Schematic, S-65/S60 TRAX/S65 TRAX Deutz TD2011L04i Models (ANSI / CSA)	6 - 48
	Ground Control Box Terminal Strip Wiring Diagram, S-65/S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)	6 - 52
	Ground Control Box Switch Panel Wiring Diagram, S-65/S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)	6 - 53
	Platform Control Box Wiring Diagram, S-65/S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)	6 - 56
	Platform Control Box Switch Panel Wiring Diagram, S-65/S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)	6 - 57
	Electrical Schematic, S-65/S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)	6 - 60
	Ground Control Box Terminal Strip Wiring Diagram, S-65/S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)	6 - 64
	Ground Control Box Switch Panel Wiring Diagram, S-65/S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)	6 - 65
	Platform Control Box Wiring Diagram, S-65/S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)	6 - 68
	Platform Control Box Switch Panel Wiring Diagram, S-65/S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)	6 - 69

 TABLE OF CONTENTS

Section 6	Schematics, continued	
	Electrical Schematics - ANSI/CSA	
	Electrical Schematic, S-60X and S-60XC	
	Ford Engine Models (ANSI/CSA)	6 - 72
	Ground Control Box Terminal Strip Wiring Diagram, S-60X and S-60XC	
	Ford Engine Models (ANSI/CSA)	6 - 76
	Ground Control Box Switch Panel Wiring Diagram, S-60X and S-60XC	
	Ford Engine Models (ANSI/CSA)	6 - 77
	Platform Control Box Wiring Diagram, S-60X and S-60XC	
	Ford Engine Models (ANSI/CSA)	6 - 80
	Platform Control Box Switch Panel Wiring Diagram, S-60X and S-60XC	
	Ford Engine Models (ANSI/CSA)	6 - 81
	Electrical Schematic, S-60X and S-60XC	
	Deutz D2011L03i Models (ANSI/CSA)	6 - 84
	Electrical Schematic, S-60X and S-60XC	
	Deutz TD2011L04i Models (ANSI/CSA)	6 - 88
	Ground Control Box Terminal Strip Wiring Diagram, S-60X and S-60XC	
	Deutz Engine Models (ANSI/CSA)	6 - 92
	Ground Control Box Switch Panel Wiring Diagram, S-60X and S-60XC	
	Deutz Engine Models (ANSI/CSA)	6 - 93
	Platform Control Box Wiring Diagram, S-60X and S-60XC	
	Deutz Engine Models (ANSI/CSA)	6 - 96
	Platform Control Box Switch Panel Wiring Diagram, S-60X and S-60XC	
	Deutz Engine Models (ANSI/CSA)	6 - 97
	Electrical Schematic, S-60X and S-60XC	
	Perkins Engine Models (ANSI/CSA)	6 - 100
	Ground Control Box Terminal Strip Wiring Diagram, S-60X and S-60XC	
	Perkins Engine Models (ANSI/CSA)	6 - 104
	Ground Control Box Switch Panel Wiring Diagram, S-60X and S-60XC	
	Perkins Engine Models (ANSI/CSA)	6 - 105
	Platform Control Box Wiring Diagram, S-60X and S-60XC	
	Perkins Engine Models (ANSI/CSA)	6 - 108
	Platform Control Box Switch Panel Wiring Diagram, S-60X and S-60XC	
	Perkins Engine Models (ANSI/CSA)	6 - 109

Section 6	Schematics, continued	
	Electrical Schematics - CE	
	Electrical Schematic, S-60/S-65 Ford Engine Models (CE) (from SN 21001 to 22516)	6 - 112
	Electrical Schematic, S-60/S-65 Ford Engine Models (CE) (after SN 22516)	6 - 116
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 Ford Engine Models (CE) (from SN 21001 to 22516)	6 - 120
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 Ford Engine Models, (CE) (after SN 22516)	6 - 121
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 Ford Engine Models (CE)	6 - 124
	Platform Control Box Wiring Diagram, S-60/S-65 Ford Engine Models (CE)	6 - 125
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 Ford Engine Models (CE)	6 - 128
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Deutz D2011L03i Models (CE)	6 - 130
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Deutz TD2011L04i Models (CE)	6 - 134
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (CE)	6 - 138
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (CE)	6 - 139
	Platform Control Box Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (CE)	6 - 142
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (CE)	6 - 143

 TABLE OF CONTENTS

Section 6	Schematics, continued	
	Electrical Schematics - CE	
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)	6 - 146
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (CE)	6 - 150
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (CE)	6 - 151
	Platform Control Box Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (CE)	6 - 154
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (CE)	6 - 155
	Electrical Schematic, S-60 HC (CE)	6 - 158
	Chassis Wiring Diagram, S-60 HC (CE)	6 - 159
	Ground Control Box Terminal Strip Wiring Diagram, S-60 HC (CE) (from SN 21001 to 21287)	6 - 162
	Ground Control Box Terminal Strip Wiring Diagram, S-60 HC (CE) (after SN 21287)	6 - 163
	Platform Control Box Wiring Diagram, S-60 HC (CE)	6 - 166
	Electrical Schematics - AS, From SN 21001 to 21629	
	Electrical Schematic, S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)	6 - 168
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)	6 - 172
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)	6 - 173
	Platform Control Box Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)	6 - 176
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)	6 - 177

Section 6	Schematics, continued	
	AS, From SN 21001 to 21629	
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Deutz D2011L03i Models (AS) (from SN 21001 to 21629)	6 - 180
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Deutz TD2011L04i Models (AS) (from SN 21001 to 21629)	6 - 184
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (from SN 21001 to 21629)	6 - 188
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (from SN 21001 to 21629)	6 - 189
	Platform Control Box Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (from SN 21001 to 21629)	6 - 192
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (from SN 21001 to 21629)	6 - 193
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)	6 - 196
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)	6 - 200
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)	6 - 201
	Platform Control Box Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)	6 - 204
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)	6 - 205

 TABLE OF CONTENTS


Section 6	Schematics, continued	
	Electrical Schematics - AS, After SN 21629	
	Electrical Schematic, S-60/S-65 Ford Engine Models (AS) (from SN 21630 to 22516)	6 - 208
	Electrical Schematic, S-60/S-65 Ford Engine Models (AS) (after SN 22516)	6 - 212
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (from SN 21630 to 22516)	6 - 216
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (after SN 22516))	6 - 217
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (after SN 21629)	6 - 220
	Platform Control Box Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (after SN 21629)	6 - 221
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 Ford Engine Models (AS) (after SN 21629)	6 - 224
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Deutz D2011L03i Models (AS) (after SN 21629)	6 - 226
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Deutz TD2011L04i Models (AS) (after SN 21629)	6 - 230
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)	6 - 234
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)	6 - 235
	Platform Control Box Wiring Diagram, S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)	6 - 238
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)	6 - 239

TABLE OF CONTENTS

Section 6	Schematics, continued	
	Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)	6 - 242
	Ground Control Box Terminal Strip Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)	6 - 246
	Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)	6 - 247
	Platform Control Box Wiring Diagram, S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)	6 - 250
	Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)	6 - 251



TABLE OF CONTENTS



This page intentionally left blank.

Specifications

Machine Specifications

Tires and wheels, S-60, S-65, S-60 HC, S-60X and S-60XC

Tire size (Rough terrain)	355/55D625
Tire weight, new foam-filled (minimum) (Rough terrain)	415 lbs 188 kg
Tire size (Hi-flotation)	41/18LL x 22.5
Tire ply rating (Rough terrain and Hi-flotation)	14
Wheel lugs	9 @ 5/8 -18
Lug nut torque, dry	240 ft-lbs 325 Nm
Lug nut torque, lubricated	180 ft-lbs 244 Nm
Overall tire diameter (Rough terrain, low profile tires)	36.9 in 93.7 cm
Overall tire diameter (Hi-flotation tires)	40.3 in 102.4 cm
Tire pressure (Rough terrain, low profile tires)	70 psi 4.92 bar
Tire pressure (Hi-flotation tires)	60 psi 4.13 bar

Track Components, S-60 TRAX and S-65 TRAX

Track material	Rubber
Tensioning system	Pressurized grease
Weight (each)	1,500 lbs 680 kg

Fluid capacities

Fuel tank (Deutz and Perkins Models)	35 gallons 132.5 liters
(Ford models)	30 gallons 113.5 liters
LPG tank	33.5 pounds 15.2 kg
Hydraulic tank	45 gallons 170 liters
Hydraulic system (including tank)	55 gallons 208 liters
Drive hubs	20 fl oz 0.6 liters
Turntable rotation drive hub (before serial number 20367)	40 fl oz 1.2 liters
(after serial number 20366)	43 oz 1.3 liters
Drive hub oil type: SAE 90 multipurpose hypoid gear oil API service classification GL5	

For operational specifications, refer to the Operator's Manual.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Performance Specifications**Boom function speeds, maximum from platform controls**

Jib boom up (S-65 models)	60 to 70 seconds
Jib boom down (S-65 models)	40 to 50 seconds
Boom up	60 to 70 seconds
Boom down	60 to 70 seconds
Boom extend	58 to 66 seconds
Boom retract	53 to 62 seconds
Turntable rotate, 360° boom stowed	78 to 86 seconds
Turntable rotate, 360° boom extended	125 to 165 seconds
Platform rotate, 160°	8 to 12 seconds

Braking distance, maximum

High range on paved surface	3 to 6 ft 0.9 to 1.8 m
-----------------------------	---------------------------

Drive speed, maximum stowed position

2WD models	40 ft / 6.2 sec 12.2 m / 6.2 sec
4WD models	40 ft / 7.2 sec 12.2 m / 7.2 sec
S-60 TRAX and S-65 TRAX	40 ft / 12 sec 12.2 m / 12 sec

Drive speed, maximum raised or extended position

S-60, S-65, S-60 HC, S-60X and S-60XC	40 ft / 40 sec 12.2 m / 40 sec
S-60 TRAX and S-65 TRAX	40 ft / 57 sec 12.2 m / 57 sec

Gradeability	See Operator's Manual
---------------------	-----------------------

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Hydraulic Specifications

Hydraulic Oil Specifications

Hydraulic oil type	Chevron Rando HD MV equivalent
Approximate SAE grade	5W-20
Viscosity index rating	200
Cleanliness level, minimum	15/13
Water content, maximum	200 ppm

Chevron Rando HD MV oil is fully compatible and mixable with Shell Donax TG (Dexron III) oils.

Genie specifications require hydraulic oils which are designed to give maximum protection to hydraulic systems, have the ability to perform over a wide temperature range, and the viscosity index should exceed 140. They should provide excellent antiwear, oxidation, corrosion inhibition, seal conditioning, and foam and aeration suppression properties.

Optional fluids

Biodegradable	Petro Canada Environ MV46 Statoil Hydra Way Bio Pa 32 BP Biohyd SE-S
Fire resistant	UCON Hydrolube HP-5046 Quintolubric 822
Mineral based	Shell Tellus S2 V 32 Shell Tellus S2 V 46 Chevron Aviation A ARNICA 32

NOTICE

Continued use of Chevron Aviation A hydraulic oil when ambient temperatures are consistently above 32°F / 0°C may result in component damage.

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.

Note: Use Chevron Aviation A hydraulic oil when ambient temperatures consistently below 0°F / -18°C.

Note: Use Shell Tellus T46 hydraulic oil when oil temperatures consistently exceed 205°F / 96°C.

Note: Genie specifications require additional equipment and special installation instructions for the approved optional fluids. Consult the Genie Service Department before use.

Drive pump

Type:	bi-directional, variable displacement piston pump
Flow rate @ 2500 rpm	32.4 gpm 122.6 L/min
Drive pressure, maximum	3750 psi 259 bar

Charge pump

Type:	gerotor
Displacement	0.85 cu in 13.9 cc
Flow rate @ 2500 rpm	9.2 gpm 34.8 L/min
Charge pressure @ 2500 rpm	310 psi 21.4 bar

Function pump

Type:	2 section tandem gear pump
Displacement - Pump 1 (inner)	1.4 cu in 23 cc
Flow rate @ 2500 rpm	15.3 gpm 58 L/min
Displacement - Pump 2 (outer) (oscillate models)	0.24 cu in 4 cc
Flow rate @ 2500 rpm	2 gpm 7.6 L/min



SPECIFICATIONS

Auxiliary pump

Type: gear, fixed displacement

Displacement 1.75 gpm
2.8 L/min

Function manifold

System relief valve pressure 3000 psi
207 bar

Steer flow regulator 3.5 gpm
13.2 L/min

Jib boom / platform rotate
flow regulator 0.6 gpm
2.27 L/min

Oscillate relief valve pressure (@ 2500 rpm) 800 psi
55 bar

Drive manifold

Hot oil relief valve pressure 280 psi
19.3 bar

Drive motors, 4WD models

Displacement per revolution,
high speed 0.79 cu in
13 cc

Displacement per revolution,
low speed 1.83 cu in
30 cc

Drive motors, 2WD models

Displacement per revolution,
high speed 1.28 cu in
20.9 cc

Displacement per revolution,
low speed 2.14 cu in
35 cc

Hydraulic filters

High pressure filter Beta \geq 200

High pressure filter
bypass pressure 51 psi
3.5 bar

Medium pressure filter Beta \geq 200

Medium pressure filter
bypass pressure 51 psi
3.5 bar

Hydraulic return filter 10 micron with
25 psi / 1.7 bar bypass

Manifold Component Specifications**Plug torque**

SAE No. 2 36 in-lbs / 4 Nm

SAE No. 4 10 ft-lbs / 13 Nm

SAE No. 6 14 ft-lbs / 19 Nm

SAE No. 8 38 ft-lbs / 51 Nm

SAE No. 10 41 ft-lbs / 55 Nm

SAE No. 12 56 ft-lbs / 76 Nm

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Ford DSG-423 EFI Engine

Displacement	140.4 cu in 2.3 liters
---------------------	---------------------------

Number of cylinders	4
----------------------------	---

Bore & stroke	3.44 x 3.7 inches 87.5 x 94 mm
--------------------------	-----------------------------------

Horsepower	59 @ 2500 rpm 44 kW @ 2500 rpm
-------------------	-----------------------------------

Firing order	1 - 3 - 4 - 2
---------------------	---------------

Low function idle (computer controlled)	1600 rpm 53.3 Hz
--	---------------------

High function idle (computer controlled)	2500 rpm 83.3 Hz
---	---------------------

Compression ratio	9.7:1
--------------------------	-------

Compression pressure (approx.)

Pressure (psi or bar) of lowest cylinder must be at least 75% of highest cylinder

Lubrication system

Oil pressure	29 to 39 psi
(at operating temperature @ 2500 rpm)	2 to 2.7 bar

Oil capacity	4 quarts
(including filter)	3.8 liters

Oil pressure switch

Oil pressure switch point	7.5 psi 0.51 bar
---------------------------	---------------------

Oil viscosity requirements

Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Handbook on your machine.

Electronic fuel pump

Fuel pressure, static	64 psi 4.4 bar
-----------------------	-------------------

Fuel flow rate	0.43 gpm 1.6 L/min
----------------	-----------------------

Fuel requirement

For fuel requirements, refer to the engine Operator's Manual on your machine.

Ignition system

Spark plug type	Motorcraft AGSF-32-FEC
-----------------	------------------------

Spark plug gap	0.049 to 0.053 inches 1.244 to 1.346 mm
----------------	--

Engine coolant

Capacity	10 quarts 9.5 liters
----------	-------------------------

Cylinder head temperature sending unit

Fault code set temperature	280°F 138°C
----------------------------	----------------

Engine shut-down temperature	300°F 149°C
------------------------------	----------------

Starter motor

Normal engine cranking speed	200 to 250 rpm
------------------------------	----------------

Current draw, normal load	140-200A
---------------------------	----------

Current draw, maximum load	800A
----------------------------	------

Alternator

Output	95A, 13.8V DC
--------	---------------

Battery

Type	12V DC, Group 31
------	------------------

Quantity	1
----------	---

Cold cranking ampere @ 0°F	1000A
----------------------------	-------

Reserve capacity @ 25A rate	200 minutes
-----------------------------	-------------

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Ford MSG-425 EFI Engine

Displacement	152.5 cu in 2.5 liters
---------------------	---------------------------

Number of cylinders	4
----------------------------	---

Bore & stroke	3.50 x 3.94 inches 89 x 100 mm
--------------------------	-----------------------------------

Horsepower	60 @ 2500 rpm 44.7 kW @ 2500 rpm
-------------------	-------------------------------------

Firing order	1 - 3 - 4 - 2
---------------------	---------------

Low function idle (computer controlled)	1600 rpm 53.3 Hz
--	---------------------

High function idle (computer controlled)	2500 rpm 83.3 Hz
---	---------------------

Compression ratio	9.7:1
--------------------------	-------

Compression pressure (approx.)

Pressure (psi or bar) of lowest cylinder must be at least 75% of highest cylinder

Lubrication system

Oil pressure	29 to 39 psi
(at operating temperature @ 2500 rpm)	2 to 2.7 bar

Oil capacity	6.7 quarts
(including filter)	6.4 liters

Oil pressure switch

Oil pressure switch point	7 to 9 psi 0.48 to 0.62 bar
---------------------------	--------------------------------

Oil viscosity requirements

Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Handbook on your machine.

Electronic fuel pump

Fuel pressure, static	60 psi 4.1 bar
-----------------------	-------------------

Fuel flow rate	0.43 gpm 1.6 L/min
----------------	-----------------------

Fuel requirement

For fuel requirements, refer to the engine Operator's Manual on your machine.

Ignition system

Spark plug type	Motorcraft AYFS-32Y-R
-----------------	-----------------------

Spark plug gap	0.049 to 0.053 inches 1.25 to 1.35 mm
----------------	--

Engine coolant

Capacity	10 quarts 9.5 liters
----------	-------------------------

Cylinder head temperature sending unit

Fault code set temperature	280°F 138°C
----------------------------	----------------

Engine shut-down temperature	300°F 149°C
------------------------------	----------------

Starter motor

Normal engine cranking speed	200 to 250 rpm
------------------------------	----------------

Current draw, normal load	140-200A
---------------------------	----------

Current draw, maximum load	800A
----------------------------	------

Alternator

Output	95A, 13.8V DC
--------	---------------

Battery

Type	12V DC, Group 31
------	------------------

Quantity	1
----------	---

Cold cranking ampere @ 0°F	1000A
----------------------------	-------

Reserve capacity @ 25A rate	200 minutes
-----------------------------	-------------

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Deutz D2011L03i Engine

Displacement	142 cu in 2.33 liters
Number of cylinders	3
Bore and stroke	3.7 x 4.4 inches 94 x 112 mm
Horsepower	48 @ 2800 rpm 36 kW @ 2800 rpm
Firing order	1 - 2 - 3
Low idle	1500 rpm 313 Hz
High idle	2500 rpm 521.7 Hz
Compression ratio	19:1
Compression pressure	362 to 435 psi 25 to 30 bar
Governor	centrifugal mechanical
Valve clearance, cold	
Intake	0.012 in 0.3 mm
Exhaust	0.020 in 0.5 mm

Lubrication system

Oil pressure (@ 2000 rpm)	40 to 60 psi 1.4 to 3 bar
------------------------------	------------------------------

Oil capacity (including filter)	9.5 quarts 9 liters
------------------------------------	------------------------

Oil viscosity requirements

-22° F to 86° F / -30° C to 30° C	5W-30 (synthetic)
-----------------------------------	----------------------

-4° F to 90° F / -20° C to 32° C	10W-40
----------------------------------	--------

Above 23° F / -5° C	20W-50
---------------------	--------

Units ship with 15W-40.

Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Handbook on your machine.

Oil temperature switch

Temperature switch point	220°F 104°C
--------------------------	----------------

Oil pressure switch

Oil pressure switch point	22 psi 1.5 bar
---------------------------	-------------------

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Deutz D2011L03i Engine, continued**Fuel injection system**

Injection pump make	Bosch
Injection pump pressure, maximum	15000 psi 1034 bar
Injector opening pressure	3046 psi 210 bar

Fuel requirement

For fuel requirements, refer to the engine Operator's Manual on your machine.

Starter motor

Current draw, normal load	140A to 200A
Brush length, new	0.72 in 18.5 mm
Brush length, minimum	0.27 in 7 mm

Battery

Type	12V DC
Size	13 x 6 ^{13/16} x 9 ^{3/8} inches 33 x 17.3 x 23.8 cm
Quantity	1
Cold cranking ampere	1000A
Reserve capacity @ 25A rate	200 minutes

Alternator output	60A @ 14V DC
--------------------------	--------------

Fan belt deflection	³ / ₈ to ¹ / ₂ inch 9 to 12 mm
----------------------------	---

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Deutz TD2011L04i Engine

Displacement	220.9 cu in 3.62 liters
Number of cylinders	4
Bore and stroke	3.78 x 4.92 inches 96 x 125 mm
Horsepower Net intermittent @ 2400 rpm	74 / 55 kW
Induction system	turbocharged
Firing order	1 - 3 - 4 - 2
Low idle	1500 rpm 450 Hz
High idle	2350 rpm 705 Hz
Compression ratio	17.5:1
Compression pressure Pressure (psi or bar) of the lowest cylinder must be at least 75% of the highest cylinder.	
Governor	centrifugal mechanical
Valve clearance, cold	
Intake	0.012 in 0.3 mm
Exhaust	0.020 in 0.5 mm

Lubrication system

Oil pressure, hot (at 2000 rpm)	40 to 60 psi 2.8 to 4.1 bar
------------------------------------	--------------------------------

Oil capacity (including filter)	12.8 quarts 12.1 liters
------------------------------------	----------------------------

Oil viscosity requirements

-22°F to 86°F / -30°C to 30°C	5W-30 (synthetic)
-------------------------------	----------------------

-4°F to 104°F / -20°C to 40°C	10W-40
-------------------------------	--------

Above 5°F / -15°C	15W-40
-------------------	--------

Units ship with 15W-40.

Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Handbook on your machine.

Oil temperature switch

Installation torque	8-18 ft-lbs 11-24 Nm
---------------------	-------------------------

Oil temperature switch point	275°F 135°C
------------------------------	----------------

Oil pressure switch

Installation torque	8-18 ft-lbs 11-24 Nm
---------------------	-------------------------

Oil pressure switch point	22 psi 1.5 bar
---------------------------	-------------------

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Deutz TD2011L04i Engine, continued**Fuel injection system**

Injection pump make	Motorpal
Injection pump pressure, maximum	15,000 psi 1034 bar
Injector opening pressure	3046 psi 210 bar

Fuel requirement

For fuel requirements, refer to the engine Operator's Manual on your machine.

Starter motor

Current draw, normal load	140-200A
Cranking speed	250-350 rpm

Battery

Type	12V DC
Size	13 x 6 ¹³ / ₁₆ x 9 ³ / ₈ inches 33 x 17.3 x 23.8 cm
Quantity	1
Cold cranking ampere	1000A
Reserve capacity @ 25A rate	200 minutes

Alternator output	80A @ 14V DC
--------------------------	--------------

Fan belt deflection	$\frac{3}{8}$ to $\frac{1}{2}$ inch 9 to 12 mm
----------------------------	---

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Perkins 404-22 Engine

Displacement	134 cu in 2.2 liters
Number of cylinders	4
Bore and stroke	3.31 x 3.94 inches 84 x 100 mm
Horsepower	51 @ 2500 rpm 38 kW @ 2500 rpm
Firing order	1 - 3 - 4 - 2
Low idle	1300 rpm 229.7 Hz
High idle	2500 rpm 441.7 Hz
Compression ratio	23.3:1
Compression pressure	426 psi 29.4 bar
Pressure (psi) of lowest cylinder must be within 50 psi / 3.45 bar of highest cylinder	
Governor	centrifugal mechanical
Valve clearance, cold	
Intake	0.008 in 0.2 mm
Exhaust	0.008 in 0.2 mm

Lubrication system

Oil pressure, cold (at 2500 rpm)	60 psi 4.1 bar
----------------------------------	-------------------

Oil capacity (including filter)	9.3 quarts 8.8 liters
---------------------------------	--------------------------

Oil viscosity requirements

Below 86°F / 30°C	5W-20
-------------------	-------

-4°F to 104°F / -20°C to 40°C	10W-30
-------------------------------	--------

Above 14°F / -10°C	15W-40
--------------------	--------

Units ship with 15W-40.

Extreme operating temperatures may require the use of alternative engine oils. For oil requirements, refer to the Engine Operator Handbook on your machine.

Oil pressure sending unit

Oil pressure switch point	14.2 psi 1 bar
---------------------------	-------------------

Fuel injection system

Injection pump make	Zexel
---------------------	-------

Injection pressure	2133 psi 147 bar
--------------------	---------------------

Fuel requirement

For fuel requirements, refer to the engine Operator's Manual on your machine.

Alternator output	55A @ 12V DC
--------------------------	--------------

Fan belt deflection	³ / ₈ in 10 mm
----------------------------	---

Starter motor

Current draw, no load	90A
-----------------------	-----

Brush length, new	0.7480 in 19 mm
-------------------	--------------------

Brush length, minimum	0.5 in 12.7 mm
-----------------------	-------------------

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Perkins 404-22 Engine, continued

Battery	
Type	12V DC
Size	13 x 6 ¹³ / ₁₆ x 9 ³ / ₈ inches 33 x 17.3 x 23.8 cm
Quantity	1
Cold cranking ampere	1000A
Reserve capacity @ 25A rate	200 minutes
Engine coolant	
Capacity	7.7 quarts 7.3 liters
Coolant temperature sending unit	
Temperature switch point	221° F 105° C

Machine Torque Specifications

Platform rotator	
1-8 center bolt, GR 5	640 ft-lbs 867 Nm
3/8 -16 bolts, GR 8 (use a removable thread locking compound)	33 ft-lbs* 45 Nm
1/2 -13 bolts, GR 8	80 ft-lbs 108 Nm
Drive motor and hubs	
Drive hub mounting bolts, lubricated	160 ft-lbs 217 Nm
Drive motor mounting bolts, lubricated	55 ft-lbs 75 Nm
Turntable bearing	
Rotate bearing mounting bolts, lubricated	180 ft-lbs 244 Nm
Turntable rotation assembly	
Backlash pivot plate, lubricated	320 ft-lbs 433 Nm

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

TRAX Torque Specifications

Sprocket to hub adapter fasteners

$\frac{3}{4}$ -10 nuts, GR 8, dry	317 ft-lbs 430 Nm
-----------------------------------	----------------------

$\frac{3}{4}$ -10 nuts, GR 8, lubricated	281 ft-lbs 381 Nm
--	----------------------

$\frac{1}{2}$ -13 FHS screws, dry	80 ft-lbs 108 Nm
-----------------------------------	---------------------

$\frac{1}{2}$ -13 FHS screws, lubricated	60 ft-lbs 81 Nm
--	--------------------

Hub adapter to drive hub fasteners

Lug nut torque, dry	240 ft-lbs 325 Nm
---------------------	----------------------

Lug nut torque, lubricated	180 ft-lbs 244 Nm
----------------------------	----------------------

Sprocket bearing hub fasteners

1-14 bolts, GR 8, dry	650 ft-lbs 881 Nm
-----------------------	----------------------

1-14 bolts, GR 8, lubricated	488 ft-lbs 662 Nm
------------------------------	----------------------

Idler and bogey wheel fasteners

$\frac{3}{4}$ -10 bolts, GR 8, dry	375 ft-lbs 508 Nm
------------------------------------	----------------------

$\frac{3}{4}$ -10 bolts, GR 8, lubricated	281 ft-lbs 381 Nm
---	----------------------

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.



SPECIFICATIONS

Hydraulic Hose and Fitting Torque Specifications

Your machine is equipped with Parker Seal-Lok™ ORFS or 37° JIC fittings and hose ends. Genie specifications require that fittings and hose ends be torqued to specification when they are removed and installed or when new hoses or fittings are installed.


Seal-Lok™ Fittings (hose end - ORFS)	
SAE Dash size	Torque
-4	10 ft-lbs / 13.6 Nm
-6	30 ft-lbs / 40.7 Nm
-8	40 ft-lbs / 54.2 Nm
-10	60 ft-lbs / 81.3 Nm
-12	85 ft-lbs / 115 Nm
-16	110 ft-lbs / 150 Nm
-20	140 ft-lbs / 190 Nm
-24	180 ft-lbs / 245 Nm

JIC 37° Fittings (swivel nut or hose connection)		
SAE Dash size	Thread Size	Flats
-4	7/16-20	2
-6	9/16-18	1 1/4
-8	3/4-16	1
-10	7/8-14	1
-12	1 1/16-12	1
-16	1 5/16-12	1
-20	1 5/8-12	1
-24	1 7/8-12	1

SAE O-ring Boss Port

(tube fitting - installed into Aluminum)
(all types)

SAE Dash size	Torque
-4	14 ft-lbs / 19 Nm
-6	23 ft-lbs / 31.2 Nm
-8	36 ft-lbs / 54.2 Nm
-10	62 ft-lbs / 84 Nm
-12	84 ft-lbs / 114 Nm
-16	125 ft-lbs / 169.5 Nm
-20	151 ft-lbs / 204.7 Nm
-24	184 ft-lbs / 249.5 Nm



SAE O-ring Boss Port

(tube fitting - installed into Steel)

SAE Dash size	Torque
-4 ORFS / 37° (Adj)	15 ft-lbs / 20.3 Nm
ORFS (Non-adj)	26 ft-lbs / 35.3 Nm
37° (Non-adj)	22 ft-lbs / 30 Nm
-6 ORFS (Adj / Non-adj)	35 ft-lbs / 47.5 Nm
37° (Adj / Non-adj)	29 ft-lbs / 39.3 Nm
-8 ORFS (Adj / Non-adj)	60 ft-lbs / 81.3 Nm
37° (Adj / Non-adj)	52 ft-lbs / 70.5 Nm
-10 ORFS (Adj / Non-adj)	100 ft-lbs / 135.6 Nm
37° (Adj / Non-adj)	85 ft-lbs / 115.3 Nm
-12 (All types)	135 ft-lbs / 183 Nm
-16 (All types)	200 ft-lbs / 271.2 Nm
-20 (All types)	250 ft-lbs / 339 Nm
-24 (All types)	305 ft-lbs / 413.5 Nm



SPECIFICATIONS

Torque Procedure

Seal-Lok™ fittings

- 1 Replace the O-ring. The O-ring must be replaced anytime the seal has been broken. The O-ring cannot be re-used if the fitting or hose end has been tightened beyond finger tight.

Note: The O-rings used in the Parker Seal Lok™ fittings and hose ends are custom-size O-rings. They are not standard SAE size O-rings. They are available in the O-ring field service kit (Genie part number 49612).

- 2 Lubricate the O-ring before installation.
- 3 Be sure that the face seal O-ring is seated and retained properly.
- 4 Position the tube and nut squarely on the face seal end of the fitting and tighten the nut finger tight.
- 5 Tighten the nut or fitting to the appropriate torque per given size as shown in the table.
- 6 Operate all machine functions and inspect the hoses and fittings and related components to confirm that there are no leaks.

JIC 37° fittings

- 1 Align the tube flare (hex nut) against the nose of the fitting body (body hex fitting) and tighten the hex nut to the body hex fitting to hand-tight, approximately 30 in-lbs / 3.4 Nm.
- 2 Make a reference mark on one of the flats of the hex nut, and continue it on to the body hex fitting with a permanent ink marker. Refer to Figure 1.




Figure 1

- a hex nut
- b reference mark
- c body hex fitting

- 3 Working clockwise on the body hex fitting, make a second mark with a permanent ink marker to indicate the proper tightening position. Refer to Figure 2.

Note: Use the *JIC 37° Fittings* table on the previous page to determine the correct number of flats for the proper tightening position.

Note: The marks indicate that the correct tightening positions have been determined. Use the second mark on the body hex fitting to properly tighten the joint after it has been loosened.






Figure 2

- a body hex fitting
- b reference mark
- c second mark





- 4 Tighten the hex nut until the mark on the hex nut is aligned with the second mark on the body hex fitting.
- 5 Operate all machine functions and inspect the hoses and fittings and related components to confirm that there are no leaks.

SPECIFICATIONS

SAE FASTENER TORQUE CHART
 • This chart is to be used as a guide only unless noted elsewhere in this manual •

SIZE	THREAD	Grade 5 				Grade 8 				A574 High Strength Black Oxide Bolts	
		LUBED		DRY		LUBED		DRY		LUBED	
		in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm
1/4	20	80	9	100	11.3	110	12.4	140	15.8	130	14.7
	28	90	10.1	120	13.5	120	13.5	160	18	140	15.8
		LUBED		DRY		LUBED		DRY		LUBED	
		ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm
5/16	18	13	17.6	17	23	18	24	25	33.9	21	28.4
	24	14	19	19	25.7	20	27.1	27	36.6	24	32.5
3/8	16	23	31.2	31	42	33	44.7	44	59.6	38	51.5
	24	26	35.2	35	47.4	37	50.1	49	66.4	43	58.3
7/16	14	37	50.1	49	66.4	50	67.8	70	94.7	61	82.7
	20	41	55.5	55	74.5	60	81.3	80	108.4	68	92.1
1/2	13	57	77.3	75	101.6	80	108.4	110	149	93	126
	20	64	86.7	85	115	90	122	120	162	105	142
9/16	12	80	108.4	110	149	120	162	150	203	130	176
	18	90	122	120	162	130	176	170	230	140	189
5/8	11	110	149	150	203	160	217	210	284	180	244
	18	130	176	170	230	180	244	240	325	200	271
3/4	10	200	271	270	366	280	379	380	515	320	433
	16	220	298	300	406	310	420	420	569	350	474
7/8	9	320	433	430	583	450	610	610	827	510	691
	14	350	474	470	637	500	678	670	908	560	759
1	8	480	650	640	867	680	922	910	1233	770	1044
	12	530	718	710	962	750	1016	990	1342	840	1139
1 1/8	7	590	800	790	1071	970	1315	1290	1749	1090	1477
	12	670	908	890	1206	1080	1464	1440	1952	1220	1654
1 1/4	7	840	1138	1120	1518	1360	1844	1820	2467	1530	2074
	12	930	1260	1240	1681	1510	2047	2010	2725	1700	2304
1 1/2	6	1460	1979	1950	2643	2370	3213	3160	4284	2670	3620
	12	1640	2223	2190	2969	2670	3620	3560	4826	3000	4067

METRIC FASTENER TORQUE CHART
 • This chart is to be used as a guide only unless noted elsewhere in this manual •

Size (mm)	Class 4.6 				Class 8.8 				Class 10.9 				Class 12.9 			
	LUBED		DRY		LUBED		DRY		LUBED		DRY		LUBED		DRY	
	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm	in-lbs	Nm
5	16	1.8	21	2.4	41	4.63	54	6.18	58	6.63	78	8.84	68	7.75	91	10.3
6	19	3.05	36	4.07	69	7.87	93	10.5	100	11.3	132	15	116	13.2	155	17.6
7	45	5.12	60	6.83	116	13.2	155	17.6	167	18.9	223	25.2	195	22.1	260	29.4
	LUBED		DRY		LUBED		DRY		LUBED		DRY		LUBED		DRY	
	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm	ft-lbs	Nm
8	5.4	7.41	7.2	9.88	14	19.1	18.8	25.5	20.1	27.3	26.9	36.5	23.6	32	31.4	42.6
10	10.8	14.7	14.4	19.6	27.9	37.8	37.2	50.5	39.9	54.1	53.2	72.2	46.7	63.3	62.3	84.4
12	18.9	25.6	25.1	34.1	48.6	66	64.9	88	69.7	94.5	92.2	125	81	110	108	147
14	30.1	40.8	40	54.3	77.4	105	103	140	110	150	147	200	129	175	172	234
16	46.9	63.6	62.5	84.8	125	170	166	226	173	235	230	313	202	274	269	365
18	64.5	87.5	86.2	117	171	233	229	311	238	323	317	430	278	377	371	503
20	91	124	121	165	243	330	325	441	337	458	450	610	394	535	525	713
22	124	169	166	225	331	450	442	600	458	622	612	830	536	727	715	970
24	157	214	210	285	420	570	562	762	583	791	778	1055	682	925	909	1233



Scheduled Maintenance Procedures



Observe and Obey:

- ☑ Maintenance inspections shall be completed by a person trained and qualified on the maintenance of this machine.
- ☑ Scheduled maintenance inspections shall be completed daily, quarterly, semi-annually, annually and every 2 years as specified on the *Maintenance Inspection Report*. The frequency and extent of periodical examinations and tests may also depend on national regulations.

⚠ WARNING Failure to perform each procedure as presented and scheduled may cause death, serious injury or substantial damage.

- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating machine.
- ☑ Use only Genie approved replacement parts.
- ☑ Unless otherwise specified, perform each maintenance procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Boom in stowed position
 - Turntable rotated with the boom between the non-steer wheels
 - Turntable secured with the turntable rotation lock
 - Key switch in the off position with the key removed
 - Wheels chocked
 - All external AC power supply disconnected from the machine

About This Section

This section contains detailed procedures for each scheduled maintenance inspection.

Each procedure includes a description, safety information and step-by-step instructions.

Symbols Legend



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

⚠ DANGER

Used to indicate the presence of an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING

Used to indicate the presence of a potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION

Used to indicate the presence of a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.

NOTICE

Used to indicate the presence of a potentially hazardous situation which, if not avoided, may result in property damage.

- ⦿ Indicates that a specific result is expected after performing a series of steps.
- ⊗ Indicates that an incorrect result has occurred after performing a series of steps.

SCHEDULED MAINTENANCE PROCEDURES

Maintenance Symbols Legend

The following symbols have been used in this manual to help communicate the intent of the instructions. When one or more of the symbols appear at the beginning of a maintenance procedure, it conveys the meaning below.



Indicates that tools will be required to perform this procedure.



Indicates that new parts will be required to perform this procedure.



Indicates that a cold engine will be required to perform this procedure.



Indicates that a warm engine will be required to perform this procedure.



Indicates that dealer service is required to perform this procedure.

Pre-delivery Preparation Report

The pre-delivery preparation report contains checklists for each type of scheduled inspection.

Make copies of the *Pre-delivery Preparation Report* to use for each inspection. Store completed forms as required.

Maintenance Schedule

There are five types of maintenance inspections that must be performed according to a schedule—daily, quarterly, semi-annually, annual and two years. The *Scheduled Maintenance Procedures Section* and the *Maintenance Inspection Report* have been divided into five subsections—A, B, C, D and E. Use the following chart to determine which group(s) of procedures are required to perform a scheduled inspection.

Inspection	Checklist
Daily or every 8 hours	A
Quarterly or every 250 hours	A + B
Semi-annually or every 500 hours	A + B + C
Annual or every 1000 hours	A + B + C + D
Two years or every 2000 hours	A + B + C + D + E

Maintenance Inspection Report

The maintenance inspection report contains checklists for each type of scheduled inspection.

Make copies of the *Maintenance Inspection Report* to use for each inspection. Maintain completed forms for a minimum of 4 years or in compliance with employer, jobsite and governmental regulations and requirements.

Pre-Delivery Preparation

Fundamentals

It is the responsibility of the dealer to perform the Pre-delivery Preparation.

The Pre-delivery Preparation is performed prior to each delivery. The inspection is designed to discover if anything is apparently wrong with a machine before it is put into service.

A damaged or modified machine must never be used. If damage or any variation from factory delivered condition is discovered, the machine must be tagged and removed from service.

Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications.

Scheduled maintenance inspections shall be performed by qualified service technicians, according to the manufacturer's specifications and the requirements listed in the responsibilities manual.

Instructions

Use the operator's manual on your machine.

The Pre-delivery Preparation consists of completing the Pre-operation Inspection, the Maintenance items and the Function Tests.

Use this form to record the results. Place a check in the appropriate box after each part is completed. Follow the instructions in the operator's manual.

If any inspection receives an N, remove the machine from service, repair and re-inspect it. After repair, place a check in the R box.

Legend

Y = yes, completed

N = no, unable to complete

R = repaired

Comments

Pre-Delivery Preparation	Y	N	R
Pre-operation inspection completed			
Maintenance items completed			
Function tests completed			

Model

Serial number

Date

Machine owner

Inspected by (print)

Inspector signature


Inspector title

Inspector company



Terex South Dakota, Inc USA
500 Oak Wood Road
PO Box 1150
Watertown, SD 57201-6150
(605) 882-4000

Genie UK
The Maltings, Wharf Road
Grantham, Lincolnshire
NG31-6BH England
(44) 1476-584333



This page intentionally left blank.

Maintenance Inspection Report

Model
Serial number
Date
Hour meter
Machine owner
Inspected by (print)
Inspector signature
Inspector title
Inspector company

Instructions

- Make copies of this report to use for each inspection.
- Select the appropriate checklist(s) for the type of inspection to be performed.

<input type="checkbox"/>	Daily or 8 hour Inspection:	A
<input type="checkbox"/>	Quarterly or 250 hour Inspection:	A+B
<input type="checkbox"/>	Semi-annual or 500 hour Inspection:	A+B+C
<input type="checkbox"/>	Annual or 1000 hours Inspection:	A+B+C+D
<input type="checkbox"/>	2 Year or 2000 hour Inspection:	A+B+C+D+E

- Place a check in the appropriate box after each inspection procedure is completed.
- Use the step-by-step procedures in this section to learn how to perform these inspections.
- If any inspection receives an "N", tag and remove the machine from service, repair and re-inspect it. After repair, place a check in the "R" box.

Legend

- Y = yes, acceptable
- N = no, remove from service
- R = repaired

Checklist A	Y	N	R
A-1 Manuals and decals			
A-2 Pre-operation inspection			
A-3 Functions tests			
A-4 Engine maintenance			
A-5 Filter condition indicator			
A-6 Oscillate axle			
A-7 Inspect tracks, S-60 TRAX and S-65 TRAX			
Perform after 40 hours:			
A-8 30 day service			
Perform every 30 days:			
A-9 Check track tension, S-60 TRAX and S-65 TRAX			
Perform every 100 hours:			
A-10 Engine maintenance - Ford and Perkins models			
A-11 Fuel filter/separator - Diesel models			
A-12 Check engine RPM- Perkins models			
A-13 Rotation bearing			
Perform after 150 hours:			
A-14 Drive hub oil			
Perform every 200 hours:			
A-15 Engine maintenance - Ford models			
A-16 Engine maintenance - Perkins models			

Checklist B	Y	N	R
B-1 Inspect battery			
B-2 Inspect electrical wiring			
B-3 Exhaust system			
B-4 Inspect air filter - Ford, Deutz and Perkins models			
B-5 Oil cooler and fins- Deutz models			
B-6 Tires and wheels, S-60, S-65, S-60 HC S-60X and S-60XC			
B-7 Brake configuration			
B-8 Drive hub oil level			
B-9 Engine RPM - Ford and Deutz models			
B-10 Ground control override			
B-11 Directional valve			
B-12 Platform leveling			
B-13 Engine idle select			
B-14 Fuel select - Ford models			
B-15 Drive brakes			
B-16 Drive speed - stowed position			
B-17 Drive speed - raised position			
B-18 Alarm package			
B-19 Hydraulic oil analysis			
B-20 Fuel and hydraulic tank cap venting			
B-21 Fuel filter element - Perkins models			
B-22 Inspect the Boom extend/retract cables			

Comments



MAINTENANCE INSPECTION REPORT

Model
Serial number
Date
Hour meter
Machine owner
Inspected by (print)
Inspector signature
Inspector title
Inspector company

- Instructions**
- Make copies of this report to use for each inspection.
 - Select the appropriate checklist(s) for the type of inspection to be performed.

<input type="checkbox"/>	Daily or 8 hour Inspection:	A
<input type="checkbox"/>	Quarterly or 250 hour Inspection:	A+B
<input type="checkbox"/>	Semi-annual or 500 hour Inspection:	A+B+C
<input type="checkbox"/>	Annual or 1000 hours Inspection:	A+B+C+D
<input type="checkbox"/>	2 Year or 2000 hour Inspection:	A+B+C+D+E

- Place a check in the appropriate box after each inspection procedure is completed.
- Use the step-by-step procedures in this section to learn how to perform these inspections.
- If any inspection receives an "N", tag and remove the machine from service, repair and re-inspect it. After repair, place a check in the "R" box.

Legend
 Y = yes, acceptable
 N = no, remove from service
 R = repaired

Checklist B (cont)	Y	N	R
Perform every 400 hours:			
B-23 Engine maintenance - Deutz models			
B-24 Engine maintenance - Ford models			
B-25 Replace air filter - Ford models			
B-26 Engine maintenance - Perkins models			

Checklist C	Y	N	R
C-1 Engine maintenance - Deutz models			
C-2 Grease platform overload (if equipped)			
C-3 Test platform overload, S-60, S-65, S-60 TRAX and S-65 TRAX (if equipped)			
C-4 Test load sense, S-60 HC			
C-5 Fuel filter/separator - Perkins models			
C-6 Replace air filter - Deutz and Perkins models			
C-7 Safety envelope S-60X, S-60XC			
Perform every 600 hours:			
C-8 Engine maintenance - Perkins models			
Perform every 800 hours:			
C-9 Engine maintenance - Ford models			

Checklist D	Y	N	R
D-1 Boom wear pads			
D-2 Turntable bearing bolts			
D-3 Turntable bearing wear			
D-4 Drive hub oil			
D-5 Free-wheel configuration			
D-6 Hydraulic filters			
D-7 Engine maintenance - Deutz models			

Checklist E	Y	N	R
E-1 Hydraulic oil			
Perform every 3000 hours:			
E-2 Engine maintenance - Deutz models			
Perform every 12,000 hours:			
E-3 Engine maintenance - Deutz models			
Perform every 10 years:			
E-4 Replace the Boom Extend/Retract cables			

Comments

Checklist A Procedures

A-1 Inspect the Manuals and Decals

Genie specifications require that this procedure be performed daily or every 8 hours, whichever comes first.

Maintaining the operator's and safety manuals in good condition is essential to safe machine operation. Manuals are included with each machine and should be stored in the container provided in the platform. An illegible or missing manual will not provide safety and operational information necessary for a safe operating condition.

In addition, maintaining all of the safety and instructional decals in good condition is mandatory for safe machine operation. Decals alert operators and personnel to the many possible hazards associated with using this machine. They also provide users with operation and maintenance information. An illegible decal will fail to alert personnel of a procedure or hazard and could result in unsafe operating conditions.

- 1 Check to make sure that the operator's and safety manuals are present and complete in the storage container on the platform.
 - 2 Examine the pages of each manual to be sure that they are legible and in good condition.
- ⦿ Result: The operator's manual is appropriate for the machine and all manuals are legible and in good condition.
 - ⊗ Result: The operator's manual is not appropriate for the machine or all manuals are not in good condition or are illegible. Remove the machine from service until the manual is replaced.

- 3 Open the operator's manual to the decals inspection section. Carefully and thoroughly inspect all decals on the machine for legibility and damage.
- ⦿ Result: The machine is equipped with all required decals, and all decals are legible and in good condition.
 - ⊗ Result: The machine is not equipped with all required decals, or one or more decals are illegible or in poor condition. Remove the machine from service until the decals are replaced.
- 4 Always return the manuals to the storage container after use.

Note: Contact your authorized Genie distributor or Genie if replacement manuals or decals are needed.



CHECKLIST A PROCEDURES

**A-2
Perform Pre-operation
Inspection**

Completing a Pre-operation Inspection is essential to safe machine operation. The Pre-operation Inspection is a visual inspection performed by the operator prior to each work shift. The inspection is designed to discover if anything is apparently wrong with a machine before the operator performs the function tests. The Pre-operation Inspection also serves to determine if routine maintenance procedures are required.

Complete information to perform this procedure is available in the appropriate operator's manual. Refer to the Operator's Manual on your machine.

**A-3
Perform Function Tests**

Completing the function tests is essential to safe machine operation. Function tests are designed to discover any malfunctions before the machine is put into service. A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service.

Complete information to perform this procedure is available in the appropriate operator's manual. Refer to the Operator's Manual on your machine.

CHECKLIST A PROCEDURES

A-4 Perform Engine Maintenance



Engine specifications require that this procedure be performed daily or every 8 hours, whichever comes first.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Deutz 2011 Series Operation Manual* (Deutz part number 0312-3547) OR the *Ford DSG-423 EFI Operator Handbook* (EDI part number 1060020) OR the *Ford MSG-425 EFI Operator Handbook* (EDI part number 1020010) OR the *Perkins 400 Series Operation Manual* (Perkins part number TPD 1443S).

Deutz 2011 Series Operation Manual	
Genie part number	139320
Ford DSG 423 EFI Operator Handbook	
Genie part number	119488
Ford MSG 425 EFI Operator Handbook	
Genie part number	215322
Perkins 400 Series Operation Manual	
Genie part number	94890

A-5 Check the High Pressure Hydraulic Filter Condition Indicator

Genie specifications require that this procedure be performed daily or every 8 hours, whichever comes first.

Maintaining the high pressure hydraulic filter in good condition is essential to good system performance and safe machine operation. The filter condition indicator will show when the hydraulic flow is bypassing a clogged filter. If the filter is not frequently checked and replaced, impurities will remain in the hydraulic system and cause component damage.

- 1 Open the engine side turntable cover.
 - 2 Start the engine from the ground controls.
 - 3 Change the engine idle to high rpm (rabbit symbol).
 - 4 Visually inspect the filter condition indicator.
- ⊙ Result: The filter condition indicator should be operating with the plunger in the green area.
- ⊗ Result: If the indicator displays the plunger in the red area, this indicates that the hydraulic filter is being bypassed and the filter should be replaced. See D-6, *Replace the Hydraulic Filters*.

CHECKLIST A PROCEDURES

A-6 Test the Oscillate Axle (if equipped)



Genie specifications require that this procedure be performed daily or every 8 hours, whichever comes first.

Proper axle oscillation is essential to safe machine operation. If the axle oscillation system is not operating correctly, the stability of the machine is compromised and it may tip over.

- 1 Start the engine from the platform controls.
- 2 Drive the right steer tire or track (if equipped) up onto a 6 inch / 15 cm block or curb.
 - ⊙ Result: The three remaining tires or tracks (if equipped) should stay in firm contact with the ground and the chassis should remain level at all times.
- 3 Drive the left steer tire or track (if equipped) up onto a 6 inch / 15 cm block or curb.
 - ⊙ Result: The three remaining tires or tracks (if equipped) should stay in firm contact with the ground and the chassis should remain level at all times.
- 4 Drive both steer tires or tracks (if equipped) up onto a 6 inch / 15 cm block or curb.
 - ⊙ Result: The non-steer tires or tracks (if equipped) should stay in firm contact with the ground.

Note: If the chassis does not remain level during test, refer to Repair Procedure 7-6, *How to Set Up the Oscillate Directional Valve*.

A-7 Inspect the Track Components, S-60 TRAX and S-65 TRAX



Genie specifications require that this procedure be performed daily or every 8 hours, whichever comes first.

Maintaining tracks and track assembly components is essential to safe operation and good performance. A track assembly failure could result in a machine tip-over. Component damage may also result if problems are not discovered and repaired in a timely fashion.

- 1 Thoroughly clean the track assembly of any dirt, rocks, clay, etc.
- 2 Inspect the following areas for damaged, cracked, loose or missing parts and fasteners:
 - Track
 - Idler wheels
 - Drive sprocket and hub
 - Bogey wheels
 - Undercarriage
 - Rotation limiter brackets attached to axles
 - Track assembly fasteners
 - King pin bushings

CHECKLIST A PROCEDURES

A-8 Perform 30 Day Service



The 30 day maintenance procedure is a one time sequence of procedures to be performed after the first 30 days or 40 hours of usage, whichever comes first. After this interval, refer to the maintenance tables for continued scheduled maintenance.

1 Perform the following maintenance procedures:

- A-10 Perform Engine Maintenance - Ford and Perkins Models
- A-13 Grease the Turntable Bearing and Rotate Gear
- B-6 Inspect the Tires, Wheels and Lug Nut Torque, S-60, S-65, S-60 HC, S-60X and S-60XC
- B-8 Check the Drive Hub Oil Level and Fastener Torque
- C-1 Perform Engine Maintenance - Deutz Models
- D-2 Check the Turntable Rotation Bearing Bolts
- D-6 Replace the Hydraulic Filters

A-9 Check the Track Tension and Fastener Torque, S-60 TRAX and S-65 TRAX




Manufacturer specifications require that this procedure be performed every 30 days.

Maintaining proper track tension and properly torqued fasteners is essential to good machine performance and service life. The machine will not operate properly with a track that is incorrectly tensioned. Continued use of a machine with incorrectly tensioned tracks may cause component damage.


- 1 Thoroughly clean the track assembly of any dirt, rocks, clay, etc.
- 2 Chock the tracks at one end of the machine to prevent the machine from rolling.
- 3 Center a lifting jack of ample capacity (20,000 lbs / 10,000 kg) under the drive chassis between the tracks at the other end of the machine.
- 4 Lift the machine until the tracks are off the ground and then place jack stands under the drive chassis for support.

CHECKLIST A PROCEDURES

- 5 Visually inspect the section of track under the bogey wheels.
- ⊙ Result: There should be less than 1 inch / 2.5 cm of gap between the bogey wheels and the inside surface of the track. Proceed to step 12.
- ⊗ Result: There is 1 inch / 2.5 cm or more of gap between the bogey wheels and the inside surface of the track. Proceed to step 6.



- 6 Locate the grease plug on the track tension cylinder. Loosen the plug, but do not remove it.



- 7 Locate the grease zerk fitting on the other side of the track tension cylinder.
- 8 Pump grease into the grease zerk fitting until grease, free from air, comes out of the grease plug. Securely tighten the grease plug. Do not overtighten.
- 9 Continue to pump grease into the grease zerk fitting just until the idler wheel moves. Check the track tension.
- 10 If necessary, continue to pump grease into the cylinder until the track has proper tension.

NOTICE Component damage hazard. Do not over tighten the track. Overtightening the track will cause the machine to lose power during operation.

Note: If the track becomes too tight, loosen the grease plug on the cylinder to remove grease and loosen the track.

- 11 Clean up any grease that may have spilled.
- 12 Check the torque of the track assembly fasteners. Refer to Section 2, *Specifications*.
- 13 Raise the machine, remove the jack stands and lower the machine.
- 14 Repeat this procedure for each track assembly.

Grease Specification

Chevron Ultra-duty grease, EP NLGI 2 (lithium based) or equivalent.

CHECKLIST A PROCEDURES

A-10 Perform Engine Maintenance - Ford and Perkins Models



Engine specifications require that this procedure be performed every 100 hours. Perform this procedure more often if dusty conditions exist or the machine is subjected to extended low idle operation.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Ford DSG-423 EFI Operator Handbook* (EDI part number 1060020) OR the *Ford MSG-425 EFI Operator Handbook* (EDI part number 1020010) OR the *Perkins 400 Series Operation Manual* (Perkins part number TPD 1443S).

Ford DSG 423 EFI Operator Handbook	
Genie part number	119488
Ford MSG 425 EFI Operator Handbook	
Genie part number	215322
Perkins 400 Series Operation Manual	
Genie part number	94890

A-11 Inspect the Fuel Filter/Water Separator - Diesel Models



Genie specifications require that this procedure be performed every 100 hours or monthly, whichever comes first.

Proper maintenance of the fuel filter/water separator is essential for good engine performance. Failure to perform this procedure can lead to poor engine performance and/or hard starting, and continued use may result in component damage. Extremely dirty conditions may require this procedure be performed more often.

CAUTION Explosion and fire hazard. Engine fuels are combustible. Perform this procedure in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.


Note: Perform this procedure with the engine off.

Perkins Models:

- 1 Put on protective clothing and eye wear.
 - 2 Open the engine side turntable cover and locate the fuel filter/water separator next to the hydraulic return filter on the bulkhead.
 - 3 Inspect the filter bowl for water buildup.
- ⊙ Result: If water is present in the filter bowl continue with steps 4 through 8.

CHECKLIST A PROCEDURES

- 4 Loosen the vent plug located on the fuel filter/water separator head.



- 5 Loosen the drain plug located at the bottom of the bowl. Allow the water to drain into a suitable container until fuel starts to come out. Immediately tighten the drain plug.

- 6 Tighten the vent plug.

Note: If the fuel filter/water separator is completely drained, you must prime the fuel filter/water separator before starting the engine. See C-6, *Replace The Fuel Filter/Water Separator Element - Perkins Models*, for instructions on how to prime the fuel filter/water separator.

- 7 Clean up any fuel that may have spilled.

- 8 Start the engine from the ground controls and check the fuel filter/water separator and vent plug for leaks.

⚠ DANGER

Explosion and fire hazard. If a fuel leak is discovered, keep any additional personnel from entering the area and do not operate the machine. Repair the leak immediately.

Deutz Models:

- Put on protective clothing and eye wear.
- Remove the engine tray retaining fastener located under the engine tray. Swing the engine tray out and away from the machine.
- Install the fastener that was just removed through the engine tray and into the engine tray anchor hole in the turntable.

⚠ WARNING


Crushing hazard. Failure to install the fastener into the engine tray anchor hole to secure the engine tray from moving could result in death or serious injury.

- Locate the fuel filter/water separator next to the oil filter.

CHECKLIST A PROCEDURES

- 5 Loosen the drain plug located at the bottom of the filter. Allow the water to drain into a suitable container until fuel starts to come out. Immediately tighten the drain plug.

Note: Do not completely drain the filter.



a fuel filter/water separator
b drain valve

- 6 Clean up any fuel that may have spilled.
- 7 Start the engine from the ground controls and check the fuel filter/water separator for leaks.

▲ DANGER Explosion and fire hazard. If a fuel leak is discovered, keep any additional personnel from entering the area and do not operate the machine. Repair the leak immediately.

- 8 Swing the engine back to its original position and install the engine pivot plate retaining fastener.

A-12 Check and Adjust the Engine RPM - Perkins Models



Engine specifications require that this procedure be performed every 100 hours.

Maintaining the engine rpm at the proper setting for both low and high idle is essential to good engine performance and service life. The machine will not operate properly if the rpm is incorrect and continued use may cause component damage.


Note: This procedure will require two people.

- 1 Connect a tachometer to the engine. Start the engine from the ground controls and check the rpm. Refer to Section 2, *Specifications*.

Skip to step 3 if the low idle rpm is correct.

CHECKLIST A PROCEDURES

- Loosen the low idle lock nut and turn the low idle adjustment screw clockwise to increase the rpm, or counterclockwise to decrease the rpm. Tighten the low idle lock nut and confirm the rpm.



- a solenoid boot
- b high idle adjustment nut
- c yoke
- d low idle lock nut and adjustment screw

- Move the function enable toggle switch to the high idle (rabbit symbol) position and note the rpm. Refer to Section 2, *Specifications*.

If high idle rpm is correct, disregard adjustment step 4.

- Loosen the yoke lock nut, then turn the high idle adjustment nut and solenoid boot counterclockwise to increase the rpm or clockwise to decrease the rpm. Tighten the yoke lock nut and recheck the rpm.

Note: Be sure the solenoid fully retracts when activating high idle.

A-13 Grease the Turntable Rotation Bearing and Rotate Gear



Genie specifications require that this procedure be performed every 100 hours of operation. Perform this procedure more often if dusty conditions exist.

Frequent application of lubrication to the turntable bearing and rotate gear is essential to good machine performance and service life. Continued use of an improperly greased bearing and gear will result in component damage.

- Locate the grease fitting on the front turntable cover.
- Pump grease into the turntable rotation bearing. Rotate the turntable in increments of 4 to 5 inches / 10 to 13 cm at a time and repeat this step until the entire bearing has been greased.
- Apply grease to each tooth of the drive gear, located under the turntable.

Grease Specification

Chevron Ultra-duty grease, EP NLGI 2 (lithium based) or equivalent

CHECKLIST A PROCEDURES

A-14 Replace the Drive Hub Oil




Manufacturer drive hub specifications require that this one-time procedure be performed after the first 150 hours.

Replacing the drive hub oil is essential for good machine performance and service life. Failure to replace the drive hub oil after the first 150 hours of use may cause the machine to perform poorly and continued use may cause component damage.

S-60, S-65, S-60 HC, S-60X and S-60XC:

- 1 Select the drive hub to be serviced. Drive the machine until one of the two plugs is at the lowest point.
- 2 Remove both plugs and drain the oil into a suitable container.
- 3 Drive the machine until both plugs are horizontal.



a drive hub plugs

- 4 Fill the hub until the oil level is even with the bottom of the plug hole. Refer to Section 2, *Specifications*.
- 5 Install the plugs into the drive hub.
- 6 Repeat this procedure for the other drive hub.


S-60 TRAX and S-65 TRAX:

- 1 Select the drive hub to be serviced. Loosen and remove as many sprocket retaining fasteners as possible from the hub adapter.
- 2 Drive the machine in either direction just enough to access the remaining fasteners. Do not remove the retaining fasteners.
- 3 Chock the tracks at the opposite end of the machine to prevent the machine from rolling.
- 4 Center a lifting jack of ample capacity (20,000 lbs / 10,000 kg) under the drive chassis between the tracks.
- 5 Lift the machine until the tracks are off the ground and then place jack stands under the drive chassis for support.
- 6 Attach a lifting strap from an overhead crane to the center-point of the track assembly, above the sprocket.
- 7 Remove the remaining sprocket retaining fasteners from the hub adapter.
- 8 Carefully remove the track assembly from the drive hub and set aside.

CAUTION Crushing hazard. The track assembly could become unbalanced and fall when removed from the machine if not properly supported by the overhead crane.

CHECKLIST A PROCEDURES

- 9 Locate the hub disconnect pin in the center of the drive hub. Manually depress the pin and rotate the drive hub until one of the two plugs is at the lowest point.



a drive hub plugs

- 10 Remove both plugs and drain the oil into a suitable container.
- 11 Manually depress the hub disconnect pin and rotate the drive hub until both plugs are horizontal.
- 12 Fill the hub until the oil level is even with the bottom of the side plug hole. Refer to Section 2, *Specifications*.
- 13 Install the plugs into the drive hub.
- 14 Attach a lifting strap from an overhead crane to the center-point of the track assembly, above the sprocket.
- 15 Install the track assembly onto the drive hub adapter while guiding the hub adapter studs into the sprocket of the track assembly. Install as many sprocket retaining fasteners as possible to the hub adapter and torque to specification. Refer to Section 2, *Specifications*.
- 16 Raise the machine, remove the jack stands and lower the machine.
- 17 Drive the machine in either direction just until the remaining sprocket retaining fasteners can be installed onto the drive hub adapter. Turn the machine off.
- 18 Install the remaining sprocket retaining fasteners to the drive hub adapter and torque to specification. Refer to Section 2, *Specifications*.
- 19 Repeat this procedure for each drive hub.

CHECKLIST A PROCEDURES

A-15 Perform Engine Maintenance - Ford Models



Engine specifications require that this procedure be performed every 200 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Ford DSG-423 EFI Operator Handbook* (EDI part number 1060020) OR the *Ford MSG-425 EFI Operator Handbook* (EDI part number 1020010).

Ford DSG 423 EFI Operator Handbook	
Genie part number	119488

Ford MSG 425 EFI Operator Handbook	
Genie part number	215322

A-16 Perform Engine Maintenance - Perkins Models



Engine specifications require that this procedure be performed every 200 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Perkins 400 Series Operation Manual* (Perkins part number TPD 1443S).

Perkins 400 Series Operation Manual	
Genie part number	94890

Checklist B Procedures

B-1 Inspect the Battery



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper battery condition is essential to good engine performance and operational safety. Improper fluid levels or damaged cables and connections can result in engine component damage and hazardous conditions.

⚠ WARNING Electrocutation/burn hazard. Contact with hot or live circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

⚠ WARNING Bodily injury hazard. Batteries contain acid. Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

- 1 Put on protective clothing and eye wear.
- 2 Be sure that the battery cable connections are free of corrosion.

Note: Adding terminal protectors and a corrosion preventative sealant will help eliminate corrosion on the battery terminals and cables.

- 3 Be sure that the battery hold downs and cable connections are tight.

- 4 Be sure that the battery separator wire connections are tight (if equipped).
- 5 Fully charge the battery(s) and allow the battery(s) to rest at least 6 hours.
- 6 Remove the battery vent caps and check the specific gravity of each battery cell with a hydrometer. Note the results.
- 7 Check the ambient air temperature and adjust the specific gravity reading for each cell as follows:
 - Add 0.004 to the reading of each cell for every 10° / 5.5° C above 80° F / 26.7° C.
 - Subtract 0.004 from the reading of each cell for every 10° / 5.5° C below 80° F / 26.7° C.
- ⊕ Result: All battery cells display an adjusted specific gravity of 1.277 or higher. The battery is fully charged. Proceed to step 11.
- ⊗ Result: One or more battery cells display a specific gravity of 1.217 or below. Proceed to step 8.
- 8 Perform an equalizing charge OR fully charge the battery(s) and allow the battery(s) to rest at least 6 hours.
- 9 Remove the battery vent caps and check the specific gravity of each battery cell with a hydrometer. Note the results.

CHECKLIST B PROCEDURES

10 Check the ambient air temperature and adjust the specific gravity reading for each cell as follows:

- Add 0.004 to the reading of each cell for every 10° / 5.5° C above 80° F / 26.7° C.
- Subtract 0.004 from the reading of each cell for every 10° / 5.5° C below 80° F / 26.7° C.
- ⦿ Result: All battery cells display a specific gravity of 1.277 or greater. The battery is fully charged. Proceed to step 13.
- ⊗ Result: The difference in specific gravity readings between cells is greater than 0.1 OR the specific gravity of one or more cells is less than 1.177. Replace the battery.

11 Check the battery acid level. If needed, replenish with distilled water to $\frac{1}{8}$ inch / 3 mm below the bottom of the battery fill tube. Do not overfill.

12 Install the vent caps and neutralize any electrolyte that may have spilled.

B-2 Inspect the Electrical Wiring



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining electrical wiring in good condition is essential to safe operation and good machine performance. Failure to find and replace burnt, chafed, corroded or pinched wires could result in unsafe operating conditions and may cause component damage.

⚠ WARNING Electrocuting/burn hazard. Contact with hot or live circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 1 Open the engine side turntable cover.
- 2 Remove the engine tray retaining fastener located under the engine tray. Swing the engine tray out and away from the machine.
- 3 Install the fastener that was just removed through the engine tray and into the engine tray anchor hole in the turntable.

⚠ WARNING Crushing hazard. Failure to install the fastener into the engine tray anchor hole to secure the engine tray from moving could result in death or serious injury.

CHECKLIST B PROCEDURES

- 4 Inspect the following areas for burnt, chafed, corroded and loose wires:
 - Engine wiring harness
 - Hydraulic manifold wiring
- 5 Open the ground controls side turntable cover.
- 6 Inspect the following areas for burnt, chafed, corroded and loose wires:
 - Inside of the ground control box
 - Hydraulic manifold wiring
- 7 Inspect for a liberal coating of dielectric grease at the following location:
 - All wire harnesses connectors to the ground control box
- 8 Start the engine from the ground controls and raise the boom above the turntable covers.
- 9 Inspect the turntable area for burnt, chafed and pinched cables.
- 10 Lower the boom to the stowed position and turn the engine off.
- 11 Inspect the following areas for burnt, chafed, corroded, pinched and loose wires:
 - Cable track on the primary boom
 - Cables on the primary, and jib booms
 - Jib boom/Platform rotate manifold
 - Inside of the platform control box
- 12 Inspect for a liberal coating of dielectric grease at the following location:
 - All wire harnesses connectors to the platform control box
- 13 Swing the engine back to its original position and install the engine tray retaining fastener.

B-3 Check the Exhaust System



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the exhaust system is essential to good engine performance and service life. Running the engine with a damaged or leaking exhaust system can cause component damage and unsafe operating conditions.

▲WARNING Bodily injury hazard. Do not inspect while the engine is running. Remove the key to secure from operation.

▲CAUTION Burn hazard. Beware of hot engine components. Contact with hot engine components may result in severe burns.

- 1 Remove the engine tray retaining fastener located under the engine tray. Swing the engine tray out and away from the machine.
- 2 Install the fastener that was just removed through the engine tray and into the engine tray anchor hole in the turntable.

▲WARNING Crushing hazard. Failure to install the fastener into the engine tray anchor hole to secure the engine tray from moving could result in death or serious injury.

- 3 Be sure that all nuts and bolts are tight.
- 4 Inspect all welds for cracks.
- 5 Inspect for exhaust leaks; i.e., carbon buildup around seams and joints.
- 6 Swing the engine back to its original position and install the engine tray retaining fastener.

CHECKLIST B PROCEDURES

B-4 Inspect the Engine Air Filter - Ford, Deutz and Perkins Models



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the engine air filter in good condition is essential to good engine performance and service life. Failure to perform this procedure can lead to poor engine performance and component damage.

Note: Perform this procedure with the engine off.

- 1 Locate the engine air filter assembly.
- 2 Release the latches from the air cleaner canister end cap. Remove the end cap.
- 3 Remove the filter element.
- 4 Clean the inside of the canister and the end cap with a damp cloth.
- 5 Inspect the air filter element. If needed, blow from the inside out using low pressure dry compressed air, or carefully tap out dust. Replace the filter if needed.
- 6 Install the filter element.
- 7 Install the air filter canister end cap and secure the end cap latches.

Note: Be sure the discharge valve is pointing down when the cap is installed.

B-5 Check the Oil Cooler and Cooling Fins - Deutz Models



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the oil cooler in good condition is essential for good engine performance. Operating a machine with a damaged oil cooler may result in engine damage. Also, restricting air flow through the oil cooler will affect the performance of the cooling system.

▲WARNING Bodily injury hazard. Do not inspect while the engine is running. Remove the key to secure from operation.

▲CAUTION Burn hazard. Beware of hot engine components. Contact with hot engine components may result in severe burns.


Oil cooler:

- 1 Remove the engine tray retaining fastener located under the engine tray. Swing the engine tray out and away from the machine.
- 2 Install the fastener that was just removed through the engine tray and into the engine tray anchor hole in the turntable.

▲WARNING Crushing hazard. Failure to install the fastener into the engine tray anchor hole to secure the engine tray from moving could result in death or serious injury.

CHECKLIST B PROCEDURES

- 3 Remove the fasteners from the engine side cover, then remove the cover.
- 4 Inspect the oil cooler for leaks and physical damage.



- a oil cooler
- b cylinder head cooling fins
- c fan blower fins

- 5 Clean the oil cooler of debris and foreign material.

Cooling and fan blower fins:

- 6 Inspect the fan blower fins for physical damage.
- 7 Clean the fan blower fins of debris and foreign material.
- 8 Inspect the head cooling passages and fins for physical damage or foreign material, using a flashlight.
- 9 Clean the cylinder head cooling passages of debris and foreign material.
- 10 Install the engine side cover.
- 11 Swing the engine back to its original position and install the engine pivot plate retaining fastener.

B-6**Inspect the Tires, Wheels and Lug Nut Torque, S-60, S-65, S-60 HC, S60X and S-60XC**

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the tires and wheels, including proper wheel fastener torque, is essential to safe operation and good performance. Tire and/or wheel failure could result in a machine tip-over. Component damage may also result if problems are not discovered and repaired in a timely fashion.

▲WARNING Bodily injury hazard. An over-inflated tire can explode and could cause death or serious injury.

▲WARNING Tip-over hazard. Do not use temporary flat tire repair products.

Note: The tires on some machines are foam-filled and do not need air added to them.

- 1 Check all tire treads and sidewalls for cuts, cracks, punctures and unusual wear.
- 2 Check each wheel for damage, bends and cracked welds.
- 3 Check each lug nut for proper torque. Refer to Section 2, *Specifications*.
- 4 Check the pressure in each air-filled tire. Refer to Section 2, *Specifications*.

CHECKLIST B PROCEDURES

B-7 Confirm the Proper Brake Configuration




Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.


Proper brake configuration is essential to safe operation and good machine performance. Hydrostatic brakes and hydraulically-released, spring-applied individual wheel brakes can appear to operate normally when they are actually not fully operational.

- 1 Locate the drive hub disconnect cap.

Models with RT tires




Models with TRAX



a drive hub disconnect cap

- 2 Check each drive hub disconnect cap to be sure it is in the engaged position.



B-8 Check the Drive Hub Oil Level and Fastener Torque




Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Failure to maintain proper drive hub oil levels may cause the machine to perform poorly and continued use may cause component damage.

S-60, S-65, S-60 HC, S-60X and S-60XC:

- 1 Drive the machine to rotate the hub until the plugs are both horizontal.



a drive hub plugs

- 2 Remove one plug and check the oil level.
 - ⦿ Result: The oil level should be even with the bottom of the plug hole.
- 3 If necessary, remove the other plug and add oil until the oil level is even with the bottom of the plug hole.
- 4 Install the plug(s) into the drive hub.
- 5 Check the torque of the drive hub mounting bolts. Refer to Section 2, *Specifications*.
- 6 Repeat this procedure for each drive hub.




CHECKLIST B PROCEDURES

S-60 TRAX and S-65 TRAX:

- 1 Select the drive hub to be serviced. Loosen and remove as many sprocket retaining fasteners as possible from the hub adapter.
- 2 Drive the machine in either direction just enough to access the remaining fasteners. Do not remove the retaining fasteners.
- 3 Chock the tracks at the opposite end of the machine to prevent the machine from rolling.
- 4 Center a lifting jack of ample capacity (20,000 lbs / 10,000 kg) under the drive chassis between the tracks.
- 5 Lift the machine until the tracks are off the ground and then place jack stands under the drive chassis for support.
- 6 Attach a lifting strap from an overhead crane to the center-point of the track assembly, above the sprocket.
- 7 Remove the remaining sprocket retaining fasteners from the hub adapter.
- 8 Carefully remove the track assembly from the drive hub and set aside.

CAUTION Crushing hazard. The track assembly could become unbalanced and fall when removed from the machine if not properly supported by the overhead crane.

- 9 Locate the hub disconnect pin in the center of the drive hub. Manually depress the pin and rotate the drive hub until the plugs are both horizontal.



a drive hub plugs


- 10 Remove one plug and check the oil level.
 - ⊙ Result: The oil level should be even with the bottom of the plug hole.
- 11 If necessary, remove the other plug and add oil until the oil level is even with the bottom of the plug hole. Refer to Section 2, *Specifications*.
- 12 Install the plug(s) into the drive hub.
- 13 Check the torque of the drive hub mounting bolts. Refer to Section 2, *Specifications*.
- 14 Attach a lifting strap from an overhead crane to the center-point of the track assembly, above the sprocket.

CHECKLIST B PROCEDURES

- 15 Install the track assembly onto the drive hub adapter while guiding the hub adapter studs into the sprocket of the track assembly. Install as many sprocket retaining fasteners as possible to the hub adapter and torque to specification. Refer to Section 2, *Specifications*.
- 16 Raise the machine, remove the jack stands and lower the machine.
- 17 Drive the machine in either direction just until the remaining sprocket retaining fasteners can be installed onto the drive hub adapter. Turn the machine off.
- 18 Install the remaining sprocket retaining fasteners to the drive hub adapter and torque to specification. Refer to Section 2, *Specifications*.
- 19 Repeat this procedure for each drive hub.

Turntable rotate drive hub

- 1 Remove the plug located on the side of the hub and check the oil level.
- ⊙ Result: The oil level should be even with the bottom of the plug hole.



a drain/fill plug
b mounting fasteners

- 2 If necessary, add oil until the oil level is even with the bottom of the plug hole.
- 3 Apply pipe thread sealant to the plug, and install the plug in the drive hub.
- 4 Check the torque of the turntable drive hub mounting fasteners. Refer to Section 2, *Specifications*.

CHECKLIST B PROCEDURES

B-9**Check and Adjust the Engine RPM - Ford and Deutz Models**

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the engine rpm at the proper setting for both low and high idle is essential to good engine performance and service life. The machine will not operate properly if the rpm is incorrect and continued use may cause component damage.

Ford models:

Note: The engine rpm is controlled by the ECM and can only be adjusted by re-programming the ECM. If rpm adjustment or service is required, please contact Genie Service Department OR your local Ford dealer.

Deutz models:

Note: This procedure will require two people.


- 1 Remove the engine tray retaining fastener located under the engine tray. Swing the engine tray out and away from the machine.
- 2 Install the fastener that was just removed through the engine tray and into the engine tray anchor hole in the turntable.

WARNING Crushing hazard. Failure to install the fastener into the engine tray anchor hole to secure the engine tray from moving could result in death or serious injury.

- 3 Connect a tachometer to the engine, and then start the engine from the ground controls and check the rpm. Refer to Section 2, *Specifications*.

Skip to step 5 if the low idle rpm is correct.

- 4 Loosen the low idle lock nut, then turn the low idle adjustment screw clockwise to increase the rpm or counterclockwise to decrease the rpm. Tighten the low idle lock nut and recheck the rpm.



- a solenoid boot
- b high idle adjustment nut
- c yoke lock nut
- d yoke
- e low idle adjustment screw
- f low idle lock nut

- 5 Move the function enable/rpm select toggle switch to the high idle (rabbit symbol) position at the ground controls and check the rpm. Refer to Section 2, *Specifications*.

If high idle rpm is correct, disregard adjustment step 6.

- 6 Loosen the yoke lock nut, then turn the high idle adjustment nut and solenoid boot counterclockwise to increase the rpm or clockwise to decrease the rpm. Tighten the yoke lock nut and recheck the rpm.

Note: Be sure the solenoid fully retracts when activating high idle.

- 7 Swing the engine back to its original position and install the engine pivot plate retaining fastener.

CHECKLIST B PROCEDURES

B-10 Test the Ground Control Override

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

A properly functioning ground control override is essential to safe machine operation. The ground control override function is intended to allow ground personnel to operate the machine from the ground controls whether or not the Emergency Stop button on the platform controls is in the on or off position. This function is particularly useful if the operator at the platform controls cannot return the boom to the stowed position.

- 1 Push in the platform red Emergency Stop button to the off position.
 - 2 Start the engine from the ground controls.
 - 3 At the ground controls, operate each boom function through a partial cycle.
- ⊙ Result: All boom functions should operate.

B-11 Check the Oscillate Directional Valve Linkage



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Note: Perform this test only on models equipped with a oscillating axle.

Proper axle oscillation is essential to safe machine operation. If the oscillate directional valve linkage is not operating correctly, the stability of the machine is compromised and it may tip over.

- 1 Remove the drive chassis cover from the non-steer end of the machine.
- 2 Locate the oscillate directional valve inside of the non-steer axle and inspect the linkage for the following:
 - Lock nut is tight against yoke
 - Yoke clevis pins are installed
 - Cotter pins are installed through clevis pins
 - Linkage is properly attached to directional valve

CHECKLIST B PROCEDURES

B-12 Test the Platform Self-leveling



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Automatic platform self-leveling throughout the full cycle of boom raising and lowering is essential for safe machine operation. The platform is maintained at level by the platform leveling slave cylinder which operates in a closed loop hydraulic circuit with the master cylinder located at the base of the boom.

A platform self-leveling failure creates an unsafe working condition for platform and ground personnel.

- 1 Start the engine from the ground controls and lower the boom into the stowed position.
- 2 Hold the function enable/rpm select toggle switch to either side and adjust the platform to a level position using the platform level toggle switch.
- 3 Raise and lower the primary boom through a full cycle.
- ⦿ Result: The platform should remain level at all times to within ± 5 degrees.

B-13 Test the Engine Idle Select

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

A properly operating engine idle select switch is essential to good engine performance and safe machine operation. There are two settings.

Foot switch activated low idle (turtle symbol) allows the operator to control individual boom functions.

Foot switch activated high idle (rabbit symbol) should be used for normal machine operation. This selection activates high idle only when the foot switch is pressed down.

- 1 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 2 Start the engine from the ground controls then move and hold the function enable/rpm select toggle switch to the high idle (rabbit symbol).
- ⦿ Result: The engine should change to high idle.
- 3 Release the function enable/rpm select toggle switch.
- ⦿ Result: The engine should return to low idle.
- 4 Turn the key switch to platform controls.
- 5 Move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol).
- ⦿ Result: The engine should **not** change to high idle.
- 6 Press down the foot switch.
- ⦿ Result: The engine should change to high idle.
- 7 Move the engine idle control switch to foot switch activated low idle (turtle symbol).
- ⦿ Result: The engine should change to low idle.

CHECKLIST B PROCEDURES

B-14

Test the Fuel Select Operation - Ford Models



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

The ability to select and switch between gasoline and LPG fuels as needed is essential to safe machine operation. A fuel selection can be made when the engine is running or not. Switching malfunctions and/or the failure of the engine to start and run properly in both fuel modes and through all idle speeds can indicate fuel system problems that could develop into a hazardous situation.

Note: Perform this test after checking the gasoline and LPG fuel levels, and warming the engine to normal operating temperature.

- 1 At the platform controls, move the fuel select switch to gasoline and then move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol).
 - 2 Start the engine from the platform controls and allow it to run at low idle.
 - 3 Press down the foot switch to allow the engine to run at high idle.
- ⦿ **Result:** The engine should start promptly and operate smoothly in low and high idle.

- 4 Release the foot switch and shut the engine off by pushing in the red Emergency Stop button in to the off position.
 - 5 Move the fuel select switch to LPG.
 - 6 Restart the engine and allow it to run at low idle.
 - 7 Press down the foot switch to allow the engine to run at high idle.
- ⦿ **Result:** The engine should start promptly and operate smoothly in low and high idle.

Note: The engine may hesitate momentarily and then continue to run on the selected fuel if the fuel source is switched while the engine is running.

CHECKLIST B PROCEDURES

B-15**Test the Drive Brakes**

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper brake action is essential to safe machine operation. The drive brake function should operate smoothly, free of hesitation, jerking and unusual noise. Hydrostatic brakes and hydraulically-released individual wheel brakes can appear to operate normally when they are actually not fully operational.

AWARNING Collision hazard. Be sure that the machine is not in free-wheel or partial free-wheel configuration. See B-7, *Confirm the Proper Brake Configuration*.

Note: Select a test area that is firm, level and free of obstructions.

- 1 Mark a test line on the ground for reference.
- 2 Start the engine from the platform controls.
- 3 Move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol), then lower the boom into the stowed position.
- 4 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the test line.
- 5 Bring the machine to top drive speed before reaching the test line. Release the drive joystick when your reference point on the machine crosses the test line.
- 6 Measure the distance between the test line and your machine reference point. Refer to Section 2, *Specifications*.

Note: The brakes must be able to hold the machine on any slope it is able to climb.

B-16**Test the Drive Speed - Stowed Position**

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper drive function movement is essential to safe machine operation. The drive function should respond quickly and smoothly to operator control. Drive performance should also be free of hesitation, jerking and unusual noise over the entire proportionally controlled speed range.

Note: Select a test area that is firm, level and free of obstructions.

- 1 Create start and finish lines by marking two lines on the ground 40 feet / 12.2 m apart.
- 2 Start the engine from the platform controls.
- 3 Move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol), then lower the boom into the stowed position.
- 4 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the start and finish lines.
- 5 Bring the machine to top drive speed before reaching the start line. Begin timing when your reference point on the machine crosses the start line.
- 6 Continue at full speed and note the time when the machine reference point crosses the finish line. Refer to Section 2, *Specifications*.

CHECKLIST B PROCEDURES

B-17

Test the Drive Speed - Raised or Extended Position



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper drive function movement is essential to safe machine operation. The drive function should respond quickly and smoothly to operator control. Drive performance should also be free of hesitation, jerking and unusual noise over the entire proportionally controlled speed range.

Note: Select a test area that is firm, level and free of obstructions.

- 1 Create start and finish lines by marking two lines on the ground 40 feet / 12.2 m apart.
- 2 Start the engine from the platform controls.
- 3 Move the engine idle select switch to foot switch activated high idle (rabbit and foot switch symbol).
- 4 Press down the foot switch and raise the primary boom above horizontal.
- 5 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the start and finish lines.
- 6 Bring the machine to top drive speed before reaching the start line. Begin timing when your reference point on the machine crosses the start line.
- 7 Continue at full speed and note the time when the machine reference point crosses the finish line. Refer to Section 2, *Specifications*.
- 8 Lower the boom to the stowed position and extend the boom 4 feet / 1.2 m.
- 9 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the start and finish lines.
- 10 Bring the machine to top drive speed before reaching the start line. Begin timing when your reference point on the machine crosses the start line.
- 11 Continue at top speed and note the time when the machine reference point crosses the finish line. Refer to Section 2, *Specifications*.



CHECKLIST B PROCEDURES

B-18**Test the Alarm Package -
Optional Equipment**

Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

The alarm package includes:

- Travel alarm
- Descent alarm
- Flashing beacon

Note: The descent alarm is standard equipment on all models after serial number 15908.

Alarms and a beacon are installed to alert operators and ground personnel of machine proximity and motion. The alarm package is installed on the turntable covers.

Note: The alarms and beacon will operate with the engine running or not running.

- 1 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
 - ⊙ Result: The flashing beacon should be on and flashing.
- 2 Move the function enable/rpm select toggle switch to either side and activate the boom toggle switch in the down position, hold for a moment and then release it.
 - ⊙ Result: The descent alarm should sound when the switch is held down.
- 3 **S-65 and S-65 TRAX:** Move the function enable/rpm select toggle switch to either side and activate the jib boom toggle switch in the down position, hold for a moment and then release it.
 - ⊙ Result: The descent alarm should sound when the switch is held down.
- 4 Turn the key switch to platform control.
 - ⊙ Result: The flashing beacon should be on and flashing.
- 5 Press down the foot switch. Move the boom control handle to the down position, hold for a moment and then release it.
 - ⊙ Result: The descent alarm should sound when the control handle is held down.
- 6 **S-65 and S-65 TRAX:** Press down the foot switch. Move the jib boom toggle switch to the down position, hold for a moment and then release it.
 - ⊙ Result: The descent alarm should sound when the control handle is held down.
- 7 Press down the foot switch. Move the drive control handle off center, hold for a moment and then release it. Move the drive control handle off center in the opposite direction, hold for a moment and then release it.
 - ⊙ Result: The travel alarm should sound when the drive control handle is moved off center in either direction.

CHECKLIST B PROCEDURES

B-19 Perform Hydraulic Oil Analysis



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Replacement or testing of the hydraulic oil is essential for good machine performance and service life. Dirty oil and a clogged suction strainer may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require oil changes to be performed more often. For hydraulic oil specifications, refer to Section 2, *Specifications*.

Note: Before replacing the hydraulic oil, the oil may be tested by an oil distributor for specific levels of contamination to verify that changing the oil is necessary. **If the hydraulic oil is not replaced at the two year inspection, test the oil quarterly. Replace the oil when it fails the test.**
See E-1, *Test or Replace the Hydraulic Oil*.

B-20 Inspect the Fuel and Hydraulic Tank Cap Venting Systems



Genie requires that this procedure be performed every 250 hours or quarterly, whichever comes first. Perform this procedure more often if dusty conditions exist.

Free-breathing fuel and hydraulic tank caps are essential for good machine performance and service life. A dirty or clogged tank cap may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the caps be inspected more often.

▲ DANGER

Explosion and fire hazard. Engine fuels are combustible. Perform this procedure in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

Note: Perform this procedure with the engine off.

- 1 Remove the cap from the fuel tank.
- 2 Check for proper venting.
- ⊙ Result: Air passes through the fuel tank cap. Proceed to step 4.
- ⊗ Result: If air does not pass through the cap, clean or replace the cap. Proceed to step 3.

Note: When checking for positive tank cap venting, air should pass freely through the cap.

CHECKLIST B PROCEDURES

3 Using a mild solvent, carefully wash the cap venting system. Dry using low pressure compressed air. Repeat this procedure beginning with step 2.

4 Install the fuel tank cap onto the fuel tank.

5 Remove the breather cap from the hydraulic tank.

6 Check for proper venting.

⊙ Result: Air passes through the hydraulic tank cap. Proceed to step 8.

⊗ Result: If air does not pass through the cap, clean or replace the cap. Proceed to step 7.

Note: When checking for positive tank cap venting, air should pass freely through the cap.

7 Using a mild solvent, carefully wash the cap venting system. Dry using low pressure compressed air. Repeat this procedure beginning with step 6.

8 Install the breather cap onto the hydraulic tank.

B-21**Replace the Fuel Filter Element - Perkins Models**

Engine specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

Replacing the diesel fuel filter element is essential for good engine performance and service life. A dirty or clogged filter may cause the engine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often.

⚠ DANGER

Explosion and fire hazard. Engine fuels are combustible. Perform this procedure in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

Note: Perform this procedure with the engine off.


- 1 Remove the engine tray retaining fastener located under the engine tray. Swing the engine tray out and away from the machine.
- 2 Install the fastener that was just removed through the engine tray and into the engine tray anchor hole in the turntable.

⚠ WARNING

Crushing hazard. Failure to install the fastener into the engine tray anchor hole to secure the engine tray from moving could result in death or serious injury.

CHECKLIST B PROCEDURES

- 3 Thoroughly clean the outside surfaces of the fuel filter assembly.
- 4 Place a suitable container under the fuel filter element.
- 5 Disconnect and plug the fuel line from the fuel pump to the fuel filter element.




a fuel line
b filter head
c fuel filter element

- 6 Remove the fuel filter element with a filter wrench.
- 7 Apply a thin layer of fuel to the new fuel filter element O-ring.
- 8 Install the new fuel filter element and tighten it securely by hand. Clean up any fuel that may have spilled during the installation procedure.
- 9 Use a permanent ink marker to write the date and number of hours from the hour meter on the oil filter housing.

Bleed the fuel system:

- 10 Loosen the vent plug on top of the fuel injection pump.



a vent plug
b fuel injection pump
c fuel lift pump

- 11 Operate the priming lever or priming bulb (if equipped) of the fuel lift pump until fuel, free from air, comes from the vent plug. Tighten the vent plug.
- 12 Clean up any fuel that may have spilled during this procedure.
- 13 Operate the starter motor for intervals of 15 seconds until the engine starts.
- 14 Swing the engine back to its original position and install the engine pivot plate retaining fastener.

Note: It is important to allow the starter motor to cool for 30 seconds between each 15 second interval of operation.

Note: If the engine runs correctly for a short time and then stops or runs roughly, check for air in the fuel system. If there is air in the fuel system, there is probably a leak in the low pressure side of the system.

CHECKLIST B PROCEDURES

B-22

Inspect the Boom Extend/Retract Cables



Genie specifications require that this procedure be performed every 250 hours or quarterly, whichever comes first.

The boom extend/retract cables are responsible for the extension and retraction of the number 3 boom tube. Inspecting for foreign objects, damage and/or improper adjustment of the boom extend/retract cables and related components on a regular basis is essential to good machine performance and safe machine operation. The boom extend and retract functions should operate smoothly and be free of hesitation, jerking and unusual noise.

- 1 Raise the boom to horizontal and fully extend the boom.
- 2 After the boom is fully extended, lower the boom until the platform is at chest height. Turn the machine off.
- 3 **S-60, S-65, S-60X, S-60XC, S-60 TRAX and S-65 TRAX:** Remove the boom end cover retaining fasteners and remove the cover.

S-60 HC: Remove the boom end cover from the pivot end of the boom while guiding the small cable from the string potentiometer out of the slot of the cover. Rest the cover and string potentiometer on the counterweight.

NOTICE

Component damage hazard. The cable from the string potentiometer can become damaged if it is kinked or pinched.

- 4 Remove the retaining fasteners from the access covers located on the side of the boom at the platform end of the machine. Remove the covers.
- 5 Visually inspect the cables and components through both inspection holes for the following:
 - Frayed or broken wire strands
 - Kinks in the cables
 - Corrosion
 - Paint or foreign materials on the cable
 - Split or cracked cable ends
 - Cables are on all pulleys
 - Extend cable break limit switch arm is centered in the pivot plate
 - Cables have equal tension
 - Cables at end of adjustment range
 - No broken or damaged pulleys
 - No unusual or excessive pulley wear
 - All fasteners in place and secure
 - **S-60 HC:** String potentiometer cable break limit switch arm is securely attached to end of cable

Note: A flashlight and inspection mirror may be necessary to thoroughly inspect the above items.

Note: A pulley groove gauge should be used to check the condition of the pulleys.

CHECKLIST B PROCEDURES

- 6 **S-60, S-65, S-60X, S-60XC, S-60 TRAX and S-65 TRAX:** Install the cover at the pivot end of the boom.

S-60 HC: Install the boom end cover at the pivot end of the boom while guiding the small cable from the string potentiometer into the slot of the cover.

NOTICE Component damage hazard. The cable from the string potentiometer can become damaged if it is kinked or pinched.

Note: Be sure the cable from the string potentiometer is correctly routed around the small pulley before installing the boom end cover.

- 7 Install the access panels on the sides of the boom.
- 8 Start the engine from the ground controls and fully retract and lower the boom to the stowed position.
- 9 Turn the key switch to the platform controls.
- 10 Extend the boom approximately 2 feet / 0.6 m.
- 11 Retract the boom. While retracting the boom, visually inspect the number 2 and number 3 boom tubes.
- ⦿ Result: The number 2 boom tube should not move more than 1/2 inch / 13 mm before the number 3 boom tube begins to retract.

Note: If the number 2 boom tube moves more than 1/2 inch / 13 mm before the number 3 boom tube begins to retract, the boom extend/retract cables need to be adjusted. See Repair Procedure 4-5, *How to Adjust the Boom Extend/Retract Cables*.

B-23 Perform Engine Maintenance - Deutz Models



Engine specifications require that this procedure be performed every 400 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Deutz 2011 Series Operation Manual* (Deutz part number 0312-3547).

Deutz 2011 Series Operation Manual

Genie part number

139320

CHECKLIST B PROCEDURES

B-24 Perform Engine Maintenance - Ford Models



Engine specifications require that this procedure be performed every 400 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Ford DSG-423 EFI Operator Handbook* (EDI part number 1060020) OR the *Ford MSG-425 EFI Operator Handbook* (EDI part number 1020010).

Ford DSG 423 EFI Operator Handbook	
Genie part number	119488
Ford MSG 425 EFI Operator Handbook	
Genie part number	215322

B-25 Replace the Engine Air Filter Element - Ford Models



Engine specifications require that this procedure be performed every 400 hours.

Maintaining the engine air filter in good condition is essential to good engine performance and service life. Failure to perform this procedure can lead to poor engine performance and component damage.

Note: Perform this procedure with the engine off.

- 1 Locate the engine air filter assembly.
- 2 Release the latches from the air cleaner canister end cap. Remove the end cap.
- 3 Remove and discard the filter element.
- 4 Clean the inside of the canister and the end cap with a damp cloth.
- 5 Install the new filter element.
- 6 Install the air filter canister end cap and secure the end cap latches.

Note: Be sure the discharge valve is pointing down when the cap is installed.

CHECKLIST B PROCEDURES

B-26

Perform Engine Maintenance - Perkins Models



Engine specifications require that this procedure be performed every 400 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Perkins 400 Series Operation Manual* (Perkins part number TPD 1443S).

Perkins 400 Series Operation Manual

Genie part number 94890

Checklist C Procedures

C-1 Perform Engine Maintenance - Deutz Models



Engine specifications require that this procedure be performed every 500 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Deutz 2011 Series Operation Manual* (Deutz part number 0312-3547).

Deutz 2011 Series Operation Manual	
Genie part number	139320

C-2 Grease the Platform Overload Mechanism (if equipped), S-60, S-65, S-60 TRAX and S-65 TRAX



Genie specifications require that this procedure be performed every 500 hours or six months, whichever comes first. Perform this procedure more often if dusty conditions exist.

Application of lubrication to the platform overload mechanism is essential to safe machine operation. Continued use of an improperly greased platform overload mechanism could result in the system not sensing an overloaded platform condition and will result in component damage.

- 1 Locate the grease fittings on each pivot pin of the platform overload assembly.
- 2 Thoroughly pump grease into each grease fitting.

Grease Specification

Chevron Ultra-duty grease, EP NLGI 2 (lithium based) or equivalent

CHECKLIST C PROCEDURES

C-3 Test the Platform Overload System (if equipped), S-60, S-65, S-60 TRAX and S-65 TRAX



Genie specifications require that this procedure be performed every 500 hours or six months, whichever comes first.

Testing the platform overload system regularly is essential to safe machine operation. Continued use of an improperly operating platform overload system could result in the system not sensing an overloaded platform condition. Machine stability could be compromised resulting in the machine tipping over.

The platform overload system is designed to detect an overloaded platform and prevent machine operation anytime the machine is turned on. When activated, the system halts all normal boom operation, giving visual and audible warning to the operator.

Models equipped with the platform overload option are provided with additional machine components: an adjustable spring-loaded platform support subassembly, a limit switch, an electronic module which receives the overload signal and interrupts power, and an audio/visual warning indication to alert the operator of the overload.

The platform support subassembly utilizes two load support arms that are opposed in a full parallelogram link. This isolates platform loads into a shear or vertical state, which translates into a compressive load. A spring in the parallelogram link supports this purely compressive load regardless of where the load is placed in the platform.

As weight is added to the platform, the spring will compress until, when the platform is overloaded, the lower arm contacts a limit switch and thereby activating the overload signal. When adjusted correctly, the platform overload system will deactivate normal boom operation at platform capacity.

Note: Perform this procedure with the boom fully retracted and in the stowed position and with the machine on a firm, level surface.

- 1 Remove all weight, tools and equipment from the platform.

Note: Failure to remove all weight, tools and accessories from the platform will result in an inaccurate test.

- 2 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position at both the ground and platform controls. Start the engine from the ground controls and level the platform. Do not turn the engine off.

CHECKLIST C PROCEDURES

- 3 Determine the maximum platform capacity. Refer to the machine serial plate.
- 4 Using a suitable lifting device, place a test weight equal to that of the available capacity in one of the locations shown. Refer to Illustration 1.
- ⊙ Result: The platform overload indicator lights should be off at both the ground and platform controls and the alarm should not sound.
 - ✗ Result: The platform overload indicator lights are on and the alarm is sounding. Calibrate the platform overload system. Refer to Repair Procedure 2-3, *How to Calibrate the Platform Overload System (if equipped), S-60, S-65, S-60 TRAX and S-65 TRAX.*
- 5 Carefully move the test weight to each remaining location. Refer to Illustration 1.
- ⊙ Result: The platform overload indicator lights should be off at both the ground and platform controls and the alarm should not sound.
 - ✗ Result: The platform overload indicator lights are on and the alarm is sounding. Calibrate the platform overload system. Refer to Repair Procedure 2-3, *How to Calibrate the Platform Overload System (if equipped), S-60, S-65, S-60 TRAX and S-65 TRAX.*
- 6 Using a suitable lifting device, place an additional 50 lbs / 23 kg of weight onto the platform.
- ⊙ Result: The alarm should sound. The platform overload indicator lights should be flashing at both the ground and platform controls.
 - ✗ Result: The alarm does not sound and the platform overload indicator lights are not flashing. Calibrate the platform overload system. Refer to Repair Procedure 2-3, *How to Calibrate the Platform Overload System (if equipped), S-60, S-65, S-60 TRAX and S-65 TRAX.*

Note: There may be a 2 second delay before the overload indicator lights flash and the alarm sounds.

- 7 Carefully move the test weights to each remaining location on the platform. Refer to Illustration 1.
- ⊙ Result: The alarm should sound. The platform overload indicator lights should be flashing at both the ground and platform controls.
 - ✗ Result: The alarm does not sound and the platform overload indicator lights are not flashing. Calibrate the platform overload system. Refer to Repair Procedure 2-3, *How to Calibrate the Platform Overload System (if equipped), S-60, S-65, S-60 TRAX and S-65 TRAX.*

Note: There may be a 2 second delay before the overload indicator lights flash and the alarm sounds.




Illustration 1

CHECKLIST C PROCEDURES

8 Test all machine functions from the platform controls.

⊙ Result: All platform control functions should not operate.

9 Turn the key switch to ground control.

10 Test all machine functions from the ground controls.

⊙ Result: All ground control functions should not operate.

11 Activate the auxiliary power toggle switch.

Note: The engine will turn off when the auxiliary power is activated.

12 Using auxiliary power, test all machine functions from the ground controls.

⊙ Result: All ground control functions should operate.

13 Using a suitable lifting device, lift the additional test weight from the platform.

⊙ Result: The platform overload indicator lights should turn off at both the ground and platform controls and the alarm should not sound.

Note: There may be a 2 second delay before the overload indicator lights and alarm turn off.

14 Start the engine and test all machine functions from the ground controls.

⊙ Result: All ground control functions should operate normally.

15 Turn the key switch to platform control.

16 Test all machine functions from the platform controls.

⊙ Result: All platform control functions should operate.

Note: If the platform overload system is not operating properly, Refer to Repair Procedure 2-3, *How to Calibrate the Platform Overload System (if equipped)*, S-60, S-65, S-60 TRAX and S-65 TRAX.

17 Using a suitable lifting device, remove the remaining test weights from the platform.

CHECKLIST C PROCEDURES

C-4 Test the Platform Load Sense System, S-60 HC



Genie specifications require that this procedure be performed every 500 hours or six months, whichever comes first.

Testing the platform overload system regularly is essential to safe machine operation. Continued use of an improperly operating platform overload system could result in the system not sensing an overloaded platform condition. Machine stability could be compromised resulting in the machine tipping over.

The platform overload system is designed to detect an overloaded platform and prevent machine operation anytime the machine is turned on. When activated, the system halts all normal boom operation, giving visual and audible warning to the operator.

Models equipped with the platform overload option are provided with additional machine components: an adjustable spring-loaded platform support subassembly, a limit switch, an electronic module which receives the overload signal and interrupts power, and an audio/visual warning indication to alert the operator of the overload.

The platform support subassembly utilizes two load support arms that are opposed in a full parallelogram link. This isolates platform loads into a shear or vertical state, which translates into a compressive load. A spring in the parallelogram link supports this purely compressive load regardless of where the load is placed in the platform.

As weight is added to the platform, the spring will compress until, when the platform is overloaded, the lower arm contacts a limit switch and thereby activating the overload signal. When adjusted correctly, the platform overload system will deactivate normal boom operation at platform capacity.

Note: Perform this procedure with the boom fully retracted and in the stowed position and with the machine on a firm, level surface.

Note: Be sure that no load sense system faults exist prior to performing this procedure.

Note: On a properly functioning machine, the LEDs on both control modules, located next to the ground control box, should be off.

Note: If your machine is equipped with any platform accessories or options, they must be removed from the platform OR the weights of those options or accessories must be subtracted from the test weights to accurately calibrate the platform load sense system.

- 1 Remove all weight, tools and equipment from the platform.

Note: Failure to remove all weight, tools and accessories from the platform will result in an inaccurate test.

CHECKLIST C PROCEDURES

- 2 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 3 Start the engine from the ground controls. Do not turn the engine off.
- 4 Using a suitable lifting device, place an appropriate test weight equal to 750 lbs / 340.2 kg on to the center of the platform floor.

- ⦿ Result: The amber restricted range of motion LED at the platform controls should come on and the engine should continue to run.
- ✗ Result: If the amber restricted range of motion LED at the platform controls does not come on, there is no alarm and the engine continues to run, the platform load sense system needs to be calibrated. See Repair Procedure 2-4, *How to Calibrate the Platform Load Sense System, S-60 HC*.

- 5 Using a suitable lifting device, place an additional appropriate test weight equal to 501 to 510 lbs / 227.2 to 231.3 kg on to the center of the platform floor. The total weight in the platform must equal 1251 to 1260 lbs / 567.4 to 571.5 kg.
- ⦿ Result: The alarm should sound and the engine should turn off. The platform overload indicator light should be on at both the ground and platform controls. The platform load sense system is functioning properly.
 - ✗ Result: If the alarm does not sound, the engine does not turn off or the platform indicator light does not come on at both the ground and platform controls, see Repair Procedure 2-4, *How to Calibrate the Platform Load Sense System, S-60 HC*.

Note: The weight in the platform must be 1200 lbs / 544.3 kg or less before the engine can be restarted.

- 6 Using a suitable lifting device, remove the test weights from the platform.
- 7 Push in the ground controls red Emergency Stop button to the off position, then pull the red Emergency Stop button out to the on position to reset the control system.

Recovery process from the platform controls:

Note: This procedure only operates if the platform is overloaded or enters the safety envelope.

- 1 With the key switch turned to platform controls, activate the auxiliary power toggle switch.
- ⦿ Result: The boom will automatically retract until it is in the unrestricted zone.
- 2 Push in the platform controls red Emergency Stop button to the off position, then pull out the red Emergency Stop button to the on position to reset the system.
- 3 Start the engine and lower the boom to the stowed position.

Recovery process from the ground controls:

Note: This procedure only operates if the platform is overloaded or enters the safety envelope.

- 1 Turn the key switch to ground controls.
- 2 Locate the recovery toggle switch on the side of the ground control box. Activate the recovery toggle switch and the auxiliary power toggle switch at the same time.
- ⦿ Result: The boom will automatically fully retract and then lower to the stowed position.
- 3 Push in the ground controls red Emergency Stop button to the off position, then pull out the red Emergency Stop button to the on position to reset the system.

CHECKLIST C PROCEDURES

C-5 Replace the Fuel Filter/Water Separator - Perkins Models




Genie specifications require that this procedure be performed every 500 hours or six months, whichever comes first.

Regular replacement of the fuel filter/water separator is essential for good engine performance. Failure to perform this procedure can lead to poor engine performance and/or hard starting, and continued use may result in component damage. Extremely dirty conditions may require this procedure be performed more often.

⚠ DANGER Explosion and fire hazard. Engine fuels are combustible. Perform this procedure in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

Note: Perform this procedure with the engine off.

- 1 Open the engine side turntable cover and locate the fuel filter/water separator on the bulkhead.
- 2 Disconnect and plug the fuel supply hose from the fuel tank to the fuel filter/water separator.
- 3 Loosen the vent plug located on the fuel filter/water separator head.



- a vent plug
- b main fuel line
- c drain plug
- d filter bowl
- e filter element
- f separator head

- 4 Place a suitable container under the filter bowl. Loosen the drain plug located at the bottom of the bowl. Completely drain the fuel.
- 5 Rotate the filter bowl counterclockwise and remove it from the element.
- 6 Rotate the filter element counterclockwise and remove it from the filter head.
- 7 Install the bowl onto the new filter element.
- 8 Apply a thin layer of oil onto the element gasket. Install the filter/bowl assembly onto the filter head. Tighten the drain plug and vent plug.

CHECKLIST C PROCEDURES


- 9 Clean up any diesel fuel that may have spilled during the installation procedure.
- 10 Install the fuel supply hose from the fuel tank to the fuel filter/water separator. Tighten the clamp.
- 11 Use a permanent ink marker to write the date and number of hours from the hour meter on the oil filter housing.

Bleed the system:

- 12 Remove the engine tray retaining fastener located under the engine tray. Swing the engine tray out and away from the machine.
- 13 Install the fastener that was just removed through the engine tray and into the engine tray anchor hole in the turntable.

⚠ WARNING Crushing hazard. Failure to install the fastener into the engine tray anchor hole to secure the engine tray from moving could result in death or serious injury.

- 14 Loosen the vent plug on top of the fuel injection pump.



- a vent plug
- b fuel injection pump
- c fuel lift pump

- 15 Operate the priming lever or priming bulb (if equipped) of the fuel lift pump until fuel, free from air, comes from the vent plug. Tighten the vent plug.

- 16 Clean up any fuel that may have spilled during this procedure.

- 17 Operate the starter motor for intervals of 15 seconds until the engine starts.

Note: It is important to allow the starter motor to cool for 30 seconds between each 15 second interval of operation.

Note: If the engine runs correctly for a short time and then stops or runs roughly, check for air in the fuel system. If there is air in the fuel system, there is probably a leak in the low pressure side of the system.

- 18 Swing the engine back to its original position and install the engine pivot plate retaining fastener.

CHECKLIST C PROCEDURES

C-6 Replace the Engine Air Filter Element - Deutz and Perkins Models



Engine specifications require that this procedure be performed every 500 hours or every six months, whichever comes first.

Maintaining the engine air filter in good condition is essential to good engine performance and service life. Failure to perform this procedure can lead to poor engine performance and component damage.

Note: Perform this procedure with the engine off.

- 1 Locate the engine air filter assembly.
- 2 Release the latches from the air cleaner canister end cap. Remove the end cap.
- 3 Remove and discard the filter element.
- 4 Clean the inside of the canister and the end cap with a damp cloth.
- 5 Install the new filter element.
- 6 Install the air filter canister end cap and secure the end cap latches.

C-7 Check the Safety Envelope Limit Switches and Angle Sensor, S-60X and S-60XC



Genie specifications require that this procedure be performed every 500 hours or six months, whichever comes first.

Testing the safety envelope system regularly is essential to safe machine operation. Continued use of an improperly operating safety envelope could result in the system not restricting the range of motion. Machine stability could be compromised resulting in the machine tipping over.

Note: Perform this procedure with the machine on a firm, level surface with all weight, tools and equipment removed from the platform.


Note: Start this procedure with the boom fully retracted and in the stowed position.

Ground controls:

- 1 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position.
- 2 Start the engine from the ground controls.

CHECKLIST C PROCEDURES

- 3 Turn and hold the function enable switch to the restricted maximum platform capacity and raise the primary boom until it is fully elevated.



- a restricted maximum platform capacity
b unrestricted maximum platform capacity

- 4 Extend the primary boom until it is fully extended.
- 5 Lower the primary boom until it stops.
- ⊙ Result: The boom will automatically stop after 10 degrees.
- ⊗ Result: The primary boom does not stop after 10 degrees. Check limit switches LST30 and LST3S.
- 6 Turn the key switch to the off position and push in the red Emergency Stop button.

Note: The following step can be done using a measuring tape or a digital protractor (Genie part number 58377).


7 Measuring Tape:

Measure the distance between the center of the pivot pins as shown, 171 inches / 434 cm \pm 2.0 inch / 5 cm.

Digital Protractor:

Place the digital protractor on the turntable chassis and reset the protractor to 0°. Place the protractor on top of the primary boom. The protractor should display 58° \pm 2°.

- ⊗ Result: The primary boom angle is not within specifications. Consult Genie Industries Service Department.




CHECKLIST C PROCEDURES

Platform controls:

Note: Start this procedure with the boom fully retracted and in the stowed position.

- 1 Pull out the red Emergency Stop button to the on position and start the engine.
- 2 Select the restricted maximum platform capacity with the toggle switch.



- a restricted maximum platform capacity
b unrestricted maximum platform capacity

- 3 Raise the primary boom until it is fully elevated.
- 4 Extend the primary boom until it is fully extended.

- 5 Lower the primary boom until it stops.
 - ⊙ Result: The boom will automatically stop after 10 degrees and the unrestricted platform capacity light will flash.
 - ⊗ Result: The primary boom does not stop after 10 degrees. Calibrate the boom angle sensor. Refer to Repair Procedure 1-2, *How to Calibrate the Boom angle Sensor*.
- 6 Move the primary boom down joystick off center and retract the primary boom until the unrestricted platform capacity light stops flashing.
 - ⊙ Result: Primary boom down should return to normal operation.
- 7 Lower the primary boom 5 feet / 1.5 m and activate primary boom extend.
 - ⊙ Result: Primary boom extend will stop and the unrestricted platform capacity light will start flashing.
- 8 Activate primary boom extend and raise the primary boom until the unrestricted platform capacity light stops flashing.
 - ⊙ Result: Primary boom extend should return to normal operation.
- 9 Return the machine to the fully stowed position.

CHECKLIST C PROCEDURES

C-8 Perform Engine Maintenance - Perkins Models



Engine specifications require that this procedure be performed every 600 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Perkins 400 Series Operation Manual* (Perkins part number TPD 1443S).

Perkins 400 Series Operation Manual	
Genie part number	94890

C-9 Perform Engine Maintenance - Ford Models



Engine specifications require that this procedure be performed every 800 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Ford DSG-423 EFI Operator Handbook* (EDI part number 1060020) OR the *Ford MSG-425 EFI Operator Handbook* (EDI part number 1020010).

Ford DSG 423 EFI Operator Handbook	
Genie part number	119488

Ford MSG 425 EFI Operator Handbook	
Genie part number	215322

Checklist D Procedures

D-1

Check the Boom Wear Pads



Genie specifications require that this procedure be performed every 1000 hours or annually, whichever comes first.

Maintaining the boom wear pads in good condition is essential to safe machine operation. Wear pads are placed on boom tube surfaces to provide a low friction, replaceable wear pad between moving parts. Improperly shimmed wear pads or continued use of worn out wear pads may result in component damage and unsafe operating conditions.

- 1 Start the engine from the ground controls.
- 2 Raise the end of the primary boom to a comfortable working height (chest high), then extend the boom 1 foot / 30 cm.
- 3 Measure each wear pad. Replace the wear pad once it reaches the minimum allowable thickness. If the wear pad is still within specification, shim as necessary to obtain minimum clearance with zero binding.

- 4 Extend and retract the primary boom through the entire range of motion to check for tight spots that may cause binding or scraping of the boom.

Note: Always maintain squareness between the outer and inner boom tubes.

Wear pad specifications	Minimum
Top and side wear pads (platform end of boom)	1/2 inch 12.7 mm
Bottom wear pads (platform end of boom)	5/8 inch 15.9 mm
Top and side wear pads (pivot end of boom)	1/2 inch 12.7 mm
Bottom wear pads (pivot end of boom)	5/8 inch 15.9 mm

CHECKLIST D PROCEDURES

D-2 Check the Turntable Rotation Bearing Bolts



Genie specifications require that this procedure be performed every 1000 hours or annually, whichever comes first.

Maintaining proper torque on the turntable bearing bolts is essential to safe machine operation. Improper bolt torque could result in an unsafe operating condition and component damage.


- 1 Raise the boom and place a safety chock on the lift cylinder rod. Carefully lower the boom onto the lift cylinder safety chock.

WARNING Crushing hazard. Keep hands away from cylinders and all moving parts when lowering the boom.


Note: The lift cylinder safety chock is available through Genie (Genie part number 75097).

- 2 Turn the engine off.
- 3 Be sure that each turntable mounting bolt is torqued in sequence to specifications. Refer to Section 2, *Specifications*.

- 4 Start the engine from the ground controls.
- 5 Raise the boom and remove the safety chock.
- 6 Lower the boom to the stowed position.
- 7 Remove drive chassis covers from both the steer end and the non-steer end of the machine.
- 8 Check to ensure that each lower bearing mounting bolt under the drive chassis is torqued in sequence to specifications. Refer to Section 2, *Specifications*.



Bolt torque sequence



Bolt torque sequence



CHECKLIST D PROCEDURES

D-3 Inspect for Turntable Bearing Wear



Genie specifications require that this procedure be performed every 1000 hours or annually, whichever comes first.


Periodic inspection of turntable bearing wear is essential to safe machine operation, good machine performance and service life. Continued use of a worn turntable bearing could create an unsafe operating condition, resulting in death or serious injury and component damage.

Note: Perform this procedure with the machine on a firm, level surface and the boom in the stowed position.

- 1 Grease the turntable bearing. See A-13, *Grease the Turntable Bearing and Rotate Gear*.
- 2 Torque the turntable bearing bolts to specification. See D-2, *Check the Turntable Rotation Bearing Bolts*.
- 3 Start the machine from the ground controls and raise the boom to full height. Do not extend the boom.

- 4 Place a dial indicator between the drive chassis and the turntable at a point that is directly under, or inline with, the boom and no more than 1 inch / 2.5 cm from the bearing.

Note: To obtain an accurate measurement, place the dial indicator no more than 1 inch / 2.5 cm from the turntable rotation bearing.



- a turntable
- b dial indicator
- c drive chassis
- d turntable rotation bearing

- 5 At the dial indicator, adjust it to "zero" the indicator.
 - 6 Fully extend the boom and lower to a horizontal position.
 - 7 Note the reading on the dial indicator.
- ⊙ Result: The measurement is less than 0.063 inch / 1.6 mm. The bearing is good.
- ⊗ Result: The measurement is more than 0.063 inch / 1.6 mm. The bearing is worn and needs to be replaced.

CHECKLIST D PROCEDURES

- 8 Fully retract the boom and raise the boom to full height. Visually inspect the dial indicator to be sure the needle returns to the "zero" position.
- 9 Remove the dial indicator and rotate the turntable 90°.
- 10 Repeat steps 4 through 9 until the rotation bearing has been checked in at least four equally spaced areas 90° apart.
- 11 Lower the boom to the stowed position and turn the machine off.
- 12 Remove the dial indicator from the machine.

D-4 Replace the Drive Hub Oil




Genie specifications require that this procedure be performed every 1000 hours or annually, whichever comes first.

Replacing the drive hub oil is essential for good machine performance and service life. Failure to replace the drive hub oil at yearly intervals may cause the machine to perform poorly and continued use may cause component damage.

S-60, S-65, S-60 HC, S-60X and S-60XC:

- 1 Select the drive hub to be serviced. Drive the machine until one of the two plugs is at the lowest point.
- 2 Remove both plugs and drain the oil into a suitable container.
- 3 Drive the machine until both plugs are horizontal.




a drive hub plugs

- 4 Fill the hub until the oil level is even with the bottom of the plug hole. Refer to Section 2, *Specifications*.
- 5 Install the plugs into the drive hub.
- 6 Check the torque of the drive hub mounting bolts. Refer to Section 2, *Specifications*.
- 7 Repeat this procedure for each drive hub.

CHECKLIST D PROCEDURES

S-60 TRAX and S-65 TRAX:

- 1 Select the drive hub to be serviced. Loosen and remove as many sprocket retaining fasteners as possible from the hub adapter.
- 2 Drive the machine in either direction just enough to access the remaining fasteners. Do not remove the retaining fasteners.
- 3 Chock the tracks at the opposite end of the machine to prevent the machine from rolling.
- 4 Center a lifting jack of ample capacity (20,000 lbs / 10,000 kg) under the drive chassis between the tracks.
- 5 Lift the machine until the tracks are off the ground and then place jack stands under the drive chassis for support.
- 6 Attach a lifting strap from an overhead crane to the center-point of the track assembly, above the sprocket.
- 7 Remove the remaining sprocket retaining fasteners from the hub adapter.
- 8 Carefully remove the track assembly from the drive hub and set aside.
- 9 Locate the hub disconnect pin in the center of the drive hub. Manually depress the pin and rotate the drive hub until one of the two plugs is at the lowest point.



CAUTION Crushing hazard. The track assembly could become unbalanced and fall when removed from the machine if not properly supported by the overhead crane.

- 10 Remove both plugs and drain the oil into a suitable container.
- 11 Manually depress the hub disconnect pin and rotate the drive hub until both plugs are horizontal.
- 12 Fill the hub until the oil level is even with the bottom of the plug hole. Refer to Section 2, *Specifications*.
- 13 Install the plugs into the drive hub.
- 14 Check the torque of the drive hub mounting bolts. Refer to Section 2, *Specifications*.
- 15 Attach a lifting strap from an overhead crane to the center-point of the track assembly, above the sprocket.

CHECKLIST D PROCEDURES

- 16 Install the track assembly onto the drive hub adapter while guiding the hub adapter studs into the sprocket of the track assembly. Install as many sprocket retaining fasteners as possible to the hub adapter and torque to specification. Refer to Section 2, *Specifications*.
- 17 Raise the machine, remove the jack stands and lower the machine.
- 18 Drive the machine in either direction just until the remaining sprocket retaining fasteners can be installed onto the drive hub adapter. Turn the machine off.
- 19 Install the remaining sprocket retaining fasteners to the drive hub adapter and torque to specification. Refer to Section 2, *Specifications*.
- 20 Repeat this procedure for each drive hub.

D-5 Check the Free-wheel Configuration



Genie specifications require that this procedure be performed every 1000 hours or annually, whichever comes first.

Proper use of the free-wheel configuration is essential to safe machine operation. The free-wheel configuration is used primarily for towing. A machine configured to free-wheel without operator knowledge may cause death or serious injury and property damage.

⚠ WARNING Collision hazard. Select a work site that is firm and level.

NOTICE Component damage hazard. If the machine must be towed, do not exceed 2 mph / 3.2 km/h.

Non-steer end: All Models


- 1 Chock the steer wheels or tracks (if equipped) to prevent the machine from rolling.
- 2 Center a lifting jack of ample capacity (20,000 lbs / 10,000 kg) under the drive chassis between the non-steer tires or tracks.
- 3 Lift the wheels or tracks off the ground and then place jack stands under the drive chassis for support.

CHECKLIST D PROCEDURES

- Disengage the drive hubs by turning over the drive hub disconnect caps on each non-steer end drive hub.

Models with RT tires

Models with TRAX




a drive hub disconnect cap

- Manually rotate each non-steer wheel or track.
 - Result: Each non-steer wheel or track should rotate with minimum effort.

Note: S-60 TRAX and S-65 TRAX: Due to the additional components of the track system, which increase rotational friction, the track may not be able to be rotated manually.

- Re-engage the drive hubs by turning over the hub disconnect caps. Rotate each wheel or track to check for engagement. Lift the machine and remove the jack stands.

WARNING Collision hazard. Failure to re-engage the drive hubs could result in death or serious injury and property damage.




Steer end: 4WD Models

- Chock the non-steer wheels or tracks to prevent the machine from rolling.
- Center a lifting jack of ample capacity (20,000 lbs / 10,000 kg) under the drive chassis between the steer tires or tracks.
- Lift the wheels or tracks off the ground and then place jack stands under the drive chassis for support.
- Disengage the drive hubs by turning over the drive hub disconnect caps on each steer end drive hub.

Models with RT tires

Models with TRAX



a drive hub disconnect cap


- Manually rotate each steer wheel or track.
 - Result: Each steer wheel or track should rotate with minimum effort.

Note: S-60 TRAX and S-65 TRAX: Due to the additional components of the track system, which increase rotational friction, the track may not be able to be rotated manually.

CHECKLIST D PROCEDURES

12 Re-engage the drive hubs by turning over the hub disconnect caps. Rotate each wheel or track to check for engagement. Raise the machine, remove the jack stands and lower the machine.

⚠ WARNING Collision hazard. Failure to re-engage the drive hubs may cause death or serious injury and property damage.



D-6 Replace the Hydraulic Filters



Genie requires that this procedure be performed every 1000 hours or annually, whichever comes first. Perform this procedure more often if dusty conditions exist.

Replacement of the hydraulic filters is essential for good machine performance and service life. A dirty or clogged filter may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filters be replaced more often.

⚠ CAUTION Bodily injury hazard. Beware of hot oil. Contact with hot oil may cause severe burns.

Note: Perform this procedure with the engine off.

Hydraulic return filter:

- 1 Open the ground controls side turntable cover and locate the hydraulic return filter housing on top of the hydraulic tank.
- 2 Remove the cap from the filter housing.
- 3 Lift the handle on the filter element and rotate the element counterclockwise to release the element from the housing.
- 4 Remove the filter element from the filter housing.

CHECKLIST D PROCEDURES

- 5 Install the new filter element into the filter housing.
- 6 Push the filter element down to be sure the O-ring on the element is fully seated into the housing.
- 7 Rotate the filter element clockwise to lock it in place.
- 8 Install the filter housing cap.
- 9 Use a permanent ink marker to write the date and number of hours from the hour meter on the oil filter housing.

Medium and high pressure filters:

Note: The medium pressure filter is for the charge pump and the high pressure filter is for all machine functions except the drive circuit and oscillating axle circuit.

- 10 Open the engine side turntable cover and locate the medium and high pressure filters near the pump.

Note: The medium pressure filter is located on the right. The high pressure filter, with filter condition indicator, is located on the left.

- 11 Place a suitable container under each filter.
- 12 Remove the filter housings by using a wrench on the nut provided on the bottom of the housings.
- 13 Remove the filter elements from the housings.
- 14 Inspect the housing seals and replace them if necessary.

- 15 Install the new filter elements into the housings and tighten them securely.

Note: The medium and high pressure filters use the same elements.

- 16 Clean up any oil that may have spilled during the installation procedure.
- 17 Use a permanent ink marker to write the date and number of hours from the hour meter on the oil filter housings.
- 18 Start the engine from the ground controls.
- 19 Inspect the filter housings and related components to be sure that there are no leaks.

CHECKLIST D PROCEDURES

D-7 Perform Engine Maintenance - Deutz Models



Engine specifications require that this procedure be performed every 1000 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Deutz 2011 Series Operation Manual* (Deutz part number 0312-3547).

Deutz 2011 Series Operation Manual

Genie part number 139320



Checklist E Procedures

E-1

Test or Replace the Hydraulic Oil



Genie requires that this procedure be performed every 2000 hours or every two years, whichever comes first. Perform this procedure more often if dusty conditions exist.

Replacement or testing of the hydraulic oil is essential for good machine performance and service life. Dirty oil and suction strainers may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require oil changes to be performed more often.

Note: Before replacing the hydraulic oil, the oil may be tested by an oil distributor for specific levels of contamination to verify that changing the oil is necessary. **If the hydraulic oil is not replaced at the two year inspection, test the oil quarterly. Replace the oil when it fails the test.**


Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

Note: Perform this procedure with the boom in the stowed position.

- 1 **Ford models:** Turn the valve on the LPG tank clockwise to the off position (if equipped). Then slowly disconnect the hose from the LPG tank.
- 2 **Ford models:** Open the clamps from the LPG tank straps and remove the LPG tank from the machine (if equipped).
- 3 Open the ground controls side turntable cover and locate the two hydraulic tank valves at the hydraulic tank. Close the valves.

NOTICE

Component damage hazard. The engine must not be started with the hydraulic tank shut-off valves in the closed position or component damage will occur. If the tank valves are closed, remove the key from the key switch and tag the machine to inform personnel of the condition.



- 4 Place a suitable container underneath the hydraulic tank.
- 5 Remove the drain plug from the hydraulic tank.
- 6 Completely drain the tank into a suitable container. See capacity specifications.

CHECKLIST E PROCEDURES

- 7 Tag, disconnect and plug the two suction hoses and supply hose for the auxiliary pump from the hydraulic tank. Cap the fittings on the tank.

Note: The hoses can be accessed through the access hole under the turntable.

- 8 Disconnect and plug the return filter hydraulic hose at the return filter. Cap the fitting on the filter housing.
- 9 Remove the ground controls side turntable cover.
- 10 Support the hydraulic tank with an appropriate lifting device.
- 11 Remove the hydraulic tank mounting fasteners.
- 12 Remove the hydraulic tank from the machine.

⚠ WARNING Crushing hazard. The hydraulic tank could become unbalanced and fall if not properly supported when removed from the machine.

- 13 Remove the hydraulic return filter housing mounting fasteners. Remove the hydraulic return filter housing from the hydraulic tank.
- 14 Remove the suction strainers from the tank and clean them using a mild solvent.
- 15 Rinse out the inside of the tank using a mild solvent.
- 16 Install the suction strainers using a thread sealant on the threads.
- 17 Install the drain plug using a thread sealant on the threads.

- 18 Install the hydraulic return filter housing onto the hydraulic tank.

- 19 Install the hydraulic tank onto the machine.

- 20 Install the two suction hoses to the suction strainers.

- 21 Install the supply hose for the auxiliary power unit and the return filter hose.

- 22 Open the two hydraulic tank valves at the hydraulic tank.

- 23 Fill the tank with hydraulic oil until the level is within the top 2 inches / 5 cm of the sight gauge. Do not overfill.

- 24 Clean up any oil that may have spilled.

- 25 Prime the pump. Refer to Repair Procedure 6-2, *How to Prime the Pump*.

Note: Always use pipe thread sealant when installing the suction hose fittings and the drain plug.

CHECKLIST E PROCEDURES

E-2 Perform Engine Maintenance - Deutz Models



Engine specifications require that this procedure be performed every 3000 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Deutz 2011 Series Operation Manual* (Deutz part number 0312-3547).

Deutz 2011 Series Operation Manual	
Genie part number	139320

E-3 Perform Engine Maintenance - Deutz Models



Engine specifications require that this procedure be performed every 12,000 hours.

Proper engine maintenance, following the engine manufacturer's maintenance schedule, is essential to good engine performance and service life. Failure to perform the maintenance procedures can lead to poor engine performance and component damage.

Required maintenance procedures and additional engine information are available in the *Deutz 2011 Series Operation Manual* (Deutz part number 0312-3547).

Deutz 2011 Series Operation Manual	
Genie part number	139320


E-4 Replace the Boom Extend/ Retract Cables



Genie specifications require that this procedure be performed every 10 years.

The boom extend/retract cables are responsible for the extension and retraction of the number 3 boom tube. Replacement of the boom extend/retract cables is essential to good machine performance and safe machine operation. The boom extend/retract functions should operate smoothly and be free of hesitation, jerking and unusual noise.

- 1 Replace the boom extend/retract cables. See Repair Procedure 4-5, *Boom Extend/Retract Cables*.



This page intentionally left blank.

Repair Procedures



Observe and Obey:

- ☑ Repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Repairs Start:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate Operator's Manual on your machine.
- ☑ Be sure that all necessary tools and parts are available and ready for use.
- ☑ Use only Genie approved replacement parts.
- ☑ Read each procedure completely and adhere to the instructions. Attempting shortcuts may produce hazardous conditions.
- ☑ Unless otherwise specified, perform each repair procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Boom in stowed position
 - Turntable rotated with the boom between the non-steer wheels
 - Turntable secured with the turntable rotation lock
 - Key switch in the off position with the key removed
 - Wheels chocked
 - All external AC power disconnected from the machine

About This Section

Most of the procedures in this section should only be performed by a trained service professional in a suitably equipped workshop. Select the appropriate repair procedure after troubleshooting the problem.

Perform disassembly procedures to the point where repairs can be completed. To re-assemble, perform the disassembly steps in reverse order.

Symbols Legend



Safety alert symbol—used to alert personnel to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

▲ DANGER

Used to indicate the presence of an imminently hazardous situation which, if not avoided, will result in death or serious injury.

▲ WARNING

Used to indicate the presence of a potentially hazardous situation which, if not avoided, could result in death or serious injury.

▲ CAUTION

Used to indicate the presence of a potentially hazardous situation which, if not avoided, may cause minor or moderate injury.

NOTICE

Used to indicate the presence of a potentially hazardous situation which, if not avoided, may result in property damage.

⦿ Indicates that a specific result is expected after performing a series of steps.


⊗ Indicates that an incorrect result has occurred after performing a series of steps.



Platform Controls

The platform control box contains one printed circuit board. The ALC-500 circuit board inside the platform control box controls all proportional machine functions from the platform. The joystick controllers at the platform controls utilize Hall Effect technology and require no adjustment. The operating parameters of the joysticks are stored in memory at the ECM circuit board at the platform controls. If a joystick error occurs or if a joystick is replaced, it will need to be calibrated before that particular machine function will operate. See 1-2, *How to Calibrate a Joystick*.

Each joystick controller should operate smoothly and provide proportional speed control over its entire range of motion.



- a ALC-500 circuit board
- b drive/steer joystick controller
- c primary boom up/down, extend/retract and turntable rotate right/left joystick controller

1-1

ALC-500 Circuit Board

WARNING Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Note: When the ALC-500 circuit board is replaced, the joystick controllers will need to be calibrated. See 1-2, *How to Calibrate a Joystick*.

How to Remove the ALC-500 Circuit Board

- 1 Push in the red Emergency Stop button to the off position at both the ground and platform controls.
- 2 Remove the platform control box lid retaining fasteners. Open the control box lid.
- 3 Locate the ALC-500 circuit board mounted to the inside of the platform control box.

WARNING Electrocution/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

PLATFORM CONTROLS

- 4 Attach a grounded wrist strap to the ground screw inside the platform control box.

NOTICE

Component damage hazard. Electrostatic discharge (ESD) can damage printed circuit board components. Maintain firm contact with a metal part of the machine that is grounded at all times when handling printed circuit boards OR use a grounded wrist strap.

- 5 Carefully disconnect the wire connectors from the circuit board.
- 6 Remove the ALC-500 circuit board mounting fasteners.
- 7 Carefully remove the ALC-500 circuit board from the platform control box.

1-2 Joysticks

How to Calibrate a Joystick

The joysticks on this machine utilize digital Hall Effect technology for proportional control. If a joystick is disconnected or replaced, it must be calibrated before that particular machine function will operate.

Note: The joystick must be calibrated before the threshold, max-out or ramping can be set.

Note: Perform this procedure with the engine off.

- 1 Open the platform control box.
 - 2 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
 - 3 Turn the key switch to platform control. Do not start the engine.
 - 4 Select a joystick to calibrate.
 - 5 Disconnect the wire harness connector from the joystick for approximately 10 seconds or until the alarm sounds. Connect the wire harness connector to the joystick.
 - 6 Move the joystick full stroke in either direction and hold for 5 seconds.
 - 7 Return the joystick to the neutral position, pause for a moment, then move the joystick full stroke in the opposite direction. Hold for 5 seconds.
- ⊙ Result: The alarm should sound indicating successful joystick calibration.
 - ⊗ Result: The alarm does not sound. Check the electrical connections or replace the joystick.
- 8 Repeat this procedure for each joystick controlled machine function including the thumb rocker steer switch.

Note: No machine function should operate while performing the joystick calibration procedure.



PLATFORM CONTROLS

How to Adjust the Joystick Threshold Setting

The threshold setting of a joystick is the minimum output at which a function proportional valve can open and allow the function to operate.

Note: Perform this procedure on a firm, level surface.

- 1 Pull out the red Emergency Stop button to the on position at the ground controls.
- 2 Turn the key switch to platform control. Do not start the engine.
- 3 Push in the platform controls red Emergency Stop button to the off position.
- 4 Do not press down the foot switch.
- 5 Move and hold the drive enable toggle switch in the right position and pull out the red Emergency Stop button to the on position.
- 6 As soon as the alarm sounds, release the drive enable toggle switch.
- 7 Momentarily activate the drive enable toggle switch in the right direction 8 times.
- ⦿ Result: There should be a pause and the alarm should sound 8 times indicating that the machine is in threshold calibration mode.
- ✗ Result: The alarm does not sound. Repeat steps 3 through 7.
- 8 Start the engine from the platform controls and press down the foot switch.
- 9 Select a boom function joystick to set the threshold.
- 10 Slowly move the joystick off center in either direction just until the function begins to move.
- 11 Slowly move the joystick back to the neutral position. Just before the function stops moving, move the drive enable toggle switch to either side to set the threshold.
- 12 Repeat steps 9 through 11 for each boom joystick controlled machine function (boom up/down, boom extend/retract and turntable rotate).
- 13 Return the joystick to the neutral position and wait for approximately 10 seconds to allow the settings to be saved.
- ⦿ Result: The alarm should sound indicating that the settings have been saved in memory.

Note: Do not operate any machine function during the 10 second waiting time.

- 14 Cycle the red Emergency Stop button off, then back on.

PLATFORM CONTROLS

How to Adjust the Joystick Max-out Setting

The max-out setting of a joystick controls the maximum speed of a joystick-controlled machine function. Whenever a hydraulic cylinder, drive motor or hydraulic pump is replaced, the max-out setting should be adjusted to maintain optimum performance. The max-out settings on the joystick can be changed to compensate for hydraulic pump wear to maintain peak performance from the machine.

Note: Perform this procedure on a firm, level surface.

- 1 Pull out the red Emergency Stop button to the on position at the ground controls.
- 2 Turn the key switch to platform control. Do not start the engine.
- 3 Push in the platform controls red Emergency Stop button to the off position.
- 4 Do not press down the foot switch.
- 5 Move and hold the drive enable toggle switch in the right position and pull out the red Emergency Stop button to the on position.
- 6 When the alarm sounds, release the drive enable toggle switch.
- 7 Momentarily activate the drive enable toggle switch in the right direction 4 times.
- ⊙ Result: There should be a pause and the alarm should sound 4 times indicating that the machine is in max-out calibration mode.
- ⊗ Result: The alarm does not sound. Repeat steps 3 through 7.
- 8 Start the engine from the platform controls and press down the foot switch.
- 9 Start a timer and activate the machine function that needs to be adjusted. Record the time it takes for that function to complete a full cycle (ie; boom up).
- 10 Compare the machine function time with the function times listed in Section 2, *Specifications*. Determine whether the function time needs to increase or decrease.
- 11 While the joystick is activated, adjust the max-out setting to achieve the proper function cycle time. Momentarily move the drive enable toggle switch in the right direction to increase the function speed or momentarily move the drive enable toggle switch in the left direction to decrease the function speed.

Note: Each time the drive enable toggle switch is momentarily moved, the function speed will change in 2% increments from a default of 100%, with a minimum of 60% and a maximum of 120%.



PLATFORM CONTROLS

- 12 Repeat steps 9 through 11 for each joystick controlled machine function.
- 13 Return the joystick to the neutral position and wait for approximately 10 seconds to allow the settings to be saved.
- ⦿ Result: The alarm should sound indicating that the settings have been saved in memory.
 - ✗ Result: The alarm does not sound. The minimum or maximum adjustment has been obtained. No changes can be saved.

Note: Do not operate any machine function during the 10 second waiting time.

- 14 Cycle the red Emergency Stop button off, then back on.

How to Adjust the Joystick Ramp Rate Setting

The ramp rate setting of a joystick controls the time at which it takes for the joystick to reach maximum output, when moved out of the neutral position. The ramp rate settings of a joystick can be changed to compensate for hydraulic pump wear to maintain peak performance from the machine.

Note: Perform this procedure on a firm, level surface.

- 1 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
 - 2 Turn the key switch to platform control. Do not start the engine.
 - 3 Push in the platform controls red Emergency Stop button to the off position.
 - 4 Do not press down the foot switch.
 - 5 Move and hold the drive enable toggle switch in the right position and pull out the red Emergency Stop button to the on position.
 - 6 When the alarm sounds, release the drive enable toggle switch.
 - 7 Momentarily activate the drive enable toggle switch in the right direction 6 times.
- ⦿ Result: There should be a pause and the alarm should sound 6 times indicating that the machine is in ramp rate calibration mode.
 - ✗ Result: The alarm does not sound. Repeat steps 3 through 7.

PLATFORM CONTROLS

- 8 Start the engine from the platform controls and press down the foot switch.
- 9 Start a timer and simultaneously move the joystick in either direction full stroke. Note how long it takes the function to reach maximum speed. This is the ramp rate.
- 10 Compare the function ramp rate time with the table and determine whether the ramp rate time needs to increase or decrease.
- 11 Release the foot switch.
- 12 Activate the joystick and adjust the ramp rate. Momentarily move the drive enable toggle switch in the right direction to increase the time or momentarily move the drive enable toggle switch in the left direction to decrease the time.

Note: Each time the drive enable toggle switch is momentarily moved, the time will change in 5% increments from a default of 100%, with a minimum of 50% and a maximum of 150%.

- 13 Repeat steps 9 through 11 for each joystick controlled machine function.
 - 14 Return the joystick to the neutral position and wait for approximately 10 seconds to allow the settings to be saved.
- ⊙ Result: The alarm should sound indicating that the settings have been saved in memory.
 - ⊗ Result: The alarm does not sound. The minimum or maximum adjustment has been obtained. No changes can be saved.
- Note: Do not operate any machine function during the 10 second waiting time.
- 15 Cycle the red Emergency Stop button off, then back on.

Ramp rate (factory settings)

Boom up/down

transition accelerate	1 second
transition decelerate	10 seconds
S ramp accelerate	1 second
S ramp decelerate	0.45 second

Boom extend/retract

accelerate	2 seconds
decelerate	0.5 second

Turntable rotate

accelerate	2 seconds
decelerate	0.75 second

Drive

accelerate	2 seconds
decelerate to neutral	0.5 second
decelerate, change of direction	0.5 second
decelerate, coasting	0.75 second
decelerate, braking	1 second
decelerate, shift from low to high speed	1 second
decelerate, shift from high to low speed	4 seconds

PLATFORM CONTROLS

How to Calibrate the Boom Angle Sensor

The boom angle sensor controls the maximum angle that the boom can attain.

Note: Perform this procedure on a firm, level surface.

- 1 Pull out the red Emergency Stop button to the on position at the ground controls.
- 2 Turn the key switch to platform controls.
- 3 Move and hold the drive enable toggle switch to the right and pull out the red Emergency Stop button to the on position.
- 4 When the alarm sounds, release the drive enable toggle switch.
- 5 Momentarily activate the drive enable toggle switch to the right 12 times.
- ⊙ Result: There should be a pause and the alarm should sound 12 times indicating that the machine is in Angle Sensor calibration mode.
- 6 Start the engine from the platform controls and press down the foot switch.
- 7 Momentarily activate the drive enable toggle switch to the right 1 time to set the stowed position.
- 8 Raise the primary boom to the fully elevated position.
- Note: Manually reduce the boom speed as it reaches the fully elevated position.
- 9 Momentarily activate the drive enable toggle switch to the right 1 time to set the elevated position.
- ⊙ Result: The alarm will sound indicating that the angle sensor has been calibrated.
- 10 Release the joystick and the foot switch and wait for 10 seconds.
- ⊙ Result: The alarm will sound indicating that the settings have been saved and is leaving calibration mode.
- 11 Cycle the red Emergency Stop button off, then back on. Start the machine and return to the stowed position.

Note: The alarm will not sound indicating the setting.

Platform Components

2-1 Platform Leveling Slave Cylinder

The slave cylinder and the rotator pivot are the two primary supports for the platform. The slave cylinder keeps the platform level through the entire range of boom motion. It operates in a closed-circuit hydraulic loop with the master cylinder. The slave cylinder is equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure.

How to Remove the Platform Leveling Slave Cylinder

Note: Before cylinder removal is considered, bleed the slave cylinder to be sure there is no air in the closed loop.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Extend the boom until the slave cylinder barrel-end pivot pin is accessible.
- 2 Raise the boom slightly and place blocks under the platform for support.
- 3 Lower the boom until the platform is resting on the blocks just enough to support the platform.

Note: Do not rest the entire weight of the boom on the blocks.

- 4 Remove the pin retaining fastener from the slave cylinder rod-end pivot pin. Use a soft metal drift to drive the rod-end pivot pin out.

▲WARNING Crushing hazard. **S-65 and S-65 TRAX:** The jib boom could fall when the slave cylinder rod-end pivot pin is removed if not properly supported.

- 5 Remove the external snap rings from the barrel-end pivot pin.
- 6 Use a soft metal drift to drive the barrel-end pivot pin out.
- 7 Carefully pull the cylinder out of the boom to access the hydraulic hoses.
- 8 Tag, disconnect and plug the hydraulic hoses from the slave cylinder. Cap the fittings on the cylinder.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

How to Bleed the Slave Cylinder

Note: Do not start the engine. Use auxiliary power for this procedure.

- 1 Simultaneously activate the boom up function and the platform level up function until the boom is fully raised.
- 2 Simultaneously activate the boom down function and the platform level down function until the boom is fully lowered.

PLATFORM COMPONENTS

2-2 Platform Rotator

The platform rotator is a hydraulically activated helical gear assembly used to rotate the platform 160 degrees.

How to Remove the Platform Rotator

NOTICE Component damage hazard. Mark the platform mounting weldment and the rotator flange before removing the platform mounting weldment. The platform mounting weldment must be replaced in the exact same position on the rotator flange as it was before removal. If a new rotator is installed or the rotator is disassembled, proper alignment can be achieved by rotating the rotator all the way to the left and then installing the platform mounting weldment all the way in the left position.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Remove the platform and platform support.

Note: **S-60 HC:** If the load sense components are disassembled and/or removed from the platform support, the platform load sense system will need to be calibrated. See 2-4, *Platform Load Sense System, S-60 HC*.

- 2 **S-60 HC:** Tag and disconnect the electrical connector from the platform load sense module.
- 3 Tag, disconnect and plug the hydraulic hoses from the platform rotator manifold. Cap the fittings on the rotator.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 **S-65 and S-65 TRAX:** Support the jib boom leveling arms and the platform mounting weldment with an appropriate lifting device. Do not apply any lifting pressure.
- 5 Remove the mounting bolts from the platform mounting weldment. Remove the center bolt and slide the platform mounting weldment off of the platform rotator.

WARNING Crushing hazard. The platform mounting weldment could become unbalanced and fall if not properly supported when removed from the machine.

- 6 Support the platform rotator with an appropriate lifting device. Do not apply any lifting pressure.

S-60, S-60X, S-60XC and S-60 TRAX:

- 7 Support the rod end of the platform leveling slave cylinder. Protect the cylinder rod from damage.

PLATFORM COMPONENTS

- 8 Remove the pivot pin retaining fasteners from both the slave cylinder rod-end pivot pin and the rotator pivot pin.
- 9 Use a soft metal drift to remove both pivot pins. Remove the platform rotator from the machine.

CAUTION Crushing hazard. The platform rotator may become unbalanced and fall if not properly supported.

Note: When installing the platform rotator fasteners, torque the fasteners to specifications.

- 10 Lower the jib boom leveling arms.

CAUTION Crushing hazard. The platform rotator may become unbalanced and fall if not properly supported.

Note: When installing the platform rotator fasteners, torque the fasteners to specifications.

S-65 and S-65 TRAX:

- 7 Remove the pin retaining fasteners from the jib boom and jib boom leveling arms to platform rotator pivot pins. Do not remove the pins.
- 8 Support the jib boom leveling arms.
- 9 Use a soft metal drift to drive both pins out, then remove the platform rotator from the machine.

CAUTION Bodily injury hazard. The jib boom leveling arms may fall if not properly supported.

- 10 Lower the jib boom leveling arms.

CAUTION Crushing hazard. The platform rotator may become unbalanced and fall if not properly supported.

Note: When installing the platform rotator fasteners, torque the fasteners to specifications.

How to Bleed the Platform Rotator

Note: This procedure will require two people. Do not start the engine. Use auxiliary power for this procedure.

- 1 Move the function enable toggle switch to either side and activate the platform rotate toggle switch to the right then the left through two platform rotation cycles, then hold the switch to the right position until the platform is fully rotated to the right.
- 2 Place a suitable container underneath the platform rotator.
- 3 Open the top bleed screw on the rotator, but do not remove it.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Move the function enable toggle switch to either side and hold the platform rotate toggle switch to the left position until the platform is fully rotated to the left. Continue holding the toggle switch until air stops coming out of the bleed screw. Close the bleed screw.

WARNING Crushing hazard. Keep clear of the platform during rotation.

 PLATFORM COMPONENTS

- 5 Open the bottom bleed screw on the rotator, but do not remove it.

⚠WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 6 Move the function enable toggle switch to either side and hold the platform rotate toggle switch to the right position until the platform is fully rotated to the right. Continue holding the toggle switch until air stops coming out of the bleed screw. Close the bleed screw.

⚠WARNING Crushing hazard. Keep clear of the platform during rotation.

- 7 Clean up any hydraulic oil that may have spilled.
- 8 Rotate the platform fully in both directions and inspect the bleed screws for leaks.

2-3

Platform Overload System, S-60, S-65, S-60 TRAX and S-65 TRAX (if equipped)

How to Calibrate the Platform Overload System

Calibration of the platform overload system is essential to safe machine operation. Continued use of an improperly calibrated platform overload system could result in the system failing to sense an overloaded platform. The stability of the machine is compromised and it could tip over.

Note: For S-60 HC models, refer to Repair Procedure 2-4, *Platform Load Sense System, S-60 HC*.

Note: Perform this procedure with the machine on a firm, level surface.

- 1 Turn the key switch to platform control. Start the engine and level the platform.
- 2 Determine the maximum platform capacity. Refer to the machine serial plate.
- 3 Remove all weight, tools and accessories from the platform.

Note: Failure to remove all weight, tools and accessories from the platform will result in an incorrect calibration.

- 4 Using a suitable lifting device, place a test weight equal to the maximum platform capacity at the center of the platform floor.

PLATFORM COMPONENTS

5 Move the platform up and down by hand, so it bounces approximately 2.5 to 5 cm / 1 to 2 inches. Allow the platform to settle.

⦿ Result: The overload indicator lights are off and the alarm does not sound. Proceed to step 6.

✘ Result: The overload indicator lights are flashing at the platform and ground controls, and the alarm is sounding. Slowly tighten the load spring adjustment nut in a clockwise direction in 10° increments until the overload indicator light turns off, and the alarm does not sound. Proceed to step 8.

Note: The platform will need to be moved up and down and allowed to settle between each adjustment.

Note: There may be a 2 second delay before the platform overload indicator light and alarm responds.

6 Move the platform up and down by hand, so it bounces approximately 2.5 to 5 cm / 1 to 2 inches. Allow the platform to settle.

⦿ Result: The overload indicator lights are off at the platform and ground controls, and the alarm does not sound. Slowly loosen the load spring adjustment nut in a counterclockwise direction in 10° increments until the overload indicator light flashes at both the platform and ground controls, and the alarm sounds. Proceed to step 7.

✘ Result: The overload indicator lights are flashing at the platform and ground controls, and the alarm is sounding. Repeat this procedure beginning with step 5.

Note: The platform will need to be moved up and down and allowed to settle between each adjustment.

Note: There may be a 2 second delay before the platform overload indicator lights and alarm responds.

7 Move the platform up and down by hand, so it bounces approximately 2.5 to 5 cm / 1 to 2 inches. Allow the platform to settle.

⦿ Result: The overload indicator lights are off and the alarm does not sound. Proceed to step 8.

✘ Result: The overload indicator lights are flashing at the platform and ground controls, and the alarm is sounding. Repeat this procedure beginning with step 5.

Note: There may be a 2 second delay before the platform overload indicator light and alarm responds.

8 Add an additional 10 lb / 4.5 kg test weight to the platform.

⦿ Result: The overload indicator light is flashing at both the ground and platform controls, and the alarm is sounding. Proceed to step 9.

✘ Result: The overload indicator light is off at both the ground and platform controls, and the alarm does not sound. Remove the additional 10 lb / 4.5 kg test weight. Repeat this procedure beginning with step 6.

Note: There may be a 2 second delay before the platform overload indicator light and alarm responds.

9 Test all machine functions from the platform controls.

⦿ Result: All platform control functions should not operate.

10 Turn the key switch to ground control.

 PLATFORM COMPONENTS

11 Test all machine functions from the ground controls.

- ⦿ Result: All ground control functions should not operate.

12 Using a suitable lifting device, lift the test weight off the platform floor.

- ⦿ Result: The platform overload indicator light should be off at both the ground and platform controls and the alarm should not sound.

Note: There may be a 2 second delay before the overload indicator lights and alarm turn off.

13 Test all machine functions from the ground controls.

- ⦿ Result: All ground control functions should operate normally.

14 Turn the key switch to platform control.

15 Test all machine functions from the platform controls.

- ⦿ Result: All platform control functions should operate normally.

2-4

Platform Load Sense System, S-60 HC

How to Calibrate the Platform Load Sense System

Proper calibration of the load sense system is essential to safe machine operation. Continued use of an improperly calibrated load sense system could result in the system failing to sense an overloaded platform. The stability of the machine is compromised and it could tip over.

Note: For S-60, S-65, S-60 TRAX and S-65 TRAX models, refer to Repair Procedure 2-3, *Platform Overload System, S-60, S-65, S-60 TRAX and S-65 TRAX (if equipped)*.

Note: Perform this procedure with the boom fully retracted and in the stowed position and with the machine on a firm, level surface.

Note: The platform overload system will not allow partial calibration and must be completed in its entirety.

- 1 At the ground controls, turn the key switch to the off position and push in the red Emergency Stop button to the off position. Pull out the red Emergency Stop button to the on position at the platform controls.

PLATFORM COMPONENTS

- 2 Remove all weight, tools and equipment from the platform.

⚠ DANGER Tip-over hazard. Failure to remove all weight, options, accessories and/or tools from the platform or subtracting the weight of those items from the test weights, will result in the platform load sense system not calibrating correctly. This will allow too much weight to be added to the platform which will result in the machine tipping over.

- 3 Open the ground control box and locate the calibration toggle switch near the relays.

Note: If either the operational and/or safety controller has been replaced or if the software has been updated, restore the system to the default settings and then continue to step 4. See *How to Restore the Default Settings*. Otherwise, continue to step 4 to enter calibration mode.

- 4 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position.

- ⦿ Result: The alarm sound for approximately 2 seconds.


How to Restore the System Default Settings

- 1 Turn the key switch to ground control and pull out the red Emergency Stop button to the on position.
 - ⦿ Result: The alarm should sound a long tone.
- 2 Activate and hold the calibration toggle switch for 5 seconds.
 - ⦿ Result: The alarm should sound a tone for 1 second.
- 3 Push in the red Emergency Stop button to the off position.

- 5 Activate and release the calibration toggle switch 3 times within 2 seconds after the alarm sounds to enter calibration mode.

- ⦿ Result: The alarm should sound for 1 second indicating the first calibration step was accepted. The green LED on the operational controller should be blinking fast and the red LED should be blinking twice indicating that step 2 of calibration is next.
- ✗ Result: The alarm did not sound and the green LED on the operational controller is not blinking fast. Repeat this procedure beginning with step 1.

Note: Once calibration mode is entered and begun, there is a 8 minute time limit between each calibration step. If any one step passes the 8 minute time limit, the system will time out and the calibration process will need to be repeated beginning with step 1.




- a green LED (operational control module)
- b red LED (operational control module)
- c operational control module
- d safety control module
- e red LED (safety control module)
- f green LED (safety control module)



PLATFORM COMPONENTS

- 6 Start the engine from the ground controls.
- 7 Raise the boom until the distance, when measured between the centers of the pivot pins shown, equals 108.75 inches / 276 cm \pm 0.75 inch / 19 mm.

WARNING Crushing hazard. Keep clear of all moving parts of the boom while the boom is raising. Do not attempt to measure between the pivot pins while the boom is moving.



- 8 Activate the calibration toggle switch inside the ground control box 1 time.

⦿ Result: The alarm should sound for 1 second indicating the second calibration step was accepted. The green LED on the operational controller should be blinking fast and the red LED should be blinking three times indicating that step 3 of calibration is next.

- 9 Raise the boom until the distance, when measured between the centers of the pivot pins shown, equals 167.25 inches / 424.8 cm \pm 0.75 inch / 19 mm.

WARNING Crushing hazard. Keep clear of all moving parts of the boom while the boom is raising. Do not attempt to measure between the pivot pins while the boom is moving.

- 10 Activate and release the calibration toggle switch inside the ground control box 1 time.

⦿ Result: The alarm should sound for 1 second indicating the third calibration step was accepted. The green LED on the operational controller should be blinking fast and the red LED should be blinking four times indicating that step 4 of calibration is next.

- 11 Fully raise and extend the boom.

Operational Control Module LED Status

Description	Definition
Green AND Red LED's not flashing	System calibrated
Green LED flashing rapidly	System in calibration mode
Red LED flashing with pauses	Indicates next calibration step (ie; 2, 3, etc.)

Safety Control Module LED Status

Description	Definition
Green AND Red LED's not flashing	System calibrated
Green AND Red LED's flashing alternately	System not calibrated

PLATFORM COMPONENTS

12 Activate and release the calibration toggle switch inside the ground control box 1 time.

- ⊙ Result: The alarm should sound for 1 second indicating the fourth calibration step was accepted. The green LED on the operational controller should be blinking fast and the red LED should be blinking five times indicating that step 5 of calibration is next.

13 Fully retract and lower the boom to the stowed position.

14 Using a suitable lifting device, place an appropriate test weight equal to 750 lbs / 340.2 kg on to the center of the platform floor.

Note: If your machine is equipped with any platform accessories or options, they must be removed from the platform OR the weights of those options or accessories must be subtracted from the test weights to accurately calibrate the platform load sense system.

15 Activate and release the calibration toggle switch inside the ground control box 1 time.

- ⊙ Result: The alarm should sound for 1 second indicating the fifth calibration step was accepted. The green LED on the operational controller should be blinking fast and the red LED should be blinking six times indicating that step 6 of calibration is next.

16 Using a suitable lifting device, place an additional test weight equal to 510 lbs / 231.3 kg on to the center of the platform floor. The total weight in the platform must equal 1260 lbs / 571.5 kg.

17 Activate and release the calibration toggle switch inside the ground control box 1 time.

- ⊙ Result: The alarm should sound for 1 second indicating the sixth calibration step was accepted. The engine may turn off and the alarm may sound indicating an overloaded platform.

18 At the ground controls, push in the red Emergency Stop button to the off position, then pull out the red Emergency Stop button to the on position to reset the system.

19 Visually inspect the LEDs on the controllers.

- ⊙ Result: All LEDs on both controllers should be off indicating the platform load sense system is calibrated.

20 At the ground controls, push in the red Emergency Stop button to the off position.

21 Using a suitable lifting device, remove the test weights from the platform.

22 Pull out the red Emergency Stop button to the on position at the ground controls and visually inspect the LEDs on the operational and safety controllers.

- ⊙ Result: Both the green and red LEDs on both controllers should be off indicating the system is calibrated.

Note: If an LED is blinking on either controller, the load sense system is not calibrated correctly or a fault may exist. Refer to Section 5, *Fault Codes* to determine the system fault.

Jib Boom Components, S-65 and S-65 TRAX

3-1

Jib Boom

How to Remove the Jib Boom

Note: Perform this procedure with the boom in the stowed position.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Remove the platform.
- 2 Remove the platform mounting weldment.
- 3 Remove the hose and cable cover from the side of the jib boom.
- 4 Remove the hose and cable clamp from the jib boom pivot pin. Lay all hoses and cables to the side.

NOTICE Component damage hazard. Hoses and cables can become damaged if they are kinked or pinched.

- 5 Tag, disconnect and plug the jib boom lift cylinder hydraulic hoses. Cap the fittings on the cylinder.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 6 Attach a lifting strap from an overhead crane to the jib boom assembly.
- 7 Place blocks under the platform leveling cylinder for support. Protect the cylinder rod from damage.
- 8 Remove the pin retaining fastener from the slave cylinder rod-end pivot pin. Use a soft metal drift to remove the pin.

WARNING Crushing hazard. The jib boom could fall when the slave cylinder rod-end pivot pin is removed if not properly attached to the overhead crane.

- 9 Remove the pin retaining fastener from the jib boom bellcrank to primary boom pivot pin.
- 10 Use a soft metal drift to remove the pin and carefully remove the jib boom assembly from the primary boom.

WARNING Crushing hazard. The jib boom could become unbalanced and fall when removed from the machine if not properly attached to the overhead crane.

JIB BOOM COMPONENTS, S-65 AND S-65 TRAX

3-2 Jib Boom Lift Cylinder

How to Remove the Jib Boom Lift Cylinder

Note: Perform this procedure with the boom in the stowed position.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Raise the jib boom slightly and place blocks under the platform mounting weldment. Then lower the jib boom until the platform is resting on the blocks just enough to support the platform.

Note: Do not rest the entire weight of the boom on the blocks.

- 2 Tag, disconnect and plug the jib boom lift cylinder hydraulic hoses. Cap the fittings on the cylinder.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Remove the pin retaining fasteners from the jib boom lift cylinder rod-end pivot pin. Do not remove the pin.
- 4 Use a soft metal drift to tap the jib boom lift cylinder rod-end pivot pin half way out. Then lower one of the leveling arms to the ground. Tap the pin the other direction and lower the opposite leveling arm. Do not remove the pin.
- 5 Support the jib boom lift cylinder with a lifting device.
- 6 Remove the pin retaining fastener from the jib boom lift cylinder barrel-end pivot pin. Use a soft metal drift to remove the barrel-end pin and let the cylinder hang down.

▲WARNING Crushing hazard. The platform and jib boom could become unbalanced and fall when the jib boom barrel-end pivot pin is removed if not properly supported.

- 7 Attach a lifting strap from an overhead crane to the lug on the rod end of the jib boom lift cylinder.
- 8 Use a soft metal drift to remove the jib boom lift cylinder rod-end pin. Remove the cylinder from the machine.

▲WARNING Crushing hazard. The jib boom lift cylinder could become unbalanced and fall when removed from the machine if not properly attached to the overhead crane.

Boom Components

4-1 Cable Track

The primary boom cable track guides the cables and hoses running up the boom. It can be repaired link by link without removing the cables and hoses that run through it. Removing the entire primary boom cable track is only necessary when performing major repairs that involve removing the primary boom.

How to Remove the Cable Track, S-60, S-60X, S-60XC, S-60 HC and S-60 TRAX

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Raise the boom to a horizontal position.
 - 2 Locate the cables from the boom cable track to the platform control box. Number each cable and its entry location at the platform control box.
 - 3 Disconnect the cables from the platform control box.
 - 4 Remove the electrical outlet box bracket mounting fasteners. Remove the outlet box and lay it to the side.
 - 5 Remove the hose and cable clamp from the platform support.
 - 6 Tag, disconnect and plug the hydraulic hoses from the counterbalance valve manifold located on the platform rotator. Cap the fittings on the manifold.
- ▲WARNING** Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.
- 7 Tag, disconnect and plug the platform leveling slave cylinder hydraulic hoses from the bulkhead fittings on the side of the primary boom. Cap the bulkhead fittings.
- ▲WARNING** Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.
- 8 Locate all electrical cables under the boom at the pivot end that enter the cable track.
 - 9 Tag and disconnect the electrical connectors for all cables that enter the cable track.
 - 10 Remove the retaining fasteners from the electrical connector receptacles for the cables that enter the cable track.

BOOM COMPONENTS

- 11 Carefully pull the cables and connector receptacles out of the primary boom.
- 12 Tag, disconnect and plug all hydraulic hoses that enter the cable track from the bulkhead fittings at the pivot end of the boom.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 13 Pull the hydraulic hoses out of the primary boom.
- 14 Place blocks in between the upper and lower cable tracks and secure the upper and lower tracks together.

▲WARNING Crushing hazard. If the upper and lower cable tracks are not properly secured together, the cable track could become unbalanced and fall when removed from the machine.

- 15 Attach a strap from an overhead crane to the cable track.
 - 16 Remove the cotter pin from the cable track pull tube at the platform end of the boom.
- Note: Always replace the cotter pin with a new one.
- 17 Remove the cable track pull tube guide fasteners from the cable track guide at the platform end of the boom. Remove the cable track guide from the boom.

- 18 Remove the cable track mounting fasteners that attach the lower cable track to the primary boom.

- 19 Carefully remove the cable track from the machine and place it on a structure capable of supporting it.

▲WARNING Crushing hazard. The cable track could become unbalanced and fall if not properly attached to the overhead crane.

NOTICE Component damage hazard. Cables and hoses can be damaged if they are kinked or pinched.

NOTICE Component damage hazard. The cable track can be damaged if it is twisted.

How to Remove the Cable Track, S-65 and S-65 TRAX

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Open the platform control box.
- 2 Tag and disconnect the foot switch wiring from the terminal strip inside the platform control box. Pull the wiring out of the platform control box.
- 3 Raise the boom to a horizontal position.

BOOM COMPONENTS

- 4 Disconnect the wire connectors from the bottom of the platform control box.

Note: When installing the wire connectors to the bottom of the platform control box, match the color of the connectors to those on the control box to be sure they are installed in the correct location.

- 5 Remove the mounting fasteners from the power to platform outlet box bracket. Lay the outlet box and bracket assembly off to the side.
- 6 Remove the hose and cable clamps from the platform support and jib boom.
- 7 Tag, disconnect and plug the platform leveling slave cylinder hydraulic hoses from the bulkhead fittings on the side of the primary boom. Cap the bulkhead fittings.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 8 Tag, disconnect and plug the hydraulic hoses from the "V1" and "V2" ports of the jib boom/platform rotate manifold. Cap the fittings on the manifold.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 9 Remove the hose and cable cover from the side of the jib boom.

- 10 Locate all electrical cables under the boom at the pivot end that enter the cable track.

- 11 Tag and disconnect the electrical connectors for all cables that enter the cable track.

- 12 Remove the retaining fasteners from the electrical connector receptacles for the cables that enter the cable track.

- 13 Carefully pull the cables and connector receptacles out of the primary boom.

- 14 Tag, disconnect and plug all hydraulic hoses that enter the cable track from the bulkhead fittings at the pivot end of the boom.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 15 Pull the hydraulic hoses out of the primary boom.

- 16 Remove the cotter pin from the upper cable track at the platform end of the boom.

Note: Always replace the cotter pin with a new one.

- 17 Remove the cable track pull tube guide fasteners from the cable track guide at the platform end of the boom. Remove the cable track guide from the boom.

BOOM COMPONENTS

- 18 Place blocks in between the upper and lower cable tracks and secure the upper and lower tracks together.

AWARNING Crushing hazard. If the upper and lower cable tracks are not properly secured together, the cable track could become unbalanced and fall when removed from the machine.

- 19 Attach a lifting strap from an overhead crane to the cable track.
- 20 Remove the mounting fasteners that attach the lower cable track to the boom.
- 21 Carefully remove the cable track from the machine and place it on a structure capable of supporting it.

AWARNING Crushing hazard. The cable track could become unbalanced and fall if not properly attached to the overhead crane.

NOTICE Component damage hazard. Cables and hoses can be damaged if they are kinked or pinched.

NOTICE Component damage hazard. The cable track can be damaged if it is twisted.

How to Repair the Cable Track

NOTICE Component damage hazard. The boom cable track can be damaged if it is twisted.

Note: A cable track repair kit is available through the Genie Industries Service Parts Department, part no. 77896. The kit includes a 4 link section of cable track.

- 1 Visually inspect the cable track and determine which 4 link section needs to be replaced.
- 2 Carefully remove the snap rings from each end of the damaged section of cable track.
- 3 Remove the retaining fasteners from the upper black rollers from the 4 link section of cable track to be replaced. Remove the rollers.
- 4 Lift up the hoses and cables and carefully remove the damaged 4 link section of cable track.


NOTICE Component damage hazard. Hoses and cables can be damaged if they are kinked or pinched.

- 5 Remove the upper rollers from the replacement section of cable track.
- 6 Lift up the hoses and cables and carefully insert the new 4 link section of cable track.

NOTICE Component damage hazard. Hoses and cables can be damaged if they are kinked or pinched.

- 7 Connect the ends of the replacement cable track section to the existing cable track using the snap rings.
- 8 Install the rollers onto the new section of cable track.
- 9 Operate the boom extend/retract function through a full cycle to ensure smooth operation of the new section of cable track.

BOOM COMPONENTS



- a short link arm to boom pivot pin
- b boom
- c boom lift cylinder rod-end pivot pin
- d boom lift cylinder
- e long link arm (ground controls side)
- f long link arm (engine side)
- g long link arm to turntable pivot pin
- h master cylinder cam
- i master cylinder cam link
- j short link arm to turntable pivot pin
- k long link arm to boom pivot pin
- l master platform level cylinder
- m short link arm weldment



BOOM COMPONENTS

4-2 Boom

How to Remove the Boom

▲ DANGER Tip-over hazard. This procedure requires the removal of the turntable counterweight. Failure to remove the counterweight before removing the boom assembly will result in the machine tipping over. Do not remove the boom without first removing the counterweight.

▲ DANGER Tip-over hazard. When installing the boom onto the machine, the boom assembly must be first installed prior to the installation of the counterweight. If the counterweight is installed before the boom assembly, the machine will tip over resulting in death or serious injury.

▲ DANGER Tip-over hazard. The turntable counterweight is essential for machine stability. Failure to install the counterweight after installing the boom assembly will compromise machine stability resulting in the machine tipping over. Death or serious injury will result.

▲ WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

- 1 Remove the jib boom. See 3-1, *How to Remove the Jib Boom*.
- 2 Remove the cable track. See 4-1, *How to Remove the Cable Track*.

Note: S-60X and S-60XC: Disconnect the two limit switch connectors at the platform end of the cable track.

- 3 Raise the boom until the short and long link arm to boom pivot pins are above the turntable covers.
- 4 Place a block of wood measuring 4 x 4 x 60 inches / 10 x 10 x 152 cm under the long link arm, across the turntable covers.
- 5 Slowly lower the boom until the long link arm contacts the wood block. Do not rest the entire weight of the boom on the block. Turn the machine off.

NOTICE Component damage hazard. The turntable covers can become damaged if the weight of the boom is allowed to rest on the block.

- 6 Place wood blocks between the short link arm and the turntable weldment for support.
- 7 Insert a 1.125 x 12 inches / 32 x 300 mm eye-bolt through each hole located on the top surface of the counterweight. Secure the eye-bolts in position with flat washers and nuts.
- 8 Securely attach lifting straps or chains with a minimum rating of 5 tons / 5000 kg to the lifting points on the top of the turntable counterweight. Attach the lifting straps or chains to a 5 ton / 5000 kg overhead crane.

Note: A spreader bar and other hardware may be needed to safely remove the counterweight.

BOOM COMPONENTS

- 9 Slowly operate the overhead crane to apply tension to the lifting straps. Do not attempt to lift the machine with the overhead crane.
- 10 Locate and remove the counterweight retaining fastener at the center of the counterweight. Carefully lift the counterweight upwards and remove the counterweight from the machine. Set the counterweight on the ground. Do not leave the counterweight suspended above the ground.

⚠ DANGER Crushing hazard. The turntable counterweight will fall if not properly supported by the overhead crane resulting in death or serious injury. Keep personnel away from the area when removing the counterweight.

- 11 Attach lifting straps from a 5 ton / 5000 kg overhead crane to each end of the boom. Support the boom. Do not apply any lifting pressure.
- 12 Support and secure the rod end of the boom lift cylinder to a second overhead crane or similar lifting device.
- 13 Remove the lift cylinder rod-end pivot pin retaining fasteners. Use a soft metal drift to remove the pin.

⚠ WARNING Crushing hazard. The boom could fall if not properly supported when the lift cylinder rod-end pivot pin is removed.

- 14 Using auxiliary power, activate the boom down function so the cylinder will retract. Retract the cylinder just enough until the rod end of the cylinder will clear the mounting bracket on the boom. Turn the machine off.

⚠ WARNING Crushing hazard. The boom lift cylinder could fall if not properly supported and secured to the lifting device.

- 15 Using the overhead crane, carefully lower the boom lift cylinder and allow it to rest on the boom rest pad. Protect the cylinder rod from damage.

- 16 **S-60, S-60X, S-60XC, S-65, S-60 TRAX and S-65 TRAX:** Remove the boom end cover retaining fasteners and remove the cover.

S-60 HC: Remove the boom end cover from the pivot end of the boom while guiding the small cable from the string potentiometer out of the slot of the cover. Rest the cover and string potentiometer on the counterweight.

NOTICE Component damage hazard. The cable from the string potentiometer can become damaged if it is kinked or pinched.

- 17 **S-60 HC:** Remove the string potentiometer cable break limit switch mounting fasteners.
- 18 **S-60 HC:** Remove the pulley retaining plate from the string potentiometer pulley bracket. Carefully remove the string potentiometer cable and limit switch assembly from the boom.

BOOM COMPONENTS

19 **S-60X and S-60XC:** Disconnect the boom angle sensor harness.

20 Tag, disconnect and plug the boom extension cylinder hydraulic hoses. Cap the fittings on the cylinder.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

21 Tag and disconnect the electrical connector for the cable break limit switch.

22 Tag and disconnect all boom wire harness electrical connectors located at the pivot end of the boom.

23 Support the platform leveling master cylinder. Remove the master cylinder rod-end pivot pin retaining fasteners. Place a rod through the pin and twist to remove. Carefully lower the master cylinder down.

24 Tag, disconnect and plug the hydraulic hoses from the bulkhead fittings at the pivot end of the boom. Cap the bulkhead fittings.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

25 Remove the external snap rings from both boom pivot pins at the short and long link arms. Do not remove the pins.

26 Using the overhead crane, adjust the boom as necessary to relieve pressure from the pivot pins.

27 Use a soft metal drift to remove each boom pivot pin. Carefully remove the boom assembly from the machine and place it on a structure capable of supporting it.

▲WARNING Crushing hazard. The boom could fall if not properly supported by the overhead crane when each boom pivot pin is removed.

▲CAUTION Crushing hazard. The long and short link arms may fall if not properly supported when the boom pivot pins are removed.

BOOM COMPONENTS

4-3 Boom Lift Cylinder

The boom lift cylinder raises and lowers the boom. The boom lift cylinder is equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure.

How to Remove the Boom Lift Cylinder

▲WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Raise the boom to a horizontal position.
- 2 Attach a 5 ton / 5000 kg overhead crane to the boom at the platform end for support. Do not lift the boom.
- 3 Support and secure both ends of the boom lift cylinder to a second overhead crane or similar lifting device.
- 4 Remove the pin retaining fastener from the boom lift cylinder rod-end pivot pin. Use a soft metal drift to remove the pin.

▲WARNING Crushing hazard. The boom will fall if not properly supported when the primary boom rod-end pivot pin is removed.

- 5 Using auxiliary power, activate the boom down function so the cylinder will retract. Retract the cylinder just enough until the rod end of the cylinder will clear the mounting bracket on the boom. Turn the machine off.
- 6 Tag, disconnect and plug the boom lift cylinder hydraulic hoses. Cap the fittings on the cylinder.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 7 Remove the pin retaining fasteners from the boom lift cylinder barrel-end pivot pins. Do not remove the pins.
- 8 Use a slide hammer to remove the barrel-end pivot pins.

▲WARNING Crushing hazard. The boom lift cylinder could become unbalanced and fall if not properly supported and secured to the lifting device.

- 9 Move the boom lift cylinder towards the counterweight end of the machine. Rotate the boom lift cylinder until the barrel-end pivot pin bores will clear the boom linkage.
- 10 Carefully remove the boom lift cylinder from the machine.

▲WARNING Crushing hazard. The boom lift cylinder could become unbalanced and fall if not properly supported and secured to the lifting device.

BOOM COMPONENTS

4-4 Boom Extension Cylinder

The boom extension cylinder is located inside the boom assembly and incorporates cables and pulleys that are responsible for extending the number 3 boom tube. The primary boom extension cylinder is equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure.

How to Remove the Boom Extension Cylinder

▲WARNING Bodily injury hazard. This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools could result in death or serious injury and significant component damage. Dealer service is strongly recommended.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

Note: Perform this procedure with the boom fully retracted.

1 Raise the boom to a horizontal position.

2 **S-60, S-60X, S-60XC, S-65, S-60 TRAX and S-65 TRAX:** Remove the boom end cover retaining fasteners and remove the cover.

S-60 HC: Remove the boom end cover from the pivot end of the boom while guiding the small cable from the string potentiometer out of the slot of the cover. Rest the cover and string potentiometer on the counterweight.

NOTICE Component damage hazard. The cable from the string potentiometer can become damaged if it is kinked or pinched.

3 **S-60 HC:** Remove the string potentiometer cable break limit switch mounting fasteners.

4 **S-60 HC:** Remove the pulley retaining plate from the string potentiometer pulley bracket. Carefully remove the string potentiometer cable and limit switch assembly from the boom.


5 Remove the access covers from both sides of the boom at the pivot end.

6 Fully loosen the lock nuts on the extend cables. Do not remove the nuts.

7 Loosen the retract cable nut at the platform end of the boom. Pull the cable rod from the support and let it hang down.

BOOM COMPONENTS

- 8 Remove the cable guard fasteners and remove the cable guard.



- 9 Locate the retaining plates that secure the retract cables to the inside of the number 3 boom tube.


- 10 Remove the cable retaining plates and pull the retract cables off of the pulleys. Lay the cables flat and out of the way.

- 11 Remove the fasteners from the retaining blocks from the extension cylinder saddle. Remove the blocks.

Note: Access the fasteners through the access hole in the outer boom tube at the pivot end.

- 12 Disconnect the wire connector to the extend cable break limit switch.

- 13 Remove the retaining fasteners that secure the extend cable mounting plates to the inside of the number 1 boom tube.



- 14 Pull back on the extend cable mounting plate until it clears the blocks welded to the inside of the number 1 boom tube.

BOOM COMPONENTS

- 15 Lift up the extend cable mounting plate and push the extend cables towards the platform to create slack in the cables. Rest the cable and bracket assembly on top of the extend cylinder.
- 16 Locate the lower extend cable bracket on the bottom of the number 3 boom tube.
- 17 Remove the lower extend cable bracket mounting fasteners and pull back on the bracket to release it from the number 3 boom tube.
- 18 While pushing the lower extend cable bracket towards the platform, pull the extend cable mounting plate towards the pivot end of the boom.
- 19 Secure the extend cable bracket and cables to the cylinder to prevent them from falling off when removing the cylinder.
- 20 Remove the external snap rings from the extension cylinder pin at the pivot end of the boom.
- 21 Use a soft metal drift to remove the pin.
- 22 Tag, disconnect and plug the boom extension cylinder hydraulic hoses. Cap the fittings on the cylinder.
- 23 Attach a lifting strap from a 5 ton / 5000 kg overhead crane to the lug at the rod end of the boom extension cylinder.
- 24 Lift the boom extension cylinder with the crane until it clears the cylinder saddle inside the number 2 boom tube.
- 25 Carefully support and slide the extension cylinder out of the boom.

▲WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

▲WARNING Crushing hazard. The extension cylinder could fall when removed from the boom if not properly supported.

NOTICE Component damage hazard. Be careful not to damage the cable break limit switch.

NOTICE Component damage hazard. Be careful not to damage the counterbalance valves on the primary boom extension cylinder when removing the cylinder from the boom.

Note: During removal of the extension cylinder, the overhead crane strap will need to be carefully adjusted for proper balancing.

BOOM COMPONENTS

4-5 Boom Extend/Retract Cables

How to Adjust the Boom Extend/Retract Cables

The boom extend/retract cables are responsible for the extension and retraction of the number 3 boom tube. Proper adjustment of the boom extend/retract cables and related components on a regular basis is essential to good machine performance and safe machine operation. The boom extend and retract functions should operate smoothly and be free of hesitation, jerking and unusual noise.

Note: Perform this procedure with the boom in a horizontal position.

- 1 Fully retract the boom.
- 2 **S-60, S-60X, S-60XC, S-65, S-60 TRAX and S-65 TRAX:** Remove the boom end cover retaining fasteners and remove the cover.

S-60 HC: Remove the boom end cover from the pivot end of the boom while guiding the small cable from the string potentiometer out of the slot of the cover. Rest the cover and string potentiometer on the counterweight.

NOTICE Component damage hazard. The cable from the string potentiometer can become damaged if it is kinked or pinched.

- 3 Inspect the threaded ends of the boom extend cables. The threads must be clean and in good condition with no damaged threads.

- 4 Adjust the extend cable adjustment nuts until approximately 1.5 inches / 4 cm of threads are visible past the nylock nut.

Note: If the cables have been replaced, be sure the adjustment nuts have been replaced. Do not re-use the existing nuts.

- 5 Extend the boom until there is approximately 3 feet / 1 m of travel left. Do not fully extend the boom.
- 6 Locate the retract cable adjustment nut on the bottom of the number 1 boom tube at the platform end of the boom.
- 7 Using a dial type torque wrench, torque the retract cable adjustment nut to 32-36 ft lbs / 43-49 Nm using gentle and steady torque.
- 8 Retract and extend the boom approximately 3 feet / 1 m two times and stop during the extension cycle. This will create slack in the retract cables.

Note: Be sure to not fully extend the boom. Stop when there is approximately 3 feet / 1 m of travel left.


- 9 Repeat steps 7 and 8 two to three times.
- 10 Fully extend the boom then retract the boom approximately 12 inches / 30 cm.
- 11 At the pivot end of the boom, visually inspect the boom extend cables for even cable droop or sag.

Note: If the boom extend cables are uneven, tighten the boom extend cable adjustment nut at the pivot end of the boom for the appropriate cable.

BOOM COMPONENTS

12 Visually inspect the cable break limit switch arm to be sure the wheel of the limit switch arm is centered in the notch of the pivot plate.

Note: If the boom extend cables are adjusted evenly, the wheel of the limit switch arm should be centered in the notch of the pivot plate.



- a cable break limit switch
- b extend cable adjustment nut
- c extend cable pivot plate

13 Install the boom end cover at the pivot end of the boom.

14 Fully retract and lower the boom to the stowed position.

How to Replace the Boom Extend/Retract Cables

Note: The cable pulleys must also be replaced when replacing the cables.

1 Remove the boom extension cylinder. See 4-4, *How to Remove the Boom Extension Cylinder*.

Boom extend cables:

2 Remove the cables from the lower boom extend cable bracket that attaches to the number 3 boom tube.

3 Remove the rue rings and clevis pins from the boom extend cables located near the extend cable break limit switch.

4 Remove the external snap rings from the boom extend cable pulley pivot pin. Use a soft metal drift to remove the pin.

Note: When driving the pivot pin out, be sure to drive it from the shaped end of the pin.

5 Remove the pulley and boom extend cables from the extension cylinder assembly. Discard the old cables and pulleys.

6 Route the new boom extend cables through the boom extend pulley bracket.

7 Install the new boom extend cable pulley, pivot pin and snap rings.

Note: Be sure the boom extend cables are routed through the grooves of the pulley and the upper wear pad on the extension cylinder.

8 Install the boom extend cable clevis pins and rue rings to the pivot plate near the cable break limit switch.

9 Install the boom extend cables to the lower extend cable bracket that mounts to the number 3 boom tube.

BOOM COMPONENTS

Boom retract cables:

10 Remove the cotter pins and clevis pins from the boom retract cables at the platform end of the boom.

Note: Always use a new cotter pin when installing a clevis pin.

11 Remove the wear pad fasteners from the upper wear pads on the number 1 boom tube. Remove the wear pads.

Note: Pay attention to the location of each wear pad and the quantity of shims for each one.

12 Attach a lifting strap from an overhead crane to the platform end of the boom.

13 Raise the boom using the overhead crane and place a wood block under the number 2 boom tube between the number 1 and number 2 boom tubes for support. This will create clearance between the boom tubes to remove the retract cables.

14 Attach the cable pulling tool or a rope to one of the boom retract cables at the pivot end of the boom.

Note: A cable pulling tool is available through Genie Service Parts Department (Genie part no. 94510)

15 At the platform end of the boom, pull on the boom retract cable that has the rope attached to it.

16 Pull the old cable completely out of the boom tube. Remove the rope. Discard the old boom retract cable.

17 Securely attach the rope to the same end of the new boom retract cable.

18 At the pivot end of the boom, carefully pull the rope with the new retract cable attached.

19 Pull the new cable towards the pivot end of the boom until the end of the cable is at the end of the boom tube. Remove the rope.

20 Repeat steps 14 through 19 for the other boom retract cable.

21 At the platform end of the boom, install the retract cables, clevis pins and new cotter pins to the adjustment plate.

22 Remove and discard the old boom retract pulleys from the pivot end of the boom extension cylinder.

23 Install the new boom retract pulleys to the pivot end of the boom extension cylinder.

24 Install the boom extension cylinder assembly into the boom.

Note: Before lowering the extension cylinder into the saddles of the number 1 boom tube, wrap the boom retract cables around the pulleys.

25 Adjust the boom extend/retract cables.
See 4-5, *How to Adjust the Boom Extend/Retract Cables*.

BOOM COMPONENTS

4-6 Platform Leveling Master Cylinder

The master cylinder acts as a pump for the slave cylinder. It's part of the closed circuit hydraulic loop that keeps the platform level through the entire range of boom motion. The master cylinder is located at the pivot end of the boom.

How to Remove the Platform Leveling Master Cylinder

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Raise the boom until the master cylinder is above the turntable covers.
- 2 Tag, disconnect and plug the master cylinder hydraulic hoses. Cap the fittings on the cylinder.

⚠ WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Place a 2 x 4 x 48 inches / 5 x 10 x 120 cm block of wood across the turntable covers. Position the block under the master cylinder.

- 4 Remove the pin retaining fastener from the master cylinder rod-end pivot pin.
- 5 Place a rod through the rod-end pivot pin and twist to remove the pin. Lower the rod end of the master cylinder onto the block.
- 6 Remove the pin retaining fastener from the barrel-end pivot pin.
- 7 Place a rod through the barrel-end pivot pin and twist to remove the pin.
- 8 Remove the master cylinder from the machine.


BOOM COMPONENTS

4-7 Primary Boom Angle Sensor S-60X and S-60XC

The primary boom angle sensor works in conjunction with the boom extend limit switches when restricted maximum platform load is selected from the platform controls maintaining the working envelope. The primary boom angle sensor is located on the ground control side long link arm.

How to Replace the Primary Boom Angle Sensor

- 1 From the ground controls raise the primary boom until it is fully elevated.
- 2 Push in the red Emergency Stop button to the off position and turn the key switch to the off position.
- 3 Locate the primary boom angle sensor mounted on the ground control side long link arm.
- 4 Cut and discard the two button cable ties securing the angle sensor harness to the gusset plate.
- 5 Locate and disconnect the angle sensor harness connector.
- 6 Remove the angle sensor retaining fasteners and set aside. Remove the angle sensor.
- 7 Install the angle sensor onto the hex key. Refer to the illustration for proper alignment.
- 8 Install the angle sensor retaining fasteners. Do not tighten at this time.
- 9 Route the angle sensor harness through the gusset plate and secure using two button cable ties.
- 10 Securely connect the angle sensor harness to the main harness.
- 11 Turn the key switch to platform controls. Pull up red Emergency Stop buttons at the ground and platform controls to the on position.
- 12 Using a volt meter set to DC volts, back probe the angle sensor harness connector. Insert the negative lead into terminal 2, the positive lead into terminal 3.
- 13 Adjust the angle sensor until the volt meter reads 3.8V dc to 4.2V dc and securely tighten the fasteners.
- 14 Calibrate the boom angle sensor. Refer to Repair Procedure 1-2, *How to Calibrate the Boom Angle Sensor*.



- a button cable ties
- b start orientation
- c finish orientation
- d gusset plate

Engines

5-1 RPM Adjustment - Ford and Deutz Models

Refer to Maintenance Procedure B-9, *Check and Adjust the Engine RPM - Ford and Deutz Models*.

5-2 RPM Adjustment - Perkins Models

Refer to Maintenance Procedure A-12, *Check and Adjust the Engine RPM - Perkins Models*.


5-3 Flex Plate

The flex plate acts as a coupler between the engine and the pump. It is bolted to the engine flywheel and has a splined center to drive the pump.

Two different styles of flex plates have been used in the production of your machine model.

Type "A" flex plates utilize a flex plate installed onto the flywheel of the engine and a separate coupler installed onto the pump splined shaft.

Type "B" flex plates combines the pump coupler, as part of the flex plate, which is installed onto the engine flywheel.



Type "A"
(flexplate with
separate coupler)

Type "B"
(flexplate with
coupler combined)

ENGINES

How to Remove the Flex Plate**Deutz models:**

- 1 Remove the tailpipe bracket mounting fasteners from the engine bell housing.
- 2 Support the drive pump assembly with an appropriate lifting device.
- 3 Remove all of the engine bell housing fasteners.
- 4 Carefully pull the pump and bell housing assembly away from the engine and secure it from moving.

NOTICE Component damage hazard. Hoses can be damaged if they are kinked or pinched.

- 5 Remove the flex plate mounting fasteners. Remove the flex plate from the flywheel.

Ford models:

- 1 Disconnect the electrical connectors from both oxygen sensors at the tailpipe and exhaust manifold. Do not remove the oxygen sensors.
- 2 Remove the exhaust pipe fasteners at the muffler.
- 3 Support the muffler and bracket assembly with a suitable lifting device.
- 4 Remove the muffler bracket mounting fasteners from the bell housing. Carefully remove the muffler and bracket assembly from the engine.
- 5 Support the engine with an overhead crane or other suitable lifting device. Do not lift it.

- 6 Remove the engine mounting plate to bell housing fasteners.
- 7 Raise the engine slightly using the overhead crane and place a block of wood under the oil pan for support.
- 8 Support the drive pump assembly with an overhead crane or other suitable lifting device. Do not apply any lifting pressure.
- 9 Remove all of the engine bell housing retaining fasteners.
- 10 Carefully pull the pump and bell housing assembly away from the engine and secure it from moving.

NOTICE Component damage hazard. Hoses can be damaged if they are kinked or pinched.

- 11 Remove the flex plate mounting fasteners. Remove the flex plate from the flywheel.

Perkins models:

- 1 Remove the fuel filter/water separator mounting fasteners.
- 2 Remove the fuel filter/water separator and lay it to the side. Do not disconnect the hoses.
- 3 Support the drive pump assembly with an appropriate lifting device.
- 4 Remove all of the engine bell housing fasteners.
- 5 Carefully pull the pump and bell housing assembly away from the engine and secure it from moving.

NOTICE Component damage hazard. Hoses can be damaged if they are kinked or pinched.

- 6 Remove the flex plate mounting fasteners. Remove the flex plate from the flywheel.

ENGINES


How to Install a Type "A" Flex Plate

1 Install the flex plate onto the engine flywheel with the raised spline towards the pump.


2 **Ford models:** Torque the flex plate mounting bolts in sequence to 14 ft-lbs / 19 Nm. Then torque the flex plate mounting bolts in sequence to 20 ft-lbs / 27 Nm.

Deutz models: Torque the flex plate mounting bolts in sequence to 28 ft-lbs / 38 Nm. Then torque the flex plate mounting bolts in sequence to 40 ft-lbs / 54 Nm.

Perkins models: Torque the flex plate mounting bolts in sequence to 49 ft-lbs / 66 Nm. Then torque the flex plate mounting bolts in sequence to 70 ft-lbs / 95 Nm.




Ford and Deutz models



Perkins models

3 Install the pump coupler onto the pump shaft with the set screw toward the pump. Leave the appropriate gap between coupler and pump end plate for your engine.



- a pump
- b pump shaft
- c pump coupler
- d flex plate with raised spline
- e engine flywheel
- f $\frac{3}{16}$ inch / 4.8 mm gap - Diesel Models
0.080 inch / 2 mm gap - Ford Models

4 Apply Loctite® removable thread sealant to the pump coupler set screw. Torque the set screw to 61 ft-lbs / 83 Nm.

5 Proceed to Repair Procedure, *How to Install the Pump and Bell Housing Assembly*.


ENGINES

How to Install a Type "B" Flex Plate


- 1 Install the flex plate onto the engine flywheel with the rubber vibration isolators towards the pump.
- 2 Apply Loctite® removable thread sealant to the flex plate fasteners and loosely install the fasteners.
- 3 **Deutz models:** Torque the flex plate mounting bolts in sequence to 28 ft-lbs / 38 Nm. Then torque the flex plate mounting bolts in sequence to 40 ft-lbs / 54 Nm.
Ford and Perkins models: Torque the flex plate mounting bolts in sequence to 14 ft-lbs / 19 Nm. Then torque the flex plate mounting bolts in sequence to 20 ft-lbs / 27 Nm.
- 4 Apply a high viscosity coupling grease (Genie part number 128025) to the splines of the pump shaft and flex plate.

Grease Specification


Shell Alvania® Grease CG, NLGI 0/1 or equivalent.



Deutz models



Ford models



Perkins models

ENGINES

How to Install the Pump and Bell Housing Assembly

- 1 Install the pump and bell housing assembly.


Deutz models: Torque the bell housing mounting bolts labeled "C" in sequence to 28 ft-lbs / 38 Nm. Then torque the bell housing mounting bolts labeled "C" in sequence to 40 ft-lbs / 54 Nm.

Ford models: Torque the bell housing mounting bolts labeled "A" and "B" in sequence to 28 ft-lbs / 38 Nm and the mounting bolts labeled "C" to 49 ft-lbs / 66 Nm. Then torque the bell housing mounting bolts labeled "A" and "B" in sequence to 40 ft-lbs / 54 Nm and the mounting bolts labeled "C" to 70 ft-lbs / 95 Nm.


Perkins models: Torque the bell housing mounting bolts labeled "B" in sequence to 28 ft-lbs / 38 Nm and the mounting bolts labeled "A" to 49 ft-lbs / 66 Nm. Then torque the bell housing mounting bolts labeled "B" in sequence to 40 ft-lbs / 54 Nm and the mounting bolts labeled "A" to 70 ft-lbs / 95 Nm.

NOTICE Component damage hazard.
Type "A" flexplate: When installing the pump, do not force the pump coupler into the flexplate or damage to the pump shaft seal may occur.


NOTICE Component damage hazard. Do not force the drive pump during installation or the flex plate teeth may become damaged.



Deutz models



Ford models



Perkins models

ENGINES

5-4 Engine Fault Codes - Ford Models

How to Retrieve Engine Fault Codes

The ECM constantly monitors the engine by the use of sensors on the engine. The ECM also uses signals from the sensors to initiate sequential fuel injection and make constant and instantaneous changes to ignition timing, fuel delivery and throttle position to maintain the engine's running condition at its highest efficiency while at the same time keeping exhaust emissions to a minimum. When a sensor fails or returns signals that are outside of set parameters, the ECM will store a fault code in memory that relates to the appropriate sensor and will turn on the Check Engine Light.

Refer to Section 5, *How to Retrieve Engine Fault Codes* for your specific model of engine. Use the Fault Code Chart within Section 5 to aid in identifying the fault.

Hydraulic Pumps


6-1 Function Pump

How to Remove the Function Pump

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Locate the two hydraulic tank valves at the hydraulic tank through the access hole underneath the turntable. Close the valves.

NOTICE Component damage hazard. The engine must not be started with the hydraulic tank shut-off valves in the closed position or component damage will occur. If the tank valves are closed, remove the key from the key switch and tag the machine to inform personnel of the condition.



- 2 Tag, disconnect and plug the function pump hydraulic hoses. Cap the fittings on the pump.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Remove the pump mounting bolts. Carefully remove the pump.

NOTICE Component damage hazard. Be sure to open the two hydraulic tank valves and prime the pump after installing the pump.

HYDRAULIC PUMPS

6-2 Drive Pump

The drive pump is a bi-directional variable displacement piston pump. The pump output is controlled by the electro-proportional controller, located on the pump. The only adjustment that can be made to the pump is the neutral or null adjustment. Any internal service to the pump should only be performed at an authorized Eaton Hydraulics center. Call Genie Industries Service Department to locate your local authorized service center.


How to Remove the Drive Pump

NOTICE Component damage hazard. The work area and surfaces where this procedure will be performed must be clean and free of debris that could get into the hydraulic system and cause severe component damage. Dealer service is recommended.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Disconnect the electrical connection at the electro-proportional controller located on the drive pump.
- 2 Locate the two hydraulic tank valves at the hydraulic tank through the access hole underneath the turntable. Close the valves.

NOTICE Component damage hazard. The engine must not be started with the hydraulic tank shut-off valves in the closed position or component damage will occur. If the tank valves are closed, remove the key from the key switch and tag the machine to inform personnel of the condition.



- 3 Tag and disconnect and plug the hydraulic hoses from the drive and function pumps. Cap the fittings on the pumps.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Support the pump with a lifting device and remove the two drive pump mounting fasteners.

HYDRAULIC PUMPS

- 5 Carefully pull the drive pump out until the pump coupler separates from the flex plate.
- 6 Remove the drive pump from the machine.

NOTICE Component damage hazard. The hydraulic pump may become unbalanced and fall if not properly supported.

NOTICE Component damage hazard. When installing the pump, do not force the pump coupler into the flexplate or damage to the pump shaft seal may occur.

NOTICE Component damage hazard. Be sure to open the two hydraulic tank valves and prime the pump after installing the pump.

How to Prime the Pump

- 1 Connect a 0 to 600 psi / 0 to 50 bar pressure gauge to the test port on the drive pump.
- 2 Remove the safety pin (if equipped) from the engine pivot plate latch.


Note: The engine pivot plate latch is located under the engine turntable pivot plate at the counterweight end of the machine.

- 3 Open the engine pivot plate latch and swing the engine pivot plate out and away from the machine.

- 4 **Ford models:** Close the valve on the LPG tank then disconnect the hose from the tank. Move the fuel select switch to the LPG position.

Perkins models: Disconnect the engine wiring harness from the fuel solenoid at the injector pump.

Deutz models: Hold the manual fuel shutoff valve clockwise to the closed position.



a manual fuel shutoff valve

- 5 Have another person crank the engine with the starter motor for 15 seconds, wait 15 seconds, then crank the engine an additional 15 seconds or until the pressure reaches 320 psi / 22 bar.

- 6 **Ford models:** Connect the LPG hose to the LPG tank and open the valve on the tank. Move the fuel select switch to the gasoline position.

Perkins models: Connect the engine wiring harness to the fuel solenoid.

Deutz models: Release the manual fuel shutoff valve.

- 7 Start the engine from the ground controls and check for hydraulic leaks.

Manifolds


7-1

Function Manifold Components

The function manifold is located underneath the ground controls side turntable cover.

Index No.	Description	Schematic Item	Function	Torque
1	Counterbalance valve	H	Platform level down	30-35 ft-lbs / 41-47 Nm
2	Counterbalance valve	G	Platform level up	30-35 ft-lbs / 41-47 Nm
3	Proportional solenoid valve	M	Boom extend/retract	30-35 ft-lbs / 41-47 Nm
4	Solenoid valve, 2 position 3 way	C	Boom retract	30-35 ft-lbs / 41-47 Nm
5	Solenoid valve, 2 position 3 way	B	Boom extend	30-35 ft-lbs / 41-47 Nm
6	Solenoid valve, 3 position 4 way	D	Turntable rotate	20-25 ft-lbs / 27-34 Nm
7	Proportional solenoid valve	T	Boom up/down circuit	30-35 ft-lbs / 41-47 Nm
8	Solenoid valve, 3 position 4 way	BB	Steer left/right	20-25 ft-lbs / 27-34 Nm
9	Check valve, 30 psi / 2 bar	I	Differential sensing circuit, platform rotate left and jib boom up (S-65, S-65 TRAX)	20-25 ft-lbs / 27-34 Nm
10	Check valve, 30 psi / 2 bar	J	Differential sensing circuit, platform rotate right and jib boom down (S-65, S-65 TRAX) ...	20-25 ft-lbs / 27-34 Nm
11	Check valve	N	Differential sensing circuit, boom extend/retract	10-12 ft-lbs / 14-16 Nm
12	Solenoid valve, 2 position 3 way	F	Boom down	30-35 ft-lbs / 41-47 Nm
13	Solenoid valve, 2 position 3 way	E	Boom up	30-35 ft-lbs / 41-47 Nm
14	Check valve	O	Differential sensing circuit, turntable rotate	10-12 ft-lbs / 14-16 Nm
15	Check valve	R	Differential sensing circuit, boom up/down	10-12 ft-lbs / 14-16 Nm
16	Priority flow regulator valve, 3.5 gpm / 13.2 L/min	AA	Steer left/right circuit	30-35 ft-lbs / 41-47 Nm
17	Differential sensing valve, 110 psi / 7.6 bar	S	Boom up/down circuit	30-35 ft-lbs / 41-47 Nm
18	Differential sensing valve, 150 psi / 10.3 bar	P	Turntable rotate circuit	30-35 ft-lbs / 41-47 Nm

MANIFOLDS



MANIFOLDS

Function Manifold Components, continued

Index No.	Description	Schematic Item	Function	Torque
19	Check valve, 5 psi / 0.3 bar	A	Blocks flow from auxiliary pump to function pump	30-35 ft-lbs / 41-47 Nm
20	Relief valve, 3000 psi / 206.8 bar	K	System relief	30-35 ft-lbs / 41-47 Nm
21	Flow control valve, 0.1 gpm / 0.38 L/min	DD	Bleeds off differential sensing valves to tank	20-25 ft-lbs / 27-34 Nm
22	Differential sensing valve, 150 psi / 10.3 bar	CC	Differential sensing circuit, meters flow to functions	30-35 ft-lbs / 41-47 Nm
23	Check valve	W	Differential sensing circuit, platform level up	10-12 ft-lbs / 14-16 Nm
24	Check valve	X	Differential sensing circuit, platform level down	10-12 ft-lbs / 14-16 Nm
25	Proportional solenoid valve	Q	Turntable rotate left/right	20-25 ft-lbs / 27-34 Nm
26	Flow control valve, 0.6 gpm / 2.27 L/min	Z	Platform rotate and jib boom (S-65, S-65 TRAX)	20-25 ft-lbs / 27-34 Nm
27	Check valve, 30 psi / 2 bar	EE	Platform rotate and jib boom circuit (S-65, S-65 TRAX) (prevents hydraulic hoses from draining back to tank)	20-25 ft-lbs / 27-34 Nm
28	Differential sensing valve, 110 psi / 7.6 bar	L	Boom extend/retract circuit	30-35 ft-lbs / 41-47 Nm
29	Needle valve	U	Platform level circuit	30-35 ft-lbs / 41-47 Nm
30	Solenoid valve, 3 position 4 way	V	Platform level up/down	20-25 ft-lbs / 27-34 Nm
31	Solenoid valve, 3 position 4 way	Y	Platform rotate and jib boom up/down (S-65, S-65 TRAX)	20-25 ft-lbs / 27-34 Nm

7-2 Valve Adjustments - Function Manifold

How to Adjust the System Relief Valve

Note: Perform this procedure with the boom in the stowed position.

- 1 Connect a 0 to 5000 psi / 0 to 350 bar pressure gauge to the P_{TEST} port on the function manifold.
- 2 Start the engine from the ground controls.
- 3 Hold the function enable/rpm select toggle switch to the high idle position. Activate and hold the boom retract toggle switch with the boom fully retracted.
- 4 Observe the pressure reading on the pressure gauge. Refer to Section 2, *Specifications*.
- 5 Turn the engine off. Use a wrench to hold the relief valve and remove the cap (item K).
- 6 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the relief valve cap.


⚠WARNING Tip-over hazard. Do not adjust the relief valve higher than specified.

- 7 Repeat steps 2 through 5 and recheck relief valve pressure.
- 8 Remove the pressure gauge.

MANIFOLDS

7-3 Jib Boom / Platform Rotate Manifold Components

Index No.	Description	Schematic Item	Function	Torque
1	Solenoid valve, 2 position 3 way FF		Platform rotate/jib boom select	20-25 ft-lbs / 27-34 Nm




MANIFOLDS

7-4 Brake/Two-Speed Manifold Components (to SN 25201)

The brake/two-speed manifold is mounted near the turntable rotator.

Index No.	Description	Schematic Item	Function	Torque
1	Orifice, 0.025 inch / 0.64 mm	JJ	Turntable rotation brake release	
2	Solenoid valve, 2 position 3 way	KK	Brake release	20-25 ft-lbs / 27-34 Nm
3	Solenoid valve, 2 position 3 way	LL	Two-speed motor shift	20-25 ft-lbs / 27-34 Nm
4	Check valve	II	Brake release circuit	20-25 ft-lbs / 27-34 Nm




MANIFOLDS

7-5 Brake/Two-Speed Manifold Components (from SN 25202)

The brake/two-speed manifold is mounted near the turntable rotator.

Index No.	Description	Schematic Item	Function	Torque
1	Orifice, 0.025 inch / 0.64 mm	JJ	Turntable rotation brake release	
2	Solenoid valve, 2 position 3 way	KK	Brake release	20-25 ft-lbs / 27-34 Nm
3	Solenoid valve, 2 position 3 way	LL	Two-speed motor shift	20-25 ft-lbs / 27-34 Nm
4	Check valve	II	Brake release circuit	20-25 ft-lbs / 27-34 Nm




MANIFOLDS

7-6 Turntable Rotation Manifold Components

The turntable rotation manifold is mounted to the turntable rotation motor.

Index No.	Description	Schematic Item	Function	Torque
1	Counterbalance valve	MM	Turntable rotate right	35-40 ft-lbs / 47-54 Nm
2	Counterbalance valve	NN	Turntable rotate left	35-40 ft-lbs / 47-54 Nm
3	Shuttle valve, 2 position 3 way	OO	Turntable rotation brake release	10-13 ft-lbs / 14-18 Nm
4	Orifice, 0.030 inch / 0.76 mm	PP	Brake release circuit (located inside port)	




MANIFOLDS

7-7 Oscillate Directional Valve Components

The oscillate directional valve is mounted inside the drive chassis at the non-steer end.

Index No.	Description	Schematic Item	Function	Torque
1	Cap		Breather	20-25 ft-lbs / 27-33 Nm
2	Spool valve	JJ	Directional control	
3	Relief valve, 800 psi / 55 bar	LL	Oscillate relief	30-35 ft-lbs / 41-47 Nm



MANIFOLDS

How to Set Up the Oscillate Directional Valve

Note: Adjustment of the oscillate directional valve linkage is only necessary when the linkage or valve has been replaced.

- 1 Lower the boom to the stowed position.
- 2 Use a "bubble type" level to be sure the floor is completely level.

⚠ WARNING Tip-over hazard. Failure to perform this procedure on a level floor could compromise the stability of the machine resulting in the machine tipping over.

- 3 Check the tire pressure in all four tires and add air if needed to meet specification.

Note: The tires on some machines are foam-filled and do not need air added to them.

- 4 Remove the drive chassis cover and the non-steer axle covers.
- 5 Place a "bubble type" level across the drive chassis non-steer end. Check to be sure the drive chassis is completely level.
- 6 Remove the heim joint retaining fastener from the axle.
- 7 To level the drive chassis, start the engine and push up or pull down on the threaded rod until the machine is completely level.

- 8 Verify that the ground and drive chassis are completely level.
- 9 Adjust the heim joint until the hole lines up with the retaining fastener hole in the axle.
- 10 Install the heim joint to the axle and tighten the jam nut.
- 11 Check to be sure the drive chassis is completely level.
- 12 Measure the distance between the drive chassis and the non-steer axle on both sides (from the inside of the drive chassis).

Note: If the distance is not equal and the adjustment to the linkage was completed with the ground and drive chassis level, repeat steps 6 through 11 OR consult Genie Industries Service Department.

MANIFOLDS

7-8**Valve Adjustments - Oscillate Relief Valve****How to Adjust the Oscillate Relief Valve Pressure**

- 1 Remove the drive chassis cover from the non-steer end of the machine.
- 2 Connect a 0 to 2000 psi / 0 to 150 bar pressure gauge to the diagnostic nipple located near the oscillate directional valve.
- 3 Disconnect the directional valve linkage, by removing the heim joint and retaining fastener from the axle.
- 4 Start the engine from the platform controls. Move the engine idle toggle switch to the maintained high idle position.
- 5 With the engine running in high rpm, manually activate the valve and observe the pressure reading on the pressure gauge. Refer to Section 2, *Specifications*.
- 6 Turn the engine off.
- 7 Locate the relief valve on the directional valve and loosen the jamb nut.
- 8 Adjust the hex screw. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Tighten the jamb nut.

▲WARNING Tip-over hazard. Do not adjust the relief valve higher than specified.


- 9 Repeat steps 4 through 7 and manually activate the valve to confirm the valve pressure.
- 10 Turn the engine off, remove the pressure gauge and assemble the directional valve linkage.
- 11 Install the cover on the non-steer end of the drive chassis.

MANIFOLDS

7-9 Drive Oil Diverter Manifold Components (welder option)

The oil diverter manifold is mounted to the hydraulic generator located in the engine compartment.

Index No.	Description	Schematic Item	Function	Torque
1	Directional valve	CU	Diverter valve	80-90 ft-lbs / 108-122 Nm
2	Orifice disc, 0.030 inch / 0.080 cm . CV		Delays shift to drive	
3	Solenoid valve	CW	Pilot valve to diverter	35-40 ft-lbs / 47-54 Nm
4	Relief valve	CX	Charge pressure circuit	35-40 ft-lbs / 47-54 Nm
5	Pressure switch 200 psi / 18.6 bar . CZ		Generator relay switch	16 ft-lbs / 22 Nm
6	Connector fitting			11 ft-lbs / 15 Nm
7	Check valve	CY	Prevents oil to generator	35-40 ft-lbs / 47-54 Nm




MANIFOLDS

7-10 Traction Manifold Components, 2WD

The traction manifold is mounted inside the drive chassis at the non-steer end.

Index No.	Description	Schematic Item	Function	Torque
1	Relief valve, 280 psi / 19.3 bar	TT	Charge pressure circuit	30-35 ft-lbs / 41-47 Nm
2	Flow divider/combiner valve	WW	Controls flow to drive motors in forward and reverse	90-100 ft-lbs / 122-136 Nm
3	Check valve	SS	Drive circuit	30-35 ft-lbs / 41-47 Nm
4	Check valve	XX	Drive circuit	30-35 ft-lbs / 41-47 Nm
5	Shuttle valve, 3 position 3 way	UU	Charge pressure circuit that directs hot oil out of low pressure side of drive pump	50-55 ft-lbs / 68-75 Nm
6	Orifice, 0.070 inch / 1.78 mm	VV	Drive motor circuit	



MANIFOLDS

7-11 Valve Adjustments, 2WD Traction Manifold

How to Adjust the Charge Pressure Relief Valve

- 1 Connect a 0 to 600 psi / 0 to 50 bar pressure gauge to the test port on the drive pump.
- 2 Hold the charge pressure relief valve and remove the cap (item TT).
- 3 Turn the internal hex socket clockwise fully until it stops. Install the cap.
- 4 Start the engine and move and hold the function enable/rpm select toggle switch to the high rpm (rabbit symbol) position. Note the reading on the pressure gauge.
- 5 Turn the engine off.
- 6 Remove the pressure gauge from the drive pump. Connect the gauge to the test port located on the traction manifold.
- 7 Start the engine from the platform controls. Press down the foot switch and slowly move the drive control handle off center just until the machine begins to move. Note the reading on the pressure gauge. Turn the machine off.
- 8 Hold the charge pressure relief valve and remove the cap (item TT).
- 9 Adjust the internal hex socket until the pressure reading on the gauge is 30 psi / 2 bar less than the pressure reading on the pump. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the valve cap.
- 10 Repeat steps 7 through 9 until the pressure reading at the drive manifold is 30 psi / 2 bar less than the pressure reading at the pump.
- 11 Turn the engine off and remove the pressure gauge.


MANIFOLDS

7-12**Traction Manifold Components, 4WD (from SN 21001 to 21231)**

The traction manifold is mounted inside the drive chassis at the non-steer end.

Index No.	Description	Schematic Item	Function	Torque
1	Check valve	TT	Steer end drive motor circuit	35-40 ft-lbs / 14-16 Nm
2	Check valve	SS	Non-steer end drive motor circuit	35-40 ft-lbs / 14-16 Nm
3	Flow divider/combiner valve	AB	Controls flow to flow divider/combiner valves 11 and 13	80-90 ft-lbs / 108-122 Nm
4	Check valve	AF	Non-steer end drive motor circuit	60-70 ft-lbs / 81-95 Nm
5	Orifice, 0.040 inch / 1 mm	AC	Equalizes pressure on both sides of flow divider/combiner valve 3	
6	Orifice, 0.040 inch / 1 mm	AE	Equalizes pressure on both sides of flow divider/combiner valve 11	
7	Orifice, 0.040 inch / 1 mm	WW	Equalizes pressure on both sides of flow divider/combiner valve 13	
8	Check valve	AG	Steer end drive motor circuit	60-70 ft-lbs / 81-95 Nm
9	Check valve	ZZ	Steer end drive motor circuit	35-40 ft-lbs / 14-16 Nm
10	Shuttle valve, 3 position 3 way	VV	Charge pressure circuit that directs hot oil out of low pressure side of drive pump	80-90 ft-lbs / 108-122 Nm
11	Flow divider/combiner valve	AD	Controls flow to steer end drive motors in forward and reverse	80-90 ft-lbs / 108-122 Nm
12	Check valve	YY	Non-steer end drive motor circuit	35-40 ft-lbs / 14-16 Nm
13	Flow divider/combiner valve	XX	Controls flow to non-steer end drive motors in forward and reverse	80-90 ft-lbs / 108-122 Nm
14	Relief valve, 280 psi / 19.3 bar	UU	Charge pressure circuit	35-40 ft-lbs / 14-16 Nm

MANIFOLDS




MANIFOLDS

7-13**Traction Manifold Components, 4WD (after SN 21231)**

The traction manifold is mounted inside the drive chassis at the non-steer end.

Index No.	Description	Schematic Item	Function	Torque
1	Flow divider/combiner valve	XX	Controls flow to non-steer end drive motors in forward and reverse	80-90 ft-lbs / 108-122 Nm
2	Relief valve, 280 psi / 19.3 bar	UU	Charge pressure circuit	35-40 ft-lbs / 14-16 Nm
3	Check valve	TT	Steer end drive motor circuit	35-40 ft-lbs / 14-16 Nm
4	Flow divider/combiner valve	AB	Controls flow to flow divider/combiner valves 1 and 13	80-90 ft-lbs / 108-122 Nm
5	Orifice, 0.040 inch / 1 mm	WW	Equalizes pressure on both sides of flow divider/combiner valve 1	
6	Orifice, 0.040 inch / 1 mm	AE	Equalizes pressure on both sides of flow divider/combiner valve 13	
7	Orifice, 0.040 inch / 1 mm	AC	Equalizes pressure on both sides of flow divider/combiner valve 4	
8	Check valve	SS	Non-steer end drive motor circuit	35-40 ft-lbs / 14-16 Nm
9	Check valve	AF	Non-steer end drive motor circuit	60-70 ft-lbs / 81-95 Nm
10	Check valve	ZZ	Steer end drive motor circuit	35-40 ft-lbs / 14-16 Nm
11	Check valve	AG	Steer end drive motor circuit	60-70 ft-lbs / 81-95 Nm
12	Shuttle valve, 3 position 3 way	VV	Charge pressure circuit that directs hot oil out of low pressure side of drive pump	80-90 ft-lbs / 108-122 Nm
13	Flow divider/combiner valve	AD	Controls flow to steer end drive motors in forward and reverse	80-90 ft-lbs / 108-122 Nm
14	Check valve	YY	Non-steer end drive motor circuit	35-40 ft-lbs / 14-16 Nm

MANIFOLDS



MANIFOLDS

7-14 Valve Adjustments, 4WD Traction Manifold

How to Adjust the Charge Pressure Relief Valve

- 1 Connect a 0 to 600 psi / 0 to 50 bar pressure gauge to the test port on the drive pump.
- 2 Hold the charge pressure relief valve and remove the cap (item UU).
- 3 Turn the internal hex socket clockwise fully until it stops. Install the cap.
- 4 Start the engine and move and hold the function enable/rpm select toggle switch to the high rpm (rabbit symbol) position. Note the reading on the pressure gauge.
- 5 Turn the engine off.
- 6 Remove the pressure gauge from the drive pump. Connect the gauge to the test port located on the traction manifold.
- 7 Start the engine from the platform controls. Press down the foot switch and slowly move the drive control handle off center just until the machine begins to move. Note the reading on the pressure gauge. Turn the machine off.
- 8 Hold the charge pressure relief valve and remove the cap (item UU).
- 9 Adjust the internal hex socket until the pressure reading on the gauge is 30 psi / 2 bar less than the pressure reading on the pump. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Install the valve cap.
- 10 Repeat steps 7 through 9 until the pressure reading at the drive manifold is 30 psi / 2 bar less than the pressure reading at the pump.
- 11 Turn the engine off and remove the pressure gauge.


MANIFOLDS

7-15

Hydraulic Generator Manifold Components, 3kW (after SN 21396)

The generator manifold is mounted to the hydraulic generator located in the engine compartment.

Index No.	Description	Schematic Item	Function	Torque
1	Proportional solenoid valve	HH	Generator speed	33-37 ft-lbs / 45-50 Nm
2	Relief valve, 2700 psi / 186 bar	GG	Generator circuit	20-25 ft-lbs / 27-34 Nm



MANIFOLDS

7-16 Valve Coils

How to Test a Coil

A properly functioning coil provides an electromotive force which operates the solenoid valve. Critical to normal operation is continuity within the coil. Zero resistance indicates the coil has failed.

Since coil resistance is sensitive to temperature, resistance values outside specification can produce erratic operation. When coil resistance decreases below specification, amperage increases. As resistance rises above specification, voltage increases.

While valves may operate when coil resistance is outside specification, maintaining coils within specification will help ensure proper valve function over a wide range of operating temperatures.

⚠ WARNING Electrocuting/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 1 Tag and disconnect the wiring from the coil to be tested.
 - 2 Test the coil resistance.
- ⊙ Result: The resistance should be within specification, plus or minus 30%.
 - ⊗ Result: If the resistance is not within specification, plus or minus 30%, replace the coil.

Valve Coil Resistance Specification

Note: The following coil resistance specifications are at an ambient temperature of 68°F / 20°C. As valve coil resistance is sensitive to changes in air temperature, the coil resistance will typically increase or decrease by 4% for each 18°F / 10°C that your air temperature increases or decreases from 68°F / 20°C.

Valve Coil Resistance Specification

Description	Specification
Solenoid valve, 3 position 4 way, 10V DC (schematic items D, V and Y)	5 to 7Ω
Solenoid valve, 3 position 4 way, 10V DC (schematic item BB)	4 to 6Ω
Solenoid valve, 2 position 3 way, 10V DC (schematic items B, C, E, F and FF)	5 to 7Ω
Solenoid valve, 2 position 3 way, 10V DC (schematic items KK and LL)	5.5 to 7.5Ω
Proportional solenoid valve, 12V DC (schematic items M and T)	4 to 6Ω
Proportional solenoid valve, 12V DC (schematic item Q)	3.7 to 5.7Ω

MANIFOLDS

How to Test a Coil Diode

Genie incorporates spike suppressing diodes in all of its directional valve coils except proportional valves and those coils with a metal case. Properly functioning coil diodes protect the electrical circuit by suppressing voltage spikes. Voltage spikes naturally occur within a function circuit following the interruption of electrical current to a coil. Faulty diodes can fail to protect the electrical system, resulting in a tripped circuit breaker or component damage.


⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 1 Test the coil for resistance. See, *How to Test a Coil*.
- 2 Connect a 10Ω resistor to the negative terminal of a known good 9V DC battery. Connect the other end of the resistor to a terminal on the coil.

Resistor, 10Ω

Genie part number 27287

Note: The battery should read 9V DC or more when measured across the terminals.



Note: Dotted lines in illustration indicate a reversed connection as specified in step 6

- 3 Set a multimeter to read DC current.

Note: The multimeter, when set to read DC current, should be capable of reading up to 800 mA.

- 4 Connect the negative lead to the other terminal on the coil.

Note: If testing a single-terminal coil, connect the negative lead to the internal metallic ring at either end of the coil.

- 5 Momentarily connect the positive lead from the multimeter to the positive terminal on the 9V DC battery. Note and record the current reading.
 - 6 At the battery or coil terminals, reverse the connections. Note and record the current reading.
- ⊙ Result: Both current readings are greater than 0 mA and are different by a minimum of 20%. The coil is good.
 - ⊗ Result: If one or both of the current readings are 0 mA, or if the two current readings do not differ by a minimum of 20%, the coil and/or its internal diode are faulty and the coil should be replaced.

Turntable Rotation Components

8-1 Turntable Rotation Assembly

How to Remove the Turntable Rotation Assembly

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

Note: Perform this procedure with the machine on a firm and level surface.


- 1 Secure the turntable from rotating with the turntable rotation lock pin.

Note: The turntable rotation lock pin is located next to the boom rest pad.

- 2 Tag, disconnect and plug the hydraulic hoses from the turntable rotation drive motor. Cap the fittings on the drive motor.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Loosen the backlash pivot plate and adjustment bolts.



- a backlash pivot plate
- b adjustment bolt with lock nut
- c backlash pivot plate mounting bolts

- 4 Attach a suitable lifting device to the lifting eyes on the drive hub assembly.
- 5 Remove the backlash pivot plate mounting bolts. Carefully remove the drive hub assembly from the machine.

WARNING Crushing hazard. The turntable could rotate unexpectedly when the rotation drive hub assembly is removed if the turntable is not secured with the turntable rotation lock pin.

WARNING Crushing hazard. The turntable rotation drive hub assembly could become unbalanced and fall when removed from the machine if not properly supported.

TURNTABLE ROTATION COMPONENTS

When installing the drive hub assembly:

- 6 Install the drive hub. Torque the back lash pivot plate to specification. Refer to Section 2, *Specifications*.
- 7 Adjust turntable rotation gear backlash. See *How to Adjust the Turntable Rotation Gear Backlash*.

How to Adjust the Turntable Rotation Gear Backlash


The turntable rotation drive hub is mounted on an adjustable plate that controls the gap between the rotation motor pinion gear and the turntable bearing ring gear.

Note: Perform this procedure with the boom between the non-steer end tires and with the machine on a firm and level surface.

- 1 Secure the turntable from rotating with the turntable rotation lock pin.

Note: The turntable rotation lock pin is located next to the boom rest pad.

- 2 Loosen the backlash pivot plate mounting fasteners.



- a backlash pivot plate
- b adjustment bolt with lock nut
- c backlash pivot plate mounting bolts

- 3 Push the backlash pivot plate towards the turntable as far as possible (this will push the rotation gear into the turntable bearing ring gear).
- 4 Loosen the lock nut on the adjustment bolt.
- 5 Turn the adjustment bolt clockwise until it contacts the backlash pivot plate.
- 6 Turn the adjustment bolt $\frac{1}{2}$ turn counterclockwise. Tighten the lock nut on the adjustment bolt.
- 7 Rotate the backlash pivot plate away from the turntable until it contacts the adjustment bolt. Then torque the mounting fasteners on the backlash pivot plate to specification. Refer to Section 2, *Specifications*.
- 8 Rotate the turntable through an entire rotation. Check for tight spots that could cause binding. Readjust if necessary.

Axle Components

9-1 Oscillating Axle Cylinders

The oscillating axle cylinders extend and retract between the drive chassis and the axle to maintain a level chassis while driving over uneven terrain. The cylinders are equipped with counterbalance valves to prevent movement in the event of a hydraulic hose failure.

How to Remove an Oscillate Axle Cylinder

Note: Perform this procedure on firm, level surface with the boom in the stowed position.

Note: When removing a hose assembly or fitting, the O-ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation. Refer to Section 2, *Hydraulic Hose and Fitting Torque Specifications*.

- 1 Rotate the turntable until the boom is between the steer tires or tracks.
- 2 Tag, disconnect and plug the oscillating axle cylinder hydraulic hoses. Cap the fittings on the cylinder.

WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Remove the pin retaining fasteners from the rod-end pivot pin. Use a soft metal drift to remove the pin.
- 4 Attach a lifting strap from an overhead crane to the barrel end of the oscillating cylinder.
- 5 Remove the pin retaining fasteners from the barrel-end pivot pin. Use a soft metal drift to remove the pin.
- 6 Remove the cylinder from the machine.

WARNING Crushing hazard. The oscillate cylinder could become unbalanced and fall if not properly attached to the overhead crane when removed from the machine.

Track Components

10-1 Track Assembly, S-60 TRAX and S-65 TRAX

How to Remove a Track Assembly

Note: Perform this procedure on a firm, level surface with the boom in the stowed position.

- 1 Select a track assembly to remove. Loosen and remove as many sprocket retaining fasteners as possible from the hub adapter.
- 2 Drive the machine in either direction just enough to access the remaining fasteners. Do not remove the retaining fasteners.
- 3 Chock the tracks at the opposite end of the machine to prevent the machine from rolling.
- 4 Center a lifting jack of ample capacity (20,000 lbs / 10,000 kg) under the drive chassis between the tracks.
- 5 Lift the machine until the tracks are off the ground and then place jack stands under the drive chassis for support.
- 6 Attach a lifting strap from an overhead crane to the center-point of the track assembly, above the sprocket.
- 7 Remove the remaining sprocket retaining fasteners from the hub adapter.
- 8 Carefully remove the track assembly from the drive hub and set aside.


CAUTION Crushing hazard. The track assembly could become unbalanced and fall when removed from the machine if not properly supported by the overhead crane.

How to Replace the Track

- 1 Remove the track assembly from the machine.
See *How to Remove a Track Assembly*.

Note: The sprocket is comprised of two halves. Before removing the track assembly from the machine and to ease the removal of the sprocket, drive the machine until one complete half of the sprocket is located above the undercarriage of the track assembly.


- 2 Loosen the grease plug on the track tension cylinder to relieve the track tension. Clean up any grease that has spilled.
- 3 Remove the 2 sprocket retaining fasteners. Remove the sprocket half from the track assembly.
- 4 Carefully remove the track from the undercarriage.
- 5 Use an overhead crane to lay the undercarriage on its side with the drive sprocket bearing assembly facing upward and the track tension cylinder towards the ground.




TRACK COMPONENTS

- 6 Install the new track onto the undercarriage.
- 7 Attach a lifting strap from an overhead crane to the center-point of the track, above the sprocket.
- 8 Use the overhead crane to raise the track assembly to an upright position. Rest the assembly on the floor or ground to remove any slack in the lower portion of the track.

Note: Be sure the idler and bogey wheels are aligned with the inside surface of the track.



- 9 Rotate the sprocket half until the split tooth of the sprocket is lower than the other side.



a split tooth

- 10 Using an overhead crane or other suitable lifting device, lift up on the rubber track to create enough room to install the other sprocket half.
- 11 Install the sprocket half, removed in step 3, while engaging the sprocket teeth with the rubber track.

Note: Be sure to align the split tooth in both of the sprocket halves.


- 12 Insert a pin or rod through the wheel stud hole closest to the split tooth to hold the sprocket in place.
- 13 Insert a pointed pry bar into the wheel stud hole near the top of the sprocket. Insert another pointed pry bar into the wheel stud hole at the opposite side of the split tooth.

TRACK COMPONENTS


- 14 Using the pry bars, lift the sprocket half into position. Install the 2 sprocket retaining fasteners and torque to specification. Refer to Section 2, *Specifications*.
- 15 Attach a lifting strap from an overhead crane to the center-point of the track assembly, above the sprocket.
- 16 Install the track assembly onto the drive hub adapter while guiding the hub adapter studs into the sprocket of the track assembly. Install as many sprocket retaining fasteners as possible to the hub adapter and torque to specification. Refer to Section 2, *Specifications*.

CAUTION Crushing hazard. The track assembly could become unbalanced and fall when installed onto the machine if not properly supported by the overhead crane.

- 17 Adjust the track tension. Locate the grease plug on the track tension cylinder. Loosen the plug, but do not remove it.
- 18 Locate the grease zerk fitting on the other side of the track tension cylinder.



- 19 Pump grease into the grease zerk fitting until grease, free from air, comes out of the grease plug. Securely tighten the grease plug. Do not overtighten.
- 20 Continue to pump grease into the grease fitting just until the idler wheel moves. Check the track tension.
- ⊙ Result: There should be less than 1 inch / 2.5 cm of gap between the bogey wheels and the inside surface of the track. Proceed to step 22.
 - ✗ Result: There is 1 inch / 2.5 cm or more of gap between the bogey wheels and the inside surface of the track. Proceed to step 21.



TRACK COMPONENTS

- 21 Continue to pump grease into the cylinder until the track has proper tension.

NOTICE Component damage hazard.
Do not over tighten the track.
Overtightening the track will cause the machine to lose power during operation.

Note: If the track becomes too tight, loosen the grease plug on the cylinder to remove grease and loosen the track.

- 22 Raise the machine, remove the jack stands and lower the machine.
- 23 Drive the machine in either direction just until the remaining sprocket retaining fasteners can be installed onto the drive hub adapter. Turn the machine off.
- 24 Install the remaining sprocket retaining fasteners to the drive hub adapter and torque to specification. Refer to Section 2, *Specifications*.

Grease Specification

Chevron Ultra-duty grease, EP NLGI 2 (lithium based) or equivalent.

Fault Codes



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.
- ☑ Unless otherwise specified, perform each repair procedure with the machine in the following configuration:
 - Machine parked on a firm, level surface
 - Boom in stowed position
 - Turntable rotated with the boom between the non-steer wheels
 - Turntable secured with the turntable rotation lock
 - Welder disconnected from the machine (if equipped with the weld cable to platform option)
 - Wheels chocked
 - All external AC power disconnected from the machine

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine before attempting any maintenance or repair procedure.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.
- ☑ Read each appropriate fault code thoroughly. Attempting shortcuts may produce hazardous conditions.
- ☑ Be aware of the following hazards and follow generally accepted safe workshop practices.

⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

Note: Two persons will be required to safely perform some troubleshooting procedures.

Control System Fault Codes

Control System

How to Retrieve Control System Fault Codes

Note: At least one fault code is present when the alarm at the platform controls produces two short beeps every 30 seconds for 10 minutes.

Note: Perform this procedure with the engine off, the key switch turned to platform controls and both red Emergency Stop button pulled out to the on position at both the ground and platform controls.

- 1 Open the platform control box lid.

AWARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 2 Locate the red and yellow fault LEDs on the ALC-500 circuit board inside the platform control box. Do not touch the circuit board.

NOTICE Component damage hazard. Electrostatic discharge (ESD) can damage printed circuit board components. If the circuit board does need to be handled, maintain firm contact with a metal part of the machine that is grounded at all times when handling the printed circuit board OR use a grounded wrist strap.

- 3 **Determine the error source:** The red LED indicates the error source and will flash two separate codes. The first code will indicate the first digit of the two digit code, flashing once per second. It will then pause for 1.5 seconds and flash the second digit once per 0.5 second.

Note: When the red LED is flashing the code, the yellow LED will be on solid.

- 4 **Determine the error type:** The yellow LED indicates the error type and will flash two separate codes. The first code will indicate the first digit of the two digit code, flashing once per second. It will then pause for 1.5 seconds and flash the second digit once per 0.5 second.

Note: When the yellow LED is flashing the code, the red LED will be on solid.

- 5 Use the fault code table on the following pages to aid in troubleshooting the machine by pinpointing the area or component affected.

Control System Fault Codes

Error Source ID Name	Error Type ID Name	Condition	Solution
21 Primary Up / Down Joystick	11 Value at 5V	Function is inoperative. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
	12 Value too high		
	15 Value too low		
	16 Value at 0V		
	17 Not calibrated		
22 Primary Up / Down Directional Valves	21 Fault	Valve is operating outside of limits. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
23 Primary Up / Down Flow Valve	12 Value too high	Valve is operating outside of limits. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
	15 Value too low		
	17 Not calibrated	Normal function except threshold for one or both directions is zero.	Calibrate valve threshold.
24 Angle sensor	11 Value at 5V	Reduced speed function. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
	12 Value too high		
	15 Value too low		
	16 Value at 0V		
	17 Not calibrated		
	31 Invalid setup	Initiate 1 -second beep of Alarm Buzzer and required retract into safe envelope	Calibrate angle sensor.



Control System Fault Codes

Error Source ID Name	Error Type ID Name	Condition	Solution
26 Angle sensor cross check	19 Out of range	Reduced speed, required retract into safe envelope	Power up controller with problem corrected
31 Primary Ext. / Ret. Joystick	11 Value at 5V	Function is inoperative. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
	12 Value too high		
	15 Value too low		
	16 Value at 0V		
	17 Not calibrated		Calibrate joystick.
32 Primary Ext. / Ret. Directional Valves	21 Fault	Valve is operating outside of limits. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
33 Primary Ext. / Ret. Flow Valve	12 Value too high	Valve is operating outside of limits. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
	15 Value too low		
	17 Not calibrated	Normal function except threshold for one or both directions is zero.	Calibrate valve threshold.
34 Ext. Ret. Limit Switch	31 Invalid setup	Initiate 1-second beep of Alarm Buzzer	Fully retract, then lower boom
		-1000lb. Mode: Required retract into "FULLY RETRACTED" state before lowering	Check and service ext/ ret and fully stowed switches
		-500lb. Mode: Operates normally	



Control System Fault Codes

Error Source		Error Type		Condition	Solution		
ID	Name	ID	Name				
41	Turntable Rotate Joystick	11	Value at 5V	Limited speed and direction frozen at zero and neutral. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.		
		12	Value too high				
		15	Value too low				
		16	Value at 0V				
		17	Not calibrated		Calibrate joystick.		
42	Turntable Rotate Directional Valves	21	Fault	Limited direction. Frozen at zero and neutral. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.		
43	Turntable Rotate Flow Valve	12	Value too high	Limited speed and direction. Frozen at zero and neutral. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.		
		15	Value too low				
						17	Not calibrated
44	Drive Enable Override Switch	21	Fault	Drive enable override direction is frozen at neutral.	Cycle power off, then on after problem has been corrected.		



Control System Fault Codes

Error Source ID Name	Error Type ID Name	Condition	Solution
45 Platform Level Switch	21 Fault	Platform level frozen at neutral	Power up controller with problem corrected
46 Primary Extend/Retract Switch	21 Fault	Platform Ext/Ret frozen at neutral	Power up controller with problem corrected
51 Drive Joystick	11 Value at 5V 12 Value too high 15 Value too low 16 Value at 0V	Limited speed and direction. Frozen at zero and neutral. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
	17 Not calibrated		
53 Drive Flow Valve (EDC)	12 Value too high 15 Value too low Frozen at zero and neutral.	Limited speed and direction. problem has been corrected. Alarm sounds indicating a fault.	Cycle power off, then on after
	17 Not calibrated		

Control System Fault Codes

Error Source ID Name	Error Type ID Name	Condition	Solution
54 Drive Brake Valve	21 Fault	Drive frozen at zero and neutral. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
55 High Drive Motor Speed Valve	21 Fault	Motor speed in the low state. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
56 Platform Level Value	21 Fault	Direction frozen at zero and neutral, AB	Power up controller with problem corrected
57 Foot switch/ECU Power Crosscheck	12 Value too high 15 Value too low	Direction frozen at zero and neutral, AB	Power up controller with problem corrected
61 Steer Joystick	11 Value at 5V 12 Value too high 15 Value too low 16 Value at 0V	Limited speed and direction. Frozen at zero and neutral. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.
	17 Not calibrated		
62 Steer Directional Valve	21 Fault	Limited speed and direction. Frozen at zero and neutral. Alarm sounds indicating a fault.	Cycle power off, then on after problem has been corrected.



Ford DSG-423 EFI Engine Fault Codes

Ford DSG-423 EFI Engine

How to Retrieve Ford Engine Fault Codes

The ECM constantly monitors the engine by the use of sensors on the engine. The ECM also uses signals from the sensors to initiate sequential fuel injection and make constant and instantaneous changes to ignition timing, fuel delivery and throttle position to maintain the engine's running condition at its highest efficiency while at the same time keeping exhaust emissions to a minimum. When a sensor fails or returns signals that are outside of set parameters, the ECM will store a fault code in memory that relates to the appropriate sensor and will turn on the Check Engine Light.

Note: Perform this procedure with the key switch in the off position.

- 1 Open the ground controls side cover and locate the run/test toggle switch on the side of the ground control box.
- 2 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 3 Move and hold the run/test toggle switch to the test position.
- ⦿ Result: The check engine light should turn on. The check engine light should begin to blink.
- 4 Continue to hold the run/test toggle switch in the test position and count the blinks.

Note: Before the fault codes are displayed, the check engine light will blink a code 1-2-3 three times. After the fault codes, the check engine light will blink a code 1-2-3 three times again indicating the end of the stored codes.

Note: If any fault codes are present, the ECM will blink a three digit code three times for each code stored in memory. It will blink the first digit of a three digit code, pause, blink the second digit, pause, and then blink the third digit. For example: the check engine light blinks 5 consecutive times, blinks 3 times and then 1 time. That would indicate code 531.

Note: Once a fault code has been retrieved and the repair has been completed, the ECM memory must be reset to clear the fault code from the ECM. See *How to Clear Engine Fault Codes from the ECM*.

How to Clear Engine Fault Codes from the ECM

Note: Perform this procedure with the engine off and the key switch in the off position.

- 1 Open the engine side turntable cover and locate the battery.
- 2 Disconnect the negative battery cable from the battery for a minimum of 5 minutes.

⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 3 Connect the negative battery cable to the battery.

Ford DSG-423 EFI Engine Fault Codes

Code	Description
11	Intake cam / distributor position
16	Never crank synced at start
24	Exhaust cam position
91	FP low voltage
92	FP high voltage
107	MAP Low Voltage
108	MAP High Pressure
111	IAT higher than expected 1
112	IAT low voltage
113	IAT high voltage
116	ECT higher than expected 1
117	ECT/CHT Low Voltage
118	ECT/CHT High Voltage
121	TPS1 lower than TPS2
122	TPS1 low voltage
123	TPS1 high voltage
127	IAT higher than expected 2
129	BP low pressure
134	EGO open/lazy pre-cat 1
140	EGO open/lazy post-cat 1
154	EGO open/lazy pre-cat 2/post-cat 1
160	EGO open/lazy post-cat 2

Code	Description
171	AL high gasoline bank1
172	AL low gasoline bank1
174	AL high gasoline bank2
175	AL low gasoline bank2
182	FT Gasoline Low Voltage
183	FT Gasoline High Voltage
187	FT Gaseous fuel low voltage
188	FT Gaseous fuel high voltage
217	ECT higher than expected 2
219	Max govern speed override
221	TPS1 higher than TPS2
222	TPS2 low voltage
223	TPS2 high voltage
236	TIP Active
237	TIP Low Voltage
238	TIP High Voltage
261	Injector Loop Open or Low-side short to Ground
262	Injector Coil Shorted
264	Injector Loop Open or Low-side short to Ground
265	Injector Coil Shorted
267	Injector Loop Open or Low-side short to Ground

Code Description

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number

162067



Ford DSG-423 EFI Engine Fault Codes

268	Injector Coil Shorted	304	Emissions/catalyst damaging misfire
270	Injector Loop Open or Low-side short to Ground	305	Emissions/catalyst damaging misfire
271	Injector Coil Shorted	306	Emissions/catalyst damaging misfire
273	Injector Loop Open or Low-side short to Ground	307	Emissions/catalyst damaging misfire
274	Injector Coil Shorted	308	Emissions/catalyst damaging misfire
276	Injector Loop Open or Low-side short to Ground	326	Knock 1 Excessive Signal
277	Injector Coil Shorted	327	Knock 1 sensor Open
279	Injector Loop Open or Low-side short to Ground	331	Knock 2 Excessive Signal
280	Injector Coil Shorted	332	Knock 2 sensor Open
282	Injector Loop Open or Low-side short to Ground	336	Crank sync noise
283	Injector Coil Shorted	337	Crank loss
285	Injector Loop Open or Low-side short to Ground	341	Cam sync noise
286	Injector Coil Shorted	342	Cam loss
288	Injector Loop Open or Low-side short to Ground	420	Gasoline cat monitor
289	Injector Coil Shorted	430	Gasoline cat monitor
301	Emissions/catalyst damaging misfire	524	Oil pressure low
302	Emissions/catalyst damaging misfire	562	Battery Voltage Low
303	Emissions/catalyst damaging misfire	563	Battery Voltage High
		601	Flash checksum invalid
		604	RAM failure
		606	COP failure
		615	Start relay coil open
Code	Description	Code	Description

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual
Genie part number 162067



Ford DSG-423 EFI Engine Fault Codes

616	Start relay control ground short	1154	CL low NG
617	Start relay coil short to power	1155	CL high gasoline bank1
627	Fpump relay coil open	1156	CL low gasoline bank1
628	FPump motor loop open or high-side shorted to ground	1157	CL high gasoline bank2
628	Fpump relay control ground short	1158	CL low gasoline bank2
629	FPump motor high-side shorted to power	1161	AL high LPG
629	Fpump relay coil short to power	1162	AL low LPG
642	5VE1 low voltage	1163	AL high NG
643	5VE1 high voltage	1164	AL low NG
650	MIL open	1165	LPG cat monitor
652	5VE2 low voltage	1166	NG cat monitor
653	5VE2 high voltage	1171	Megajector delivery pressure higher than expected
685	Relay Coil Open	1172	Megajector delivery pressure lower than expected
686	Relay Control ground short	1173	Megajector comm lost
687	Relay coil short to power	1174	Megajector voltage supply high
1111	Fuel rev limit	1175	Megajector voltage supply low
1112	Spark rev limit	1176	Megajector internal actuator fault detection
1121	FPP1/2 simultaneous voltages out of range	1177	Megajector internal circuitry fault detection
1122	FPP1/2 do not match each other or the IVS	1178	Megajector internal comm fault detection
1151	CL high LPG	1181	Fuel run-out longer than expected
1152	CL low LPG		
1153	CL high NG		

Code Description

Code Description

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number

162067



Ford DSG-423 EFI Engine Fault Codes

1182	Fuel impurity level high	1543	AUX analog PUD2 high
1183	Megajector autozero / lockoff failed	1544	AUX analog PUD2 low
1311	Misfire detected	1545	AUX analog PUD3 high
1312	Misfire detected	1546	AUX analog PUD3 low
1313	Misfire detected	1547	AUX analog PUD4 high
1314	Misfire detected	1548	AUX analog PUD4 low
1315	Misfire detected	1551	AUX DIG1 high
1316	Misfire detected	1552	AUX DIG1 low
1317	Misfire detected	1553	AUX DIG2 high
1318	Misfire detected	1554	AUX DIG2 low
1511	AUX analog PU1 high	1555	AUX DIG3 high
1512	AUX analog PU1 low	1556	AUX DIG3 low
1513	AUX analog PU2 high	1561	AUX analog PD2 high
1514	AUX analog PU2 low	1562	AUX analog PD2 low
1515	AUX analog PD1 high	1563	AUX analog PD3 high
1516	AUX analog PD1 low	1564	AUX analog PD3 low
1517	AUX analog PU3 high	1611	5VE 1/2 simultaneous out-of-range
1518	AUX analog PU3 low	1612	RTI 1 loss
1521	CHT higher than expected 1	1613	RTI 2 loss
1522	CHT higher than expected 2	1614	RTI 3 loss
1531	IVS/Brake/Trans-Park interlock failure	1615	A/D loss
1541	AUX analog PUD1 high	1616	Invalid interrupt
1542	AUX analog PUD1 low		

Code Description

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual
Genie part number 162067



Ford DSG-423 EFI Engine Fault Codes

1621	Rx Inactive
1622	Rx Noise
1623	Invalid Packet Format
1624	Shutdown Request
1625	Shutdown Request
1626	CAN Tx failure
1627	CAN Rx failure
1628	CAN addresss conflict failure
1629	J1939 TSC1 message receipt lost
1630	J1939 ETC message receipt lost
1631	PWM1-Gauge1 open / ground short
1632	PWM1-Gauge1 short to power
1633	PWM2-Gauge2 open / ground short
1634	PWM2-Gauge2 short to power
1635	PWM3-Gauge3 open / ground short
1636	PWM3-Gauge3 short to power
1637	PWM4 open / ground short
1638	PWM4 short to power
1639	PWM5 open / ground short
1640	PWM5 short to power
1641	Buzzer control ground short
1642	Buzzer open
1643	Buzzer control short to power
1644	MIL control ground short
1645	MIL control short to power
1661	PWM6 open / ground short
1662	PWM6 short to power
1663	PWM7 open / ground short
1664	PWM7 short to power
1665	PWM8 open / ground short
1666	PWM8 short to power
1669	PWM9 open / ground short
1670	PWM9 short to power
2111	Unable to reach lower TPS
2112	Unable to reach higher TPS
2115	FPP1 higher than IVS limit
2116	FPP2 higher than IVS limit
2120	FPP1 invalid voltage and FPP2 disagrees with IVS
2121	FPP1 lower than FPP2
2122	FPP1 high voltage
2123	FPP1 low voltage
2125	FPP2 invalid voltage and FPP1 disagrees with IVS
2126	FPP1 higher than FPP2
2127	FPP2 low voltage
Code	Description

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number

162067



Ford DSG-423 EFI Engine Fault Codes

2128	FPP2 high voltage	2316	Primary Coil Shorted
2130	IVS stuck at-idle, FPP1/2 match	2318	Primary Loop Open or Low-side Short to Ground
2131	IVS stuck off-idle, FPP1/2 match	2319	Primary Coil Shorted
2135	TPS1/2 simultaneous voltages out of range	2321	Primary Loop Open or Low-side Short to Ground
2139	FPP1 lower than IVS limit	2322	Primary Coil Shorted
2140	FPP2 lower than IVS limit	2324	Primary Loop Open or Lowside Short to Ground
2229	BP high pressure	2325	Primary Coil Shorted
2300	Primary Loop Open or Low-side Short to Ground	2327	Primary Loop Open or Low-side Short to Ground
2301	Primary Coil Shorted	2328	Primary Coil Shorted
2303	Primary Loop Open or Low-side Short to Ground	2618	Tach output ground short
2304	Primary Coil Shorted	2619	Tach output short to power
2306	Primary Loop Open or Low-side Short to Ground		
2307	Primary Coil Shorted		
2309	Primary Loop Open or Low-side Short to Ground		
2310	Primary Coil Shorted		
2312	Primary Loop Open or Low-side Short to Ground		
2313	Primary Coil Shorted		
2315	Primary Loop Open or Low-side Short to Ground		

Code Description

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number 162067



Ford MSG-425 EFI Engine Fault Codes

Ford MSG-425 EFI Engine

How to Retrieve Ford Engine Fault Codes

The ECM constantly monitors the engine by the use of sensors on the engine. The ECM also uses signals from the sensors to initiate sequential fuel injection and make constant and instantaneous changes to ignition timing, fuel delivery and throttle position to maintain the engine's running condition at its highest efficiency while at the same time keeping exhaust emissions to a minimum. When a sensor fails or returns signals that are outside of set parameters, the ECM will store a fault code in memory that relates to the appropriate sensor and will turn on the Check Engine Light.

Note: Perform this procedure with the key switch in the off position.

- 1 Open the ground controls side cover and locate the run/test toggle switch on the side of the ground control box.
- 2 Pull out the red Emergency Stop button to the on position at both the ground and platform controls.
- 3 Move and hold the run/test toggle switch to the test position.
- ⦿ Result: The check engine light should turn on. The check engine light should begin to blink.
- 4 Continue to hold the run/test toggle switch in the test position and count the blinks.

Note: Before the fault codes are displayed, the check engine light will blink a code 1-6-5-4 three times. After the fault codes, the check engine light will blink a code 1-6-5-4 three times again indicating the end of the stored codes.

Note: If any fault codes are present, the ECM will blink a three digit code three times for each code stored in memory. It will blink the first digit of a three digit code, pause, blink the second digit, pause, and then blink the third digit. For example: the check engine light blinks 5 consecutive times, blinks 3 times and then 1 time. That would indicate code 531.

Note: Once a fault code has been retrieved and the repair has been completed, the ECM memory must be reset to clear the fault code from the ECM. See *How to Clear Engine Fault Codes from the ECM*.

How to Clear Engine Fault Codes from the ECM

Note: Perform this procedure with the engine off and the key switch in the off position.

- 1 Open the engine side turntable cover and locate the battery.
- 2 Disconnect the negative battery cable from the battery for a minimum of 5 minutes.

⚠ WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

- 3 Connect the negative battery cable to the battery.

Ford MSG-425 EFI Engine Fault Codes

Code	Description	Code	Description
16	Never crank synced at start	182	FT Gasoline Low Voltage
91	FP low voltage	183	FT Gasoline High Voltage
92	FP high voltage	187	FT Gaseous fuel low voltage
107	MAP Low Voltage	188	FT Gaseous fuel high voltage
108	MAP High Pressure	217	ECT higher than expected 2
111	IAT higher than expected 1	219	Max govern speed override
112	IAT low voltage	221	TPS1 higher than TPS2
113	IAT high voltage	222	TPS2 low voltage
116	ECT higher than expected 1	223	TPS2 high voltage
117	ECT/CHT Low Voltage	236	TIP Active
118	ECT/CHT High Voltage	237	TIP Low Voltage
121	TPS1 lower than TPS2	238	TIP High Voltage
122	TPS1 low voltage	261	Injector Loop Open or Low-side short to Ground
123	TPS1 high voltage	262	Injector Coil Shorted
127	IAT higher than expected 2	264	Injector Loop Open or Low-side short to Ground
129	BP low pressure	265	Injector Coil Shorted
134	EGO open/lazy pre-cat 1	267	Injector Loop Open or Low-side short to Ground
140	EGO open/lazy post-cat 1	268	Injector Coil Shorted
154	EGO open/lazy pre-cat 2/post-cat 1	270	Injector Loop Open or Low-side short to Ground
160	EGO open/lazy post-cat 2	271	Injector Coil Shorted
171	AL high gasoline bank1	273	Injector Loop Open or Low-side short to Ground
172	AL low gasoline bank1		
174	AL high gasoline bank2		
175	AL low gasoline bank2		

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number 162067



Ford MSG-425 EFI Engine Fault Codes

Code	Description	Code	Description
274	Injector Coil Shorted	326	Knock 1 Excessive Signal
276	Injector Loop Open or Low-side short to Ground	327	Knock 1 sensor Open
277	Injector Coil Shorted	331	Knock 2 Excessive Signal
279	Injector Loop Open or Low-side short to Ground	332	Knock 2 sensor Open
280	Injector Coil Shorted	336	Crank sync noise
282	Injector Loop Open or Low-side short to Ground	337	Crank loss
283	Injector Coil Shorted	341	Cam sync noise
285	Injector Loop Open or Low-side short to Ground	342	Cam loss
286	Injector Coil Shorted	420	Gasoline cat monitor
288	Injector Loop Open or Low-side short to Ground	430	Gasoline cat monitor
289	Injector Coil Shorted	524	Oil pressure low
301	Emissions/catalyst damaging misfire	562	Battery Voltage Low
302	Emissions/catalyst damaging misfire	563	Battery Voltage High
303	Emissions/catalyst damaging misfire	601	Flash checksum invalid
304	Emissions/catalyst damaging misfire	604	RAM failure
305	Emissions/catalyst damaging misfire	606	COP failure
306	Emissions/catalyst damaging misfire	615	Start relay coil open
307	Emissions/catalyst damaging misfire	616	Start relay control ground short
308	Emissions/catalyst damaging misfire	617	Start relay coil short to power
		627	Fpump relay coil open
		628	FPump motor loop open or high-side shorted to ground
		628	Fpump relay control ground short
		629	FPump motor high-side shorted to power

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number

162067



Ford MSG-425 EFI Engine Fault Codes

Code	Description	Code	Description
629	Fpump relay coil short to power	1163	AL high NG
642	5VE1 low voltage	1164	AL low NG
643	5VE1 high voltage	1165	LPG cat monitor
650	MIL open	1166	NG cat monitor
652	5VE2 low voltage	1171	Megajector delivery pressure higher than expected
653	5VE2 high voltage	1172	Megajector delivery pressure lower than expected
685	Relay Coil Open	1173	Megajector comm lost
686	Relay Control ground short	1174	Megajector voltage supply high
687	Relay coil short to power	1175	Megajector voltage supply low
1111	Fuel rev limit	1176	Megajector internal actuator fault detection
1112	Spark rev limit	1177	Megajector internal circuitry fault detection
1121	FPP1/2 simultaneous voltages out of range	1178	Megajector internal comm fault detection
1122	FPP1/2 do not match each other or the IVS	1311	Misfire detected
1151	CL high LPG	1312	Misfire detected
1152	CL low LPG	1313	Misfire detected
1153	CL high NG	1314	Misfire detected
1154	CL low NG	1315	Misfire detected
1155	CL high gasoline bank1	1316	Misfire detected
1156	CL low gasoline bank1	1317	Misfire detected
1157	CL high gasoline bank2	1318	Misfire detected
1158	CL low gasoline bank2	1511	AUX analog PU1 high
1161	AL high LPG	1512	AUX analog PU1 low
1162	AL low LPG		

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number 162067



Ford MSG-425 EFI Engine Fault Codes

Code	Description	Code	Description
1513	AUX analog PU2 high	1564	AUX analog PD3 low
1514	AUX analog PU2 low	1611	5VE 1/2 simultaneous out-of-range
1515	AUX analog PD1 high	1612	RTI 1 loss
1516	AUX analog PD1 low	1613	RTI 2 loss
1517	AUX analog PU3 high	1614	RTI 3 loss
1518	AUX analog PU3 low	1615	A/D loss
1521	CHT higher than expected 1	1616	Invalid interrupt
1522	CHT higher than expected 2	1621	Rx Inactive
1531	IVS/Brake/Trans-Park interlock failure	1622	Rx Noise
1541	AUX analog PUD1 high	1623	Invalid Packet Format
1542	AUX analog PUD1 low	1624	Shutdown Request
1543	AUX analog PUD2 high	1625	Shutdown Request
1544	AUX analog PUD2 low	1626	CAN Tx failure
1545	AUX analog PUD3 high	1627	CAN Rx failure
1551	AUX DIG1 high	1628	CAN addresss conflict failure
1552	AUX DIG1 low	1629	J1939 TSC1 message receipt lost
1553	AUX DIG2 high	1630	J1939 ETC message receipt lost
1554	AUX DIG2 low	1631	PWM1-Gauge1 open/ground short
1555	AUX DIG3 high	1632	PWM1-Gauge1 short to power
1556	AUX DIG3 low	1633	PWM2-Gauge2 open/ground short
1561	AUX analog PD2 high	1634	PWM2-Gauge2 short to power
1562	AUX analog PD2 low	1635	PWM3-Gauge3 open/ground short
1563	AUX analog PD3 high	1636	PWM3-Gauge3 short to power

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number

162067



Ford MSG-425 EFI Engine Fault Codes

Code	Description
1641	Buzzer control ground short
1642	Buzzer open
1643	Buzzer control short to power
1644	MIL control ground short
1645	MIL control short to power
2111	Unable to reach lower TPS
2112	Unable to reach higher TPS
2115	FPP1 higher than IVS limit
2116	FPP2 higher than IVS limit
2120	FPP1 invalid voltage and FPP2 disagrees with IVS
2121	FPP1 lower than FPP2
2122	FPP1 high voltage
2123	FPP1 low voltage
2125	FPP2 invalid voltage and FPP1 disagrees with IVS
2126	FPP1 higher than FPP2
2127	FPP2 low voltage
2128	FPP2 high voltage
2130	IVS stuck at-idle, FPP1/2 match
2131	IVS stuck off-idle, FPP1/2 match
2135	TPS1/2 simultaneous voltages out of range
2139	FPP1 lower than IVS limit
2140	FPP2 lower than IVS limit
Code	Description
2229	BP high pressure
2300	Primary Loop Open or Low-side Short to Ground
2301	Primary Coil Shorted
2303	Primary Loop Open or Low-side Short to Ground
2304	Primary Coil Shorted
2306	Primary Loop Open or Low-side Short to Ground
2307	Primary Coil Shorted
2309	Primary Loop Open or Low-side Short to Ground
2310	Primary Coil Shorted
2312	Primary Loop Open or Low-side Short to Ground
2313	Primary Coil Shorted
2315	Primary Loop Open or Low-side Short to Ground
2316	Primary Coil Shorted
2318	Primary Loop Open or Low-side Short to Ground
2319	Primary Coil Shorted
2321	Primary Loop Open or Low-side Short to Ground
2322	Primary Coil Shorted
2618	Tach output ground short
2619	Tach output short to power

For further engine fault code troubleshooting and diagnostic information, refer to the *Ford MSG-425/ Ford DSG-423 EFI Diagnostic Manual* (EDI part number 1080030).

Ford MSG-425/DSG-423 EFI Diagnostic Manual

Genie part number 162067



Load Sense System Fault Codes

Platform Load Sense System, S-60 HC


How to Retrieve Platform Load Sense System Fault Codes

Note: Perform this procedure with the engine off, the key switch turned to ground controls and the red Emergency Stop buttons pulled out to the on position at both the ground and platform controls.

- 1 Open the ground controls side turntable cover.
- 2 Locate the operational and safety controllers near the ground control box.
- 3 Determine whether a safety or operational fault exists by visually inspecting which controller has flashing LEDs.

Note: If the LEDs are flashing on both controllers, determine the fault code on one controller at a time.

- 4 **Determine the error source:** The red LED indicates the error source and will flash two separate codes. The first code will indicate the first digit of the two digit code, flashing once per second. It will then pause for 1.5 seconds and flash the second digit once per 0.5 second.
- 5 **Determine the error type:** The green LED indicates the error type and will flash two separate codes. The first code will indicate the first digit of the two digit code, flashing once per second. It will then pause for 1.5 seconds and flash the second digit once per 0.5 second.
- 6 Use the fault code table on the following pages to aid in troubleshooting the machine by pinpointing the area or component affected.



- a green LED (operational control module)
- b red LED (operational control module)
- c operational control module
- d safety control module
- e red LED (safety control module)
- f green LED (safety control module)

Load Sense System Fault Codes

Error Source 12, System Checks

Error Type ID Name	Condition	Solution
11 Safety envelope reached	Power relays disengaged.	Use recovery switch and APU from the ground controls to recover the machine to stowed position or within the operating envelope.
12 Platform load greater than 1250 lbs/567 kg	Power relays disengaged.	Remove weight from platform until load is 1200 lbs/544 kg or less.
13 CAN communication failure	Power relays disengaged.	Repair CAN bus wiring and/or connections.
14 Sensor power failure	Power relays disengaged.	Use recovery switch and APU from the ground controls to recover the machine to stowed position or within the operating envelope.
21 Angle sensor not active	Power relays disengaged.	Inspect boom angle sensor for proper operation and be sure it is connected to boom properly OR replace boom angle sensor.
22 String potentiometer not active	Power relays disengaged.	Inspect string potentiometer for proper operation and be sure it is connected to boom properly OR replace string potentiometer.
23 Power relay output short high	Power relays disengaged. Relay wiring open or shorted to voltage.	Repair system wiring and/or connections.
24 Power relay output short low	Power relays disengaged. Relay wiring open or shorted to ground.	Repair system wiring and/or connections.
25 Directional relay output short high	Boom up/down and extend/retract inoperative. Relay wiring open or shorted to voltage.	Repair system wiring and/or connections.
26 Output short low	Boom up/down and extend/retract inoperative. Relay wiring open or shorted to ground.	Repair system wiring and/or connections.



Load Sense System Fault Codes

Error Source 21, String Potentiometer Operational Sensor (C167PSL)

Error Type ID Name	Condition	Solution
5 Sensor tolerance fault	Power relays disengaged.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
11 Output short high	Power relays disengaged. String potentiometer wiring open or shorted to voltage.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
12 Value too high	Power relays disengaged. String potentiometer wiring open or shorted to voltage.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
15 Value too low	Power relays disengaged. String potentiometer wiring open or shorted to ground.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
16 Output short low	Power relays disengaged. String potentiometer wiring open or shorted to ground.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
17 Not calibrated	Boom range of motion is limited.	Calibrate the platform load sense system.
18 Just calibrated	Used to clear diagnostic codes.	Self-clearing.

Load Sense System Fault Codes

Error Source 22, String Potentiometer Safety Sensor (C167PSL)

Error Type ID Name	Condition	Solution
5 Sensor tolerance fault	Power relays disengaged.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
11 Output short high	Power relays disengaged. String potentiometer wiring open or shorted to voltage.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
12 Value too high	Power relays disengaged. String potentiometer wiring open or shorted to voltage.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
15 Value too low	Power relays disengaged. String potentiometer wiring open OR shorted to ground OR string potentiometer is faulty.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
16 Output short low	Power relays disengaged. String potentiometer wiring open OR shorted to ground.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.
17 Not calibrated	Boom range of motion is limited.	Calibrate the platform load sense system.
18 Just calibrated	Used to clear diagnostic codes.	Self-clearing.
21 Inconsistent	Checks operational and safety sensor values against each other.	Repair wiring and/or connections OR replace string potentiometer and calibrate overload system.

Load Sense System Fault Codes

Error Source 31, Boom Angle Operational Sensor (C123PBS)

Error Type ID Name	Condition	Solution
5 Sensor tolerance fault	Power relays disengaged.	Repair wiring and/or connections OR replace boom angle sensor and calibrate overload system.
11 Output short high	Power relays disengaged. Boom angle sensor wiring open or shorted to voltage.	Repair wiring and/or connections OR replace boom angle sensor and calibrate overload system.
12 Value too high	Power relays disengaged. Boom angle sensor wiring open or shorted to voltage OR sensor is out of operating range.	Repair wiring and/or connections OR adjust or replace boom angle sensor and calibrate overload system.
15 Value too low	Power relays disengaged. Boom angle sensor wiring open OR shorted to ground OR sensor is out of operating range.	Repair wiring and/or connections OR adjust or replace boom angle sensor and calibrate overload system.
16 Output short low	Power relays disengaged. Boom angle sensor wiring open OR shorted to ground.	Repair wiring and/or connections OR replace boom angle sensor and calibrate overload system.
17 Not calibrated	Boom range of motion is limited.	Calibrate the platform load sense system.
18 Just calibrated	Used to clear diagnostic codes.	Self-clearing.

Load Sense System Fault Codes

Error Source 32, Boom Angle Safety Sensor (C141PBS)

Error Type		Condition		Solution
ID	Name	ID	Name	
5	Sensor tolerance fault		Power relays disengaged.	Repair wiring and/or connections OR replace boom angle sensor and calibrate overload system.
11	Output short high		Power relays disengaged. Boom angle sensor wiring open or shorted to voltage.	Repair wiring and/or connections OR replace boom angle sensor and calibrate overload system.
12	Value too high		Power relays disengaged. Boom angle sensor wiring open or shorted to voltage OR sensor is out of operating range.	Repair wiring and/or connections OR adjust or replace boom angle sensor and calibrate overload system.
15	Value too low		Power relays disengaged. Boom angle sensor wiring open OR shorted to ground OR sensor is out of operating range.	Repair wiring and/or connections OR adjust or replace boom angle sensor and calibrate overload system.
16	Output short low		Power relays disengaged. Boom angle sensor wiring open OR shorted to ground.	Repair wiring and/or connections OR replace boom angle sensor and calibrate overload system.
17	Not calibrated		Boom range of motion is limited.	Calibrate the platform load sense system.
18	Just calibrated		Used to clear diagnostic codes.	Self-clearing.
21	Inconsistent		Checks operational and safety sensor values against each other.	Repair wiring and/or connections OR replace boom angle sensor and calibrate overload system.

Load Sense System Fault Codes

Error Source 41, Load Cell Operational (C175LDS)

Error Type ID Name	Condition	Solution
5 Sensor tolerance fault	Power relays disengaged.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system.
11 Output short high	Power relays disengaged. Load cell wiring open OR shorted to voltage.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system.
12 Value too high	Power relays disengaged. Load cell wiring open OR shorted to voltage. Platform may be overloaded.	Repair wiring and/or connections OR replace platform load cell OR remove excess weight from platform.
15 Value too low	Power relays disengaged. Load cell wiring open OR shorted to ground. Platform may be reverse loaded.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system. Check for binding of the overload component linkage and be sure platform is NOT on the ground OR supported from underneath.
16 Output short low	Power relays disengaged. Load cell wiring open OR shorted to ground.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system.
17 Not calibrated	Boom range of motion is limited.	Calibrate the platform load sense system.
18 Just calibrated	Used to clear diagnostic codes.	Self-clearing.

Load Sense System Fault Codes

Error Source 42, Load Cell Safety (C94LDS)

Error Type ID Name	Condition	Solution
5 Sensor tolerance fault	Power relays disengaged.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system.
11 Output short high	Power relays disengaged. Load cell wiring open OR shorted to voltage.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system.
12 Value too high	Power relays disengaged. Load cell wiring open OR shorted to voltage. Platform may be overloaded.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system OR remove excess weight from platform.
15 Value too low	Power relays disengaged. Load cell wiring open OR shorted to ground. Platform may be reverse loaded.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system. Check for binding of the overload component linkage and be sure platform is NOT on the ground OR supported from underneath.
16 Output short low	Power relays disengaged. Load cell wiring open OR shorted to ground.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system.
17 Not calibrated	Boom range of motion is limited.	Calibrate the platform load sense system.
18 Just calibrated	Used to clear diagnostic codes.	Self-clearing.
21 Inconsistent	Checks operational and safety sensor values against each other.	Repair wiring and/or connections OR replace platform load cell and calibrate overload system.

Schematics



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions in the appropriate operator's manual on your machine before attempting any maintenance or repair procedure.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.

About This Section

There are two groups of schematics in this section.


Electrical Schematics

⚠WARNING Electrocutation/burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.



































Hydraulic Schematics

⚠WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.





General Repair Process




Electrical Symbols Legend




Hydraulic Symbols Legend



Limit Switch Location Legend



ALL MODELS EXCEPT AS NOTED




S-60 HC, S-60X AND S-60XC AS NOTED





Ford Engine Relay Layout

Ford MSG-425 EFI





Ford DSG-423 EFI






Ford DSG-423 Engine Wire Harness




Ford DSG-423 Engine Wire Harness




Ford MSG-425 Engine Wire Harness



N M L K J I H G F E D C B A




Ford MSG-425 Engine Wire Harness




Electrical Schematic, Options (All Models)




Electrical Schematic, Options (All Models)





Wiring Diagram, Belt Driven Generator




Wiring Diagram, Belt Driven Generator



Wiring Diagram, 3kW Hydraulic Generator




Wiring Diagram, 3kW Hydraulic Generator




Wiring Diagram, 12kW Hydraulic Generator - Welder Option

N M L K J I H G F E D C B A





1
2
3
4
5
6
7
8


Wiring Diagram, 12kW Hydraulic Generator - Welder Option



**Electrical Schematic, 12kW Hydraulic Generator
Welder Option**




Electrical Schematic, 12kW Hydraulic Generator Welder Option



Hydraulic Schematic, 12kW Hydraulic Generator Option


N M L K J I H G F E D C B A





1
2
3
4
5
6
7
8




Hydraulic Schematic, 12kW Hydraulic Generator Option




Hydraulic Schematic, 2WD Models (from SN 21001 to 21396)




Hydraulic Schematic, 2WD Models (from SN 21001 to 21396)




Hydraulic Schematic, 2WD Models (after SN 21396)




ORIFICE RELOCATED AFTER SERIAL NUMBER 25201




Hydraulic Schematic, 2WD Models (after SN 21396)




Hydraulic Schematic, 4WD Models (from SN 21001 to 21396)



Hydraulic Schematic, 4WD Models (from SN 21001 to 21396)



Hydraulic Schematic, 4WD Models (after SN 21396)




ORIFICE RELOCATED AFTER SERIAL NUMBER 25201



HS0078L




Hydraulic Schematic, 4WD Models (after SN 21396)



Electrical Schematic, S-65 Ford Engine Models (ANSI / CSA)



Electrical Schematic, S-65 Ford Engine Models (ANSI / CSA)




Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



ES0396R
 FORD DSG 423 ENGINE ONLY


Electrical Schematic, S-65 Ford Engine Models (ANSI / CSA)





Ford DSG-423 EFI Engine
 Ford MSG-425 EFI Engine



Electrical Schematic, S-65
Ford Engine Models, (ANSI / CSA)




Ground Control Box Terminal Strip Wiring Diagram, S-65
Ford Engine Models (ANSI / CSA)



Ground Control Box Terminal Strip Wiring Diagram

S-65 Ford Engine Models (ANSI / CSA)




NOTE: DASHED LINES INDICATE OPTIONS.

ES0396R

Ground Control Box Switch Panel Wiring Diagram S-65 Ford Engine Models (ANSI / CSA)

N M L K J I H G F E D C B A



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS53	FUEL SELECT TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)


TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH

NOTE: DASHED LINES INDICATE OPTIONS.



Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



Ground Control Box Switch Panel Wiring Diagram
S-65 Ford Engine Models (ANSI / CSA)




Platform Control Box Wiring Diagram
S-65 Ford Engine Models (ANSI / CSA)



Platform Control Box Wiring Diagram

S-65 Ford Engine Models (ANSI / CSA)




8

Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



ES0396R

Platform Control Box Switch Panel Wiring Diagram S-65 Ford Engine Models (ANSI / CSA)



COMPONENT INDEX	
C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH CIRCUIT (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS3	FUEL SELECT TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)


TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD

NOTE: DASHED LINES INDICATE OPTIONS.
 ROCKER / STEER OPTION.



ES0396R

**Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine**


Platform Control Box Switch Panel Wiring Diagram
S-65 Ford Engine Models (ANSI / CSA)




Electrical Schematic, S-65/S60 TRAX/S65 TRAX
Deutz D2011L03i Models (ANSI / CSA)




Electrical Schematic, S-65 / S60 TRAX / S65 TRAX Deutz D2011L03i Models (ANSI / CSA)





Electrical Schematic, S-65 / S60 TRAX / S65 TRAX Deutz D2011L03i Models (ANSI / CSA)




Electrical Schematic, S-65 / S60 TRAX / S65 TRAX
Deutz D2011L03i Models (ANSI / CSA)




Electrical Schematic, S-65 / S60 TRAX / S65 TRAX
Deutz TD2011L04i Models (ANSI / CSA)




Electrical Schematic, S-65 / S60 TRAX / S65 TRAX Deutz TD2011L04i Models (ANSI / CSA)




Electrical Schematic, S-65 / S60 TRAX / S65 TRAX Deutz TD2011L04i Models (ANSI / CSA)




Electrical Schematic, S-65 / S60 TRAX / S65 TRAX
Deutz TD2011L04i Models (ANSI / CSA)



**Ground Control Box Terminal Strip Wiring Diagram, S-65
S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)**



Ground Control Box Terminal Strip Wiring Diagram, S-65 S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)




Deutz D2011L03i Engine and Deutz TD2011L04i Engine



ES0186U

Ground Control Box Switch Panel Wiring Diagram, S-65 S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS55	GLOW PLUG TOGGLE SWITCH
TS56	PLATFORM ROTATE TOGGLE SWITCH
TS57	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)


TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE

NOTE: DASHED LINES INDICATE OPTIONS.



ES0186U
Deutz D2011L03i Engine
Deutz TD2011L04i Engine



Ground Control Box Switch Panel Wiring Diagram, S-65
S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)




Platform Control Box Wiring Diagram, S-65
S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)



Platform Control Box Wiring Diagram, S-65

S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)




8

Deutz D2011L03i Engine
Deutz TD2011L04i Engine



Platform Control Box Switch Panel Wiring Diagram, S-65 S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)



COMPONENT INDEX

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH CIRCUIT (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)

TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD


NOTE: DASHED LINES INDICATE OPTIONS.
 ROCKER / STEER OPTION.

ES0186U



Deutz D2011L03i Engine
Deutz TD2011L04i Engine




Platform Control Box Switch Panel Wiring Diagram, S-65
S60 TRAX/S65 TRAX Deutz Engine Models (ANSI / CSA)



Electrical Schematic, S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (ANSI / CSA)




Electrical Schematic, S-65/S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)



Perkins 404-22 Engine




Electrical Schematic, S-65/S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)





Perkins 404-22 Engine




Electrical Schematic, S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (ANSI / CSA)



Ground Control Box Terminal Strip Wiring Diagram, S-65
S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)



Ground Control Box Terminal Strip Wiring Diagram, S-65 S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)



Perkins 404-22 Engine




NOTE: DASHED LINES INDICATE OPTIONS.

ES0193U

Ground Control Box Switch Panel Wiring Diagram, S-65 S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)

N M L K J I H G F E D C B A



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLOW PLUG TOGGLE SWITCH
TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)

TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE

NOTE: DASHED LINES INDICATE OPTIONS.


ES0193U

Perkins 404-22 Engine





TO GROUND CONTROL BOX CONNECTIONS

Ground Control Box Switch Panel Wiring Diagram, S-65
S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)




Platform Control Box Wiring Diagram, S-65
S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)



Platform Control Box Wiring Diagram, S-65

S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)




8

Perkins 404-22 Engine



Platform Control Box Switch Panel Wiring Diagram, S-65 S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)



COMPONENT INDEX

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH CIRCUIT (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)


TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD

NOTE: DASHED LINES INDICATE OPTIONS.
 ROCKER / STEER OPTION.


ES0193U

Perkins 404-22 Engine


Platform Control Box Switch Panel Wiring Diagram, S-65
S60 TRAX/S65 TRAX Perkins Engine Models (ANSI / CSA)



Electrical Schematic, S-60X and S-60XC
Ford Engine Models (ANSI / CSA)




Electrical Schematic, S-60X and S-60XC Ford Engine Models (ANSI / CSA)



Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60X and S-60XC Ford Engine Models (ANSI / CSA)





Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



Electrical Schematic, S-60X and S-60XC
Ford Engine Models (ANSI / CSA)




Ground Control Box Terminal Strip Wiring Diagram
S-60X and S-60XC, Ford Engine Models (ANSI / CSA)




Ground Control Box Terminal Strip Wiring Diagram

S-60X and S-60XC, Ford Engine Models (ANSI / CSA)



Ground Control Box Switch Panel Wiring Diagram S-60X and S-60XC, Ford Engine Models (ANSI / CSA)

N M L K J I H G F E D C B A



COMPONENT INDEX - GROUND CONTROLS


CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS53	FUEL SELECT TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS57	PLATFORM ROTATE TOGGLE SWITCH
TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH



TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH

Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine

Ground Control Box Switch Panel Wiring Diagram
S-60X and S-60XC, Ford Engine Models (ANSI / CSA)




Platform Control Box Wiring Diagram
S-60X and S-60XC, Ford Engine Models (ANSI / CSA)



Platform Control Box Wiring Diagram

S-60X and S-60XC, Ford Engine Models (ANSI / CSA)




8

Ford DSG-423 EFI Engine
 Ford MSG-425 EFI Engine



Platform Control Box Switch Panel Wiring Diagram S-60X and S-60XC, Ford Engine Models (ANSI / CSA)



COMPONENT INDEX

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	LIMIT SWITCH (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
L50	LED - ZONE A
L51	LED - ZONE B
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS3	FUEL SELECT TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH


TS7	PLATFORM ROTATE TOGGLE SWITCH
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS50	ZONE SELECT TOGGLE SWITCH
U13	ALC500 JOYSTICK CONTROLLER CARD

1 ROCKER / STEER OPTION.



ES0396J

Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine


Platform Control Box Switch Panel Wiring Diagram
S-60X and S-60XC, Ford Engine Models (ANSI / CSA)




Electrical Schematic, S-60X and S-60XC
Deutz D2011L03i Models (ANSI/CSA)




Electrical Schematic, S-60X and S-60XC Deutz D2011L03i Models (ANSI/CSA)





Electrical Schematic, S-60X and S-60XC Deutz D2011L03i Models (ANSI/CSA)




Electrical Schematic, S-60X and S-60XC
Deutz D2011L03i Models (ANSI/CSA)




Electrical Schematic, S-60X and S-60XC
DeutzTD2011L04i Models (ANSI/CSA)




Electrical Schematic, S-60X and S-60XC Deutz TD2011L04i Models (ANSI/CSA)





Electrical Schematic, S-60X and S-60XC Deutz TD2011L04i Models (ANSI/CSA)



Electrical Schematic, S-60X and S-60XC
Deutz TD2011L04i Models (ANSI/CSA)




Ground Control Box Terminal Strip Wiring Diagram
S-60X and S-60XC, Deutz Engine Models (ANSI/CSA)



Ground Control Box Terminal Strip Wiring Diagram

S-60X and S-60XC, Deutz Engine Models (ANSI/CSA)




NOTE: DASHED LINES INDICATE OPTION WIRES.

Deutz D2011L03i Engine
 Deutz TD2011L04i Engine



Ground Control Box Switch Panel Wiring Diagram S-60X and S-60XC, Deutz Engine Models (ANSI/CSA)



COMPONENT INDEX - GROUND CONTROLS


CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLOW PLUG TOGGLE SWITCH
TS57	PLATFORM ROTATE TOGGLE SWITCH
TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH



TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE

Deutz D2011L03i Engine
Deutz TD2011L04i Engine

Ground Control Box Switch Panel Wiring Diagram
S-60X and S-60XC, Deutz Engine Models (ANSI/CSA)




Platform Control Box Wiring Diagram
S-60X and S-60XC, Deutz Engine Models (ANSI/CSA)




Platform Control Box Wiring Diagram

S-60X and S-60XC, Deutz Engine Models (ANSI/CSA)



8

Platform Control Box Switch Panel Wiring Diagram S-60X and S-60XC, Deutz Engine Models (ANSI/CSA)



COMPONENT INDEX - GROUND CONTROLS

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	LIMIT SWITCH (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
L50	LED - ZONE A
L51	LED - ZONE B
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH

TS7	PLATFORM ROTATE TOGGLE SWITCH
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
TS50	ZONE SELECT TOGGLE SWITCH
U13	ALC500 JOYSTICK CONTROLLER CARD


NOTE: DASHED LINES INDICATE OPTIONS.
 ROCKER / STEER OPTION.

ES0186U



Deutz D2011L03i Engine
Deutz TD2011L04i Engine



Platform Control Box Switch Panel Wiring Diagram
S-60X and S-60XC, Deutz Engine Models (ANSI/CSA)




Electrical Schematic, S-60X and S-60XC
Perkins Engine Models (ANSI/CSA)



Electrical Schematic, S-60X and S-60XC


Perkins Engine Models (ANSI/CSA)



Perkins 404-22 Engine




Electrical Schematic, S-60X and S-60XC Perkins Engine Models (ANSI/CSA)





Perkins 404-22 Engine




Electrical Schematic, S-60X and S-60XC
Perkins Engine Models (ANSI/CSA)




Ground Control Box Terminal Strip Wiring Diagram
S-60X and S-60XC, Perkins Engine Models (ANSI/CSA)



Ground Control Box Terminal Strip Wiring Diagram S-60X and S-60XC, Perkins Engine Models (ANSI/CSA)



Ground Control Box Switch Panel Wiring Diagram S-60X and S-60XC, Perkins Engine Models (ANSI/CSA)



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLOW PLUG TOGGLE SWITCH
TS57	PLATFORM ROTATE TOGGLE SWITCH
TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH

TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE


NOTE: DASHED LINES INDICATE OPTIONS.

ES0193U



Perkins 404-22 Engine



Ground Control Box Switch Panel Wiring Diagram
S-60X and S-60XC, Perkins Engine Models (ANSI/CSA)




Platform Control Box Wiring Diagram
S-60X and S-60XC, Perkins Engine Models (ANSI/CSA)




Platform Control Box Wiring Diagram

S-60X and S-60XC, Perkins Engine Models (ANSI/CSA)



8

Platform Control Box Switch Panel Wiring Diagram S-60X and S-60XC, Perkins Engine Models (ANSI/CSA)



COMPONENT INDEX - GROUND CONTROLS

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	LIMIT SWITCH (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
L50	LED - ZONE A
L51	LED - ZONE B
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH

TS7	PLATFORM ROTATE TOGGLE SWITCH
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
TS50	ZONE SELECT TOGGLE SWITCH
U13	ALC500 JOYSTICK CONTROLLER CARD


NOTE: DASHED LINES INDICATE OPTIONS.
 ROCKER / STEER OPTION.

ES0193U



Perkins 404-22 Engine




Platform Control Box Switch Panel Wiring Diagram
S-60X and S-60XC, Perkins Engine Models (ANSI/CSA)



Electrical Schematic, S-60 / S-65
Ford Engine Models (CE) (from SN 21001 to 22516)




Electrical Schematic, S-60 / S-65 Ford Engine Models (CE) (from SN 21001 to 22516)



Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60 / S-65 Ford Engine Models (CE) (from SN 21001 to 22516)




Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60 / S-65
Ford Engine Models (CE) (from SN 21001 to 22516)



Electrical Schematic, S-60 / S-65
Ford Engine Models (CE) (after SN 22516)



Electrical Schematic, S-60 / S-65 Ford Engine Models (CE) (after SN 22516)




Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



ES0396R
 1 FORD DSG 423 ENGINE ONLY


Electrical Schematic, S-60 / S-65 Ford Engine Models (CE) (after SN 22516)





Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60 / S-65
Ford Engine Models (CE) (after SN 22516)



Ground Control Box Terminal Strip Wiring Diagram
S-60/S-65 Ford Engine Models (CE) (from SN 21001 to 22516)



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65 Ford Engine Models (CE) (from SN 21001 to 22516)




NOTE: DASHED LINES INDICATE OPTIONS.

ES0396R

Ford DSG-423 EFI Engine and Ford MSG-425 EFI Engine



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65 Ford Engine Models (CE) (after SN 22516)




NOTE: DASHED LINES INDICATE OPTIONS.



ES0396R

Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine

Ground Control Box Terminal Strip Wiring Diagram
S-60 / S-65 Ford Engine Models (CE) (after SN 22516)




Ground Control Box Switch Panel Wiring Diagram
S-60/S-65 Ford Engine Models (CE)



Ground Control Box Switch Panel Wiring Diagram

S-60/S-65 Ford Engine Models (CE)



TO GROUND CONTROL BOX CONNECTIONS

COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A	KS1	KEY SWITCH
CB2	CONTROLS CIRCUIT BREAKER, 15A	L2	LED - CHECK ENGINE
CB3	CIRCUIT BREAKER, 15A (OPTION)	L45	LED - PLATFORM OVERLOAD
CB7	HIGH IDLE CIRCUIT BREAKER	L46	LED - CABLE TENSION
CR1	START RELAY	P1	EMERGENCY STOP BUTTON
CR2	IGNITION / FUEL RELAY	P4	FUNCTION ENABLE SWITCH
CR4	HIGH IDLE RELAY	R2	RESISTOR, 5Ω, TURNABLE ROTATE SPEED
CR5	HORN RELAY	R4	RESISTOR, 7.5Ω, TURNABLE ROTATE SPEED
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)	R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
CR19	TURNTABLE SPEED REDUCTION RELAY	R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
CR23	DRIVE LIGHTS RELAY (OPTION)	TS51	AUXILIARY PUMP TOGGLE SWITCH
CR34	PRIMARY BOOM SPEED REDUCTION RELAY	TS52	ENGINE START TOGGLE SWITCH
H6	PLATFORM OVERLOAD ALARM	TS53	FUEL SELECT TOGGLE SWITCH
		TS54	RPM SELECT TOGGLE SWITCH


TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U33	LOAD SENSE MODULE
U34	TIME DELAY RELAY - 2 SECONDS, 10A

NOTE: DASHED LINES INDICATE OPTIONS.

ES0396R




Platform Control Box Wiring Diagram S-60/S-65 Ford Engine Models (CE)




**Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine**



Platform Control Box Wiring Diagram
S-60/S-65 Ford Engine Models (CE)




Platform Control Box Switch Panel Wiring Diagram
S-60/S-65 Ford Engine Models (CE)



Platform Control Box Switch Panel Wiring Diagram

S-60/S-65 Ford Engine Models (CE)



7

COMPONENT INDEX	
C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH (LIFT / DRIVE OPTION)
CR76	RELAY - LOAD SENSE AUX RECOVERY
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L4	LED - PLATFORM OVERLOAD
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
LS18	PLATFORM OVERLOAD LIMIT SWITCH
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
R20	RESISTOR - 4700Ω
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH

TS3	FUEL SELECT TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD
U35	TIME DELAY RELAY


NOTE: DASHED LINES INDICATE OPTIONS.
 ROCKER / STEER OPTION.

ES0396R


Ford DSG-423 EFI Engine and Ford MSG-425 EFI Engine



Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz D2011L03i Models (CE)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz D2011L03i Models (CE)




ES0186U





Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz D2011L03i Models (CE)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz D2011L03i Models (CE)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz TD2011L04i Models (CE)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz TD2011L04i Models (CE)





Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz TD2011L04i Models (CE)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz TD2011L04i Models (CE)



Ground Control Box Terminal Strip Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models, (CE)



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models (CE)




Deutz D2011L03i Engine and Deutz TD2011L04i Engine



Ground Control Box Switch Panel Wiring Diagram S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models (CE)

N M L K J I H G F E D C B A



TO GROUND CONTROL BOX CONNECTIONS

COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
H6	PLATFORM OVERLOAD ALARM

KS1	KEY SWITCH
L2	LED - CHECK ENGINE
L45	LED - PLATFORM OVERLOAD
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P2	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLOW PLUG TOGGLE SWITCH


TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE
U33	LOAD SENSE MODULE
U34	TIME DELAY RELAY - 2 SECONDS, 10A

NOTE: DASHED LINES INDICATE OPTIONS.


Deutz D2011L03i Engine
Deutz TD2011L04i Engine




Ground Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models (CE)



Platform Control Box Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models (CE)



Platform Control Box Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models (CE)




8

Deutz D2011L03i Engine
Deutz TD2011L04i Engine



Platform Control Box Switch Panel Wiring Diagram S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models (CE)



COMPONENT INDEX	
C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH (LIFT / DRIVE OPTION)
CR76	RELAY - LOAD SENSE AUX RECOVERY
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L4	LED - PLATFORM OVERLOAD
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
LS18	PLATFORM OVERLOAD LIMIT SWITCH
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
R20	RESISTOR - 4700Ω
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH

TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD
U35	TIME DELAY RELAY

NOTE: DASHED LINES INDICATE OPTIONS.


ROCKER / STEER OPTION.

ES0186U



**Deutz D2011L03i Engine
Deutz TD2011L04i Engine**




Platform Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Deutz Engine Models (CE)



Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (CE)



Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)




ES0193U

Perkins 404-22 Engine




Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)




Perkins 404-22 Engine




Electrical Schematic, S-60/S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (CE)



Ground Control Box Terminal Strip Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)




Perkins 404-22 Engine



Ground Control Box Switch Panel Wiring Diagram S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)

N M L K J I H G F E D C B A



TO GROUND CONTROL BOX CONNECTIONS

COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	PLATFORM OVERLOAD ALARM

KS1	KEY SWITCH
L2	LED - CHECK ENGINE
L45	LED - PLATFORM OVERLOAD
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P2	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLOW PLUG TOGGLE SWITCH

TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE
U33	LOAD SENSE MODULE
U34	TIME DELAY RELAY - 2 SECONDS, 10A


NOTE: DASHED LINES INDICATE OPTIONS.

ES0193U


Perkins 404-22 Engine



Ground Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)




Platform Control Box Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)



Platform Control Box Wiring Diagram


S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)



Perkins 404-22 Engine



Platform Control Box Switch Panel Wiring Diagram S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)



COMPONENT INDEX

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH (LIFT / DRIVE OPTION)
CR76	RELAY - LOAD SENSE AUX RECOVERY
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNABLE ROTATE
L1	LED - DRIVE ENABLE
L4	LED - PLATFORM OVERLOAD
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
LS18	PLATFORM OVERLOAD LIMIT SWITCH
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
R20	RESISTOR - 4700Ω
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH

TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD
U35	TIME DELAY RELAY

NOTE: DASHED LINES INDICATE OPTIONS.


ROCKER / STEER OPTION.

ES0193U



Perkins 404-22 Engine




Platform Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX Perkins Engine Models (CE)



Electrical Schematic, S-60 HC (CE)




Electrical Schematic, S-60 HC (CE)




ES0390J


Chassis Wiring Diagram, S-60 HC (CE)




Chassis Wiring Diagram, S-60 HC (CE)




Ground Control Box Terminal Strip Wiring Diagram
S-60 HC (CE) (from SN 21001 to 21287)




Ground Control Box Terminal Strip Wiring Diagram S-60 HC (CE) (from SN 21001 to 21287)





Ground Control Box Terminal Strip Wiring Diagram S-60 HC (CE) (after SN 21287)




Ground Control Box Terminal Strip Wiring Diagram
S-60 HC (CE) (after SN 21287)





Platform Control Box Wiring Diagram S-60 HC (CE)



Platform Control Box Wiring Diagram S-60 HC (CE)




Electrical Schematic, S-60 / S-65
Ford Engine Models (AS) (from SN 21001 to 21629)



Electrical Schematic, S-60 / S-65


Ford Engine Models (AS) (from SN 21001 to 21629)



Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60 / S-65 Ford Engine Models (AS) (from SN 21001 to 21629)





Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



Electrical Schematic, S-60 / S-65
Ford Engine Models (AS) (from SN 21001 to 21629)




Ground Control Box Terminal Strip Wiring Diagram
S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65

Ford Engine Models (AS) (from SN 21001 to 21629)



NOTE: DASHED LINES INDICATE OPTIONS.


ES0396R

HARNES TO SWITCH PANEL

Ground Control Box Switch Panel Wiring Diagram S-60/S-65

Ford Engine Models (AS) (from SN 21001 to 21629)

N M L K J I H G F E D C B A



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS53	FUEL SELECT TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)

TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH

NOTE: DASHED LINES INDICATE OPTIONS.


TO GROUND CONTROL BOX CONNECTIONS

1
2
3
4
5
6
7
8



Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



Ground Control Box Switch Panel Wiring Diagram
S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)




Platform Control Box Wiring Diagram
S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)



Platform Control Box Wiring Diagram

S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)




8

Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



Platform Control Box Switch Panel Wiring Diagram S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)



COMPONENT INDEX	
C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH CIRCUIT (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS3	FUEL SELECT TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)

TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD


NOTE: DASHED LINES INDICATE OPTIONS.
 ROCKER / STEER OPTION.

ES0396R


**Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine**




Platform Control Box Switch Panel Wiring Diagram
S-60/S-65 Ford Engine Models (AS) (from SN 21001 to 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz D2011L03i Models (AS) (from SN 21001 to 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz D2011L03i Models (AS) (from SN 21001 to 21629)





Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz D2011L03i Models (AS) (from SN 21001 to 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz D2011L03i Models (AS) (from SN 21001 to 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz TD2011L04i Models (AS) (from SN 21001 to 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz TD2011L04i Models (AS) (from SN 21001 to 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz TD2011L04i Models (AS) (from SN 21001 to 21629)



Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz TD2011L04i Models (AS) (from SN 21001 to 21629)




Ground Control Box Terminal Strip Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Deutz Engine Models (AS) (from SN 21001 to 21629)




Ground Control Box Terminal Strip Wiring Diagram S-60/S-65

S60 TRAX/S65 TRAX Deutz Engine Models (AS) (from SN 21001 to 21629)



Ground Control Box Switch Panel Wiring Diagram S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (from SN 21001 to 21629)

N M L K J I H G F E D C B A



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLOW PLUG TOGGLE SWITCH
TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)


TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE

NOTE: DASHED LINES INDICATE OPTIONS.



Deutz D2011L03i Engine
Deutz TD2011L04i Engine




Ground Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Deutz Engine Models (AS) (from SN 21001 to 21629)



Platform Control Box Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Deutz Engine Models (AS) (from SN 21001 to 21629)



Platform Control Box Wiring Diagram, S-60/S-65
S60 TRAX/S65 TRAX Deutz Engine Models (AS) (from SN 21001 to 21629)




8

Deutz D2011L03i Engine
 Deutz TD2011L04i Engine



Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (from SN 21001 to 21629)



COMPONENT INDEX	
C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH CIRCUIT (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)

TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD

NOTE: DASHED LINES INDICATE OPTIONS.


ROCKER / STEER OPTION.

ES0186U


Deutz D2011L03i Engine
Deutz TD2011L04i Engine



Platform Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Deutz Engine Models (AS) (from SN 21001 to 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Perkins Engine Models (AS) (from SN 21001 to 21629)



Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX


Perkins Engine Models (AS) (from SN 21001 to 21629)



Perkins 404-22 Engine




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)





Perkins 404-22 Engine



Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Perkins Engine Models (AS) (from SN 21001 to 21629)




Ground Control Box Terminal Strip Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (AS) (from SN 21001 to 21629)



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65


S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)



NOTE: DASHED LINES INDICATE OPTIONS.

ES0193U

Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
KS1	KEY SWITCH

L2	LED - CHECK ENGINE
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLow PLUG TOGGLE SWITCH
TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)

TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE


NOTE: DASHED LINES INDICATE OPTIONS.

ES0193U

Perkins 404-22 Engine




Ground Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (AS) (from SN 21001 to 21629)



Platform Control Box Wiring Diagram


S-60/S-65/S60 TRAX/S65 TRAX

Perkins Engine Models (AS) (from SN 21001 to 21629)




Platform Control Box Wiring Diagram S-60/S-65

S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)



8

Platform Control Box Switch Panel Wiring Diagram S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (from SN 21001 to 21629)



COMPONENT INDEX

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH CIRCUIT (LIFT / DRIVE OPTION)
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)


TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD

NOTE: DASHED LINES INDICATE OPTIONS.
 ROCKER / STEER OPTION.



ES0193U

Perkins 404-22 Engine

Platform Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (AS) (from SN 21001 to 21629)




Electrical Schematic, S-60 / S-65
Ford Engine Models (AS) (from SN 21630 to 22516)



Electrical Schematic, S-60 / S-65


Ford Engine Models (AS) (from SN 21630 to 22516)



Ford DSF-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60 / S-65 Ford Engine Models (AS) (from SN 21630 to 22516)





Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60 / S-65
Ford Engine Models (AS) (from SN 21630 to 22516)



Electrical Schematic, S-60 / S-65
Ford Engine Models (AS) (after SN 22516)




Electrical Schematic, S-60 / S-65 Ford Engine Models (AS) (after SN 22516)



Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60 / S-65 Ford Engine Models (AS) (after SN 22516)





Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine




Electrical Schematic, S-60 / S-65
Ford Engine Models (AS) (after SN 22516)




Ground Control Box Terminal Strip Wiring Diagram
S-60 / S-65 Ford Engine Models (AS) (from SN 21630 to 22516)



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65 Ford Engine Models (AS) (from SN 21630 to 22516)



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65 Ford Engine Models (AS) (after SN 22516)




NOTE: DASHED LINES INDICATE OPTIONS.



ES0396R

**Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine**

Ground Control Box Terminal Strip Wiring Diagram
S-60 / S-65 Ford Engine Models (AS) (after SN 22516)




Ground Control Box Switch Panel Wiring Diagram
S-60 / S-65 Ford Engine Models (AS) (after SN 21629)



Ground Control Box Switch Panel Wiring Diagram S-60 / S-65

Ford Engine Models (AS) (after SN 21629)



TO GROUND CONTROL BOX CONNECTIONS


COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A	KS1	KEY SWITCH	TS57	PLATFORM ROTATE TOGGLE SWITCH
CB2	CONTROLS CIRCUIT BREAKER, 15A	L2	LED - CHECK ENGINE	TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
CB3	CIRCUIT BREAKER, 15A (OPTION)	L45	LED - PLATFORM OVERLOAD	TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
CB7	HIGH IDLE CIRCUIT BREAKER	L46	LED - CABLE TENSION	TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
CR1	START RELAY	P1	EMERGENCY STOP BUTTON	TS62	TURNTABLE ROTATE TOGGLE SWITCH
CR2	IGNITION / FUEL RELAY	P4	FUNCTION ENABLE SWITCH	TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
CR4	HIGH IDLE RELAY	R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED	TS68	LOAD SENSE MODULE
CR5	HORN RELAY	R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED	TS69	TIME DELAY RELAY - 2 SECONDS, 10A
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)	R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED		
CR19	TURNTABLE SPEED REDUCTION RELAY	R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED		
CR23	DRIVE LIGHTS RELAY (OPTION)	TS51	AUXILIARY PUMP TOGGLE SWITCH		
CR34	PRIMARY BOOM SPEED REDUCTION RELAY	TS52	ENGINE START TOGGLE SWITCH		
G6	HOUR METER	TS53	FUEL SELECT TOGGLE SWITCH		
H6	PLATFORM OVERLOAD ALARM	TS54	RPM SELECT TOGGLE SWITCH		

NOTE: DASHED LINES INDICATE OPTIONS.

ES0396R


Platform Control Box Wiring Diagram S-60 / S-65 Ford Engine Models (AS) (after SN 21629)




Ford DSG-423 EFI Engine
Ford MSG-425 EFI Engine



Platform Control Box Wiring Diagram S-60 / S-65
Ford Engine Models (AS) (after SN 21629)




Platform Control Box Switch Panel Wiring Diagram
S-60 / S-65 Ford Engine Models (AS) (after SN 21629)



Platform Control Box Switch Panel Wiring Diagram S-60 / S-65

Ford Engine Models (AS) (after SN 21629)



7

COMPONENT INDEX	
C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH (LIFT / DRIVE OPTION)
CR76	RELAY - LOAD SENSE AUX RECOVERY
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L4	LED - PLATFORM OVERLOAD
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
LS18	PLATFORM OVERLOAD LIMIT SWITCH
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
R20	RESISTOR - 4700Ω
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH

TS3	FUEL SELECT TOGGLE SWITCH
TS4	RPM SELECT TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD
U35	TIME DELAY RELAY

NOTE: DASHED LINES INDICATE OPTIONS.

1 ROCKER / STEER OPTION.


2 LOAD SENSE RECOVERY OPTION

ES0396R


Ford DSG-423 EFI Engine and Ford MSG-425 EFI Engine



Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz D2011L03i Models (AS) (after SN 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz D2011L03i Models (AS) (after SN 21629)




ES0186U





Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz D2011L03i Models (AS) (after SN 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz D2011L03i Models (AS) (after SN 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz TD2011L04i Models (AS) (after SN 21629)





Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Deutz TD2011L04i Models (AS) (after SN 21629)



Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Deutz TD2011L04i Models (AS) (after SN 21629)




Ground Control Box Terminal Strip Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Deutz Engine Models (AS) (after SN 21629)




Ground Control Box Terminal Strip Wiring Diagram S-60/S-65

S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)



NOTE: DASHED LINES INDICATE OPTIONS. ES0186U

Ground Control Box Switch Panel Wiring Diagram S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
H6	PLATFORM OVERLOAD ALARM

KS1	KEY SWITCH
L2	LED - CHECK ENGINE
L45	LED - PLATFORM OVERLOAD
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLOW PLUG TOGGLE SWITCH


TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE
U33	LOAD SENSE MODULE
U34	TIME DELAY RELAY - 2 SECONDS, 10A

NOTE: DASHED LINES INDICATE OPTIONS.



Deutz D2011L03i Engine
Deutz TD2011L04i Engine




Ground Control Box Switch Panel Wiring Diagram S-60/S-65
S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)



Platform Control Box Wiring Diagram, S-60/S-65
S60 TRAX/S65 TRAX
Deutz Engine Models (AS) (after SN 21629)



Platform Control Box Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)




8

Deutz D2011L03i Engine
Deutz TD2011L04i Engine



Platform Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Deutz Engine Models (AS) (after SN 21629)



COMPONENT INDEX

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH (LIFT / DRIVE OPTION)
CR76	RELAY - LOAD SENSE AUX RECOVERY
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNABLE ROTATE
L1	LED - DRIVE ENABLE
L4	LED - PLATFORM OVERLOAD
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
LS18	PLATFORM OVERLOAD LIMIT SWITCH
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
R20	RESISTOR - 4700Ω
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH

TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD
U35	TIME DELAY RELAY

NOTE: DASHED LINES INDICATE OPTIONS.

1 ROCKER / STEER OPTION.


2 LOAD SENSE RECOVERY OPTION

ES0186U



**Deutz D2011L03i Engine
Deutz TD2011L04i Engine**




Platform Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Deutz Engine Models (AS) (after SN 21629)



Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Perkins Engine Models (AS) (after SN 21629)




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX Perkins Engine Models (AS) (after SN 21629)





△ LOAD SENSE RECOVERY OPTION
ES0193U




Electrical Schematic, S-60 / S-65 / S60 TRAX / S65 TRAX
Perkins Engine Models (AS) (after SN 21629)



Ground Control Box Terminal Strip Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (AS) (after SN 21629)



Ground Control Box Terminal Strip Wiring Diagram S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)




NOTE: DASHED LINES INDICATE OPTIONS.

ES0193U

Perkins 404-22 Engine

Ground Control Box Switch Panel Wiring Diagram, S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)



COMPONENT INDEX - GROUND CONTROLS

CB1	ENGINE CIRCUIT BREAKER, 15A
CB2	CONTROLS CIRCUIT BREAKER, 15A
CB3	CIRCUIT BREAKER, 15A (OPTION)
CB7	HIGH IDLE CIRCUIT BREAKER
CR1	START RELAY
CR2	IGNITION / FUEL RELAY
CR4	HIGH IDLE RELAY
CR5	HORN RELAY
CR17	HYDRAULIC OIL COOLER RELAY (OPTION)
CR19	TURNTABLE SPEED REDUCTION RELAY
CR23	DRIVE LIGHTS RELAY (OPTION)
CR34	PRIMARY BOOM SPEED REDUCTION RELAY
G6	HOUR METER
H6	PLATFORM OVERLOAD ALARM

KS1	KEY SWITCH
L2	LED - CHECK ENGINE
L45	LED - PLATFORM OVERLOAD
L46	LED - CABLE TENSION
P1	EMERGENCY STOP BUTTON
P4	FUNCTION ENABLE SWITCH
R2	RESISTOR, 5Ω, TURNTABLE ROTATE SPEED
R4	RESISTOR, 7.5Ω, TURNTABLE ROTATE SPEED
R14	RESISTOR, 10Ω, PRIMARY BOOM UPPER ZONE SPEED
R16	RESISTOR, 7.5Ω, PRIMARY BOOM UP / DOWN SPEED
TS51	AUXILIARY PUMP TOGGLE SWITCH
TS52	ENGINE START TOGGLE SWITCH
TS54	RPM SELECT TOGGLE SWITCH
TS56	GLOW PLUG TOGGLE SWITCH

TS57	PLATFORM ROTATE TOGGLE SWITCH
TS58	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS59	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS61	PRIMARY BOOM UP / DOWN TOGGLE SWITCH
TS62	TURNTABLE ROTATE TOGGLE SWITCH
TS63	PRIMARY BOOM EXTEND / RETRACT TOGGLE SWITCH
U1	IGNITION START MODULE
U33	LOAD SENSE MODULE
U34	TIME DELAY RELAY - 2 SECONDS, 10A


NOTE: DASHED LINES INDICATE OPTIONS.

ES0193U


Perkins 404-22 Engine



Ground Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (AS) (after SN 21629)




Platform Control Box Wiring Diagram S-60/S-65
S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)



Platform Control Box Wiring Diagram S-60/S-65

S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)




8

Perkins 404-22 Engine



Platform Control Box Switch Panel Wiring Diagram S-60/S-65 S60 TRAX/S65 TRAX Perkins Engine Models (AS) (after SN 21629)



COMPONENT INDEX

C1	CAPACITOR, JIB CIRCUIT (S-65 OPTION)
CR13	JIB SELECT RELAY (S-65 OPTION)
CR14	JIB VALVE RELAY (S-65 OPTION)
CR27	RELAY - BRAKE CIRCUIT (LIFT / DRIVE OPTION)
CR30	RELAY - LIMIT SWITCH (LIFT / DRIVE OPTION)
CR76	RELAY - LOAD SENSE AUX RECOVERY
H1	TILT ALARM
JC3	JOYSTICK - DRIVE / STEER
JC7	JOYSTICK - PRIMARY BOOM UP / DOWN, EXTEND / RETRACT, TURNTABLE ROTATE
L1	LED - DRIVE ENABLE
L4	LED - PLATFORM OVERLOAD
L47	LED - CABLE TENSION
L48	LED - TILT ALARM
LS18	PLATFORM OVERLOAD LIMIT SWITCH
P2	EMERGENCY STOP BUTTON
P3	HORN BUTTON
R20	RESISTOR - 4700Ω
TS1	AUXILIARY PUMP TOGGLE SWITCH
TS2	ENGINE START TOGGLE SWITCH

TS4	RPM SELECT TOGGLE SWITCH
TS6	GLOW PLUG TOGGLE SWITCH
TS7	PLATFORM ROTATE TOGGLE SWITCH
TS8	JIB BOOM UP / DOWN TOGGLE SWITCH (S-65 OPTION)
TS9	PLATFORM LEVEL UP / DOWN TOGGLE SWITCH
TS14	DRIVE SPEED TOGGLE SWITCH
TS15	DRIVE ENABLE TOGGLE SWITCH
TS47	GENERATOR (OPTION)
TS48	DRIVE LIGHTS (OPTION)
U13	ALC500 JOYSTICK CONTROLLER CARD
U35	TIME DELAY RELAY

NOTE: DASHED LINES INDICATE OPTIONS.

1 ▷ ROCKER / STEER OPTION.


2 ▷ LOAD SENSE RECOVERY OPTION

ES0193U

Perkins 404-22 Engine



Platform Control Box Switch Panel Wiring Diagram
S-60/S-65/S60 TRAX/S65 TRAX
Perkins Engine Models (AS) (after SN 21629)



California Proposition 65

Warning

The exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Genie North America
Phone 425.881.1800
Toll Free USA and Canada
800.536.1800
Fax 425.883.3475

Genie Australia Pty Ltd.
Phone +61 7 3456 4444
Fax +61 7 3375 1002

Genie China
Phone +86 21 53853768
Fax +86 21 53852569

Genie Singapore
Phone +65 67533544
Fax +65 67533544

Genie Japan
Phone +81 3 6436 2020
Fax +81 3 5445 1231

Genie Korea
Phone +82 2 558 7267
Fax +82 2 558 3910

Genie Brasil
Phone +55 11 4082 5600
Fax +55 22 4082 5630

Genie Holland
Phone +31 183 581 102
Fax +31 183 581 566

Genie Scandinavia
Phone 0046 3157 5154
Fax 0046 3157 5104

Genie France
Phone 0033 237 260 986
Fax 0033 237 260 998

Genie Iberica
Phone 0034 935 725 090
Fax 0034 935 725 080

Genie Germany
Phone 0800 180 9017
Phone 0049 4221 491 821
Fax 0049 4221 491 820

Genie U.K.
Phone 0044 1476 584 333
Fax 0044 1476 584 330

Genie Mexico City
Phone +52 55 5666 5242
Fax +52 55 5666 3241

Distributed By: