


Genie Industries



Genie® S-40

Service Manual



First Edition, First Printing
Part No. 32222



Genie S-40

Important

Read, understand and obey the safety rules and operating instructions in the *Genie S-40 Operator's Manual* before attempting any maintenance or repair procedure.

This service manual covers the Genie S-40 2WD and 4WD models introduced in 1994.

This manual provides detailed scheduled maintenance information for the machine owner and user. It also provides troubleshooting and repair procedures for qualified service professionals.

Basic mechanical, hydraulic and electrical skills are required to perform most procedures. However, several procedures require specialized skills, tools, lifting equipment and a suitable workshop. In these instances, we strongly recommend that maintenance and repair be performed at a Genie dealer service center.

Genie Industries has endeavored to deliver the highest degree of accuracy possible. However, continuous improvement of our products is a Genie policy. Therefore product specifications are subject to change without notice.

Readers are encouraged to notify Genie of errors and send in suggestions for improvement. All communications will be carefully considered for future printings of this and other manuals. Please write to the technical publications team in care of Genie Industries, PO Box 69, Redmond WA 98073-0069 U.S.A.

If you have any questions, call Genie Industries.

Genie North America

Telephone (206) 881-1800
Toll Free 800 536-1800
Fax (206) 883-3475

Genie Europe

Telephone (44) 0636-813943
Fax (44) 0636-815270

Genie Industries

Copyright © 1994 by Genie Industries

First Edition: First Printing, February 1994

Genie® is a registered trademark of Genie Industries. Registered 2009987

These machines comply with ANSI/SIA 92.5-1992.



Printed on recycled paper

Patents Pending

Printed in U.S.A.

Safety Rules



Danger

Failure to obey the instructions and safety rules in this manual, and the *Genie S-40 Operator's Manual* will result in death or serious injury.

Many of the hazards identified in the operator's manual are also safety hazards when maintenance and repair procedures are performed.

Do Not Perform Maintenance Unless:

- ☑ You are trained and qualified to perform maintenance on this machine.
- ☑ You read, understand and obey:
 - manufacturer's instructions and safety rules
 - employer's safety rules and worksite regulations
 - applicable governmental regulations
- ☑ You have the appropriate tools, lifting equipment and a suitable workshop.

SAFETY RULES

Personal Safety

Any person working on or around a machine must be aware of all known safety hazards. Personal safety and the continued safe operation of the machine should be your top priority.



Read each procedure thoroughly. This manual and the decals, on the machine, use signal words to identify the following:

⚠ DANGER

Indicates the presence of a hazard that **will** cause death or serious injury.

⚠ WARNING

Indicates the presence of a hazard that **may** cause death or serious injury.

⚠ CAUTION

Indicates the presence of a hazard that **will** or **may** cause serious injury or damage to the machine.

NOTICE

Indicates special operation or maintenance information.



Be sure to wear protective eye wear and other protective clothing if the situation warrants it.



Be aware of potential crushing hazards such as moving parts, free swinging or unsecured components, and lifting or placing loads. Always wear approved steel-toed shoes.

Workplace Safety



Be sure to keep sparks, flames and lighted tobacco away from flammable and combustible materials like battery gases and engine fuels. Always have an approved fire extinguisher within easy reach.



Be sure that all tools and working areas are properly maintained and ready for use. Keep work surfaces clean and free of debris that could get into machine components and cause damage.



Be sure that your workshop or work area is properly ventilated and well lit.



Be sure any forklift, overhead crane or other lifting or supporting device is fully capable of supporting and stabilizing the weight to be lifted. Use only chains or straps that are in good condition and of ample capacity.



Be sure that fasteners intended for one time use (i.e., cotter pins and self-locking nuts) are not reused. These components may fail if they are used a second time.



Be sure to properly dispose of old oil or other fluids. Use an approved container. Please be environmentally safe.

Table of Contents

Introduction

Important Information	<i>ii</i>
-----------------------------	-----------

Section One **Safety Rules**

General Safety Rules	<i>iii</i>
----------------------------	------------

Section Two **Specifications**

Machine Specifications	2 - 1
Performance Specifications	2 - 2
Hydraulic Specifications	2 - 3
Bolt Torque Specifications	2 - 4
Ford LSG 423 Engine Specifications	2 - 5
Deutz F3L Engine Specifications	2 - 7

Section Three **Scheduled Maintenance Inspections**

Introduction	3 - 1
Table A	3 - 2
Table B	3 - 3
Table C	3 - 5
Table D	3 - 6
Maintenance Inspection Report	3 - 7

Section Four **Scheduled Maintenance Procedures**

Introduction	4 - 1
A-1 Inspect the Manuals	4 - 2
A-2 Inspect the Decals and Placards	4 - 2
A-3 Inspect for Damage, Loose or Missing Parts	4 - 2
A-4 Check the Engine Oil Level	4 - 3
A-5 Check the Engine Coolant Level - Gasoline/LPG Models	4 - 3
A-6 Check for Fuel Leaks	4 - 3
A-7 Check the Hydraulic Oil Level	4 - 4
A-8 Check for Hydraulic Leaks	4 - 4

TABLE OF CONTENTS

Section Four Scheduled Maintenance Procedures, continued

A-9	Check the Tire Pressure	4 - 5
A-10	Test the Platform and Ground Controls	4 - 5
A-11	Test the Auxiliary Power Operation	4 - 6
A-12	Test the Tilt Sensor	4 - 7
A-13	Test the Limit Switches	4 - 7
A-14	Test the Oscillate Axle	4 - 9
A-15	Replace the Engine Oil and Filter - Gasoline/LPG Models	4 - 10
A-16	Replace the Engine Air Filter	4 - 11
B-1	Check the Engine Belt(s)	4 - 12
B-2	Check the Radiator - Gasoline/LPG Models	4 - 12
B-3	Check the Oil Cooler and Cooling Fins - Deutz Diesel Models	4 - 12
B-4	Check the Exhaust System	4 - 13
B-5	Check the Battery	4 - 14
B-6	Check the Hydraulic Tank Filter Condition Indicator	4 - 14
B-7	Inspect the Electrical Wiring	4 - 15
B-8	Inspect the Tires and Wheels	4 - 15
B-9	Confirm the Proper Brake Configuration	4 - 16
B-10	Check the Oil Level in the Torque Hubs	4 - 16
B-11	Check and Adjust the Engine Idle Mixture - Gasoline/LPG Models	4 - 17
B-12	Check and Adjust the Engine RPM	4 - 17
B-13	Test the Key Switch	4 - 19
B-14	Test the Emergency Stop Buttons	4 - 20
B-15	Test the Ground Control Override	4 - 20
B-16	Check the Directional Valve Linkage	4 - 21
B-17	Test the Platform Self-leveling	4 - 21
B-18	Test the Service Horn	4 - 21
B-19	Test the Foot Switch	4 - 22
B-20	Test the Engine Idle Select	4 - 22
B-21	Test the Fuel Select Operation - Gasoline/LPG Models	4 - 23

TABLE OF CONTENTS

Section Four Scheduled Maintenance Procedures, continued

B-22	Test the Drive Enable System	4 - 23
B-23	Test the Drive Brakes	4 - 24
B-24	Test the Drive Speed - Stowed Position	4 - 24
B-25	Test the Alarm Package - Optional Equipment	4 - 25
B-26	Perform Hydraulic Oil Analysis	4 - 25
B-27	Replace the Engine Oil and Filter - Deutz Diesel Models	4 - 26
C-1	Check the Boom Wear Pads	4 - 27
C-2	Check the Turntable Rotation Bearing Bolts	4 - 27
C-3	Check the Free-wheel Configuration	4 - 28
C-4	Grease the Turntable Rotation Bearing and Rotate Gear	4 - 29
C-5	Replace the Torque Hub Oil	4 - 29
C-6	Replace the Hydraulic Tank Filter	4 - 31
C-7	Replace the Drive Loop Hydraulic Filter	4 - 31
C-8	Replace the Diesel Fuel Filter - Deutz Diesel Models	4 - 32
C-9	Replace the Gasoline Fuel Filter - Gasoline/LPG Models	4 - 32
C-10	Replace the PCV Valve - Gasoline/LPG Models	4 - 34
C-11	Clean or Replace the Distributor Cap and Rotor - Gasoline/LPG Models	4 - 34
C-12	Replace the Spark Plugs - Gasoline/LPG Models	4 - 35
C-13	Check and Adjust the Air/LPG Mixture - Gasoline/LPG Models	4 - 36
C-14	Check and Adjust the Ignition Timing - Gasoline/LPG Models	4 - 37
C-15	Check the Engine Valve Clearances - Deutz Diesel Models	4 - 37
D-1	Test or Replace the Hydraulic Oil	4 - 38
D-2	Change or Recondition the Engine Coolant - Gasoline/LPG Models	4 - 39
D-3	Change the Fuel Lines	4 - 41
D-4	Check the Engine Valve Clearance - Gasoline/LPG Models	4 - 42
D-5	Check the Engine Cylinder Compression - Gasoline/LPG Models	4 - 42
D-6	Clean the PCV Hoses and Fittings - Gasoline/LPG Models	4 - 43
D-7	Check the Fuel Injection Pumps and Injectors - Deutz Diesel Models	4 - 44
D-8	Check the Toothed Belt - Deutz Diesel Models	4 - 44
D-9	Replace the Timing Belt - Gasoline/LPG Models	4 - 44

TABLE OF CONTENTS

Section Five	Troubleshooting Flow Charts	
	Introduction	5 - 1
1	Engine Will Not Crank Over	5 - 3
2	Engine Cranks Over But Will Not Start - Gasoline/LPG Models	5 - 5
3	Engine Cranks Over But Will Not Start - Deutz Diesel Models	5 - 12
4	Engine Will Not Start On LPG, But Will Start On Gasoline - Gasoline/LPG Models	5 - 15
5	Engine Will Not Start On Gasoline, But Will Start On LPG - Gasoline/LPG Models	5 - 17
6	Engine High Idle Inoperative - Gasoline/LPG Models	5 - 19
7	Engine Low Idle Inoperative - Gasoline/LPG Models	5 - 21
8	Engine High Idle Inoperative - Deutz Diesel Models	5 - 22
9	Engine Low Idle Inoperative - Deutz Diesel Models	5 - 24
10	All Functions Inoperative, Engine Starts and Runs	5 - 25
11	All Lift and Steer Functions Inoperative, Drive Functions Operational	5 - 26
12	Ground Controls Inoperative, Platform Controls Operate Normally	5 - 27
13	Platform Controls Inoperative, Ground Controls Operate Normally	5 - 28
14	Boom Up Function Inoperative	5 - 29
15	Boom Down Function Inoperative	5 - 31
16	Boom Extend Function Inoperative	5 - 33
17	Boom Retract Function Inoperative	5 - 35
18	Turntable Rotate Function Inoperative	5 - 36
19	Turntable Rotate Left Function Inoperative	5 - 38
20	Turntable Rotate Right Function Inoperative	5 - 39
21	All Platform Leveling Functions Inoperative	5 - 40
22	Platform Level Up Function Inoperative	5 - 41
23	Platform Level Down Function Inoperative	5 - 42

TABLE OF CONTENTS

Section Five	Troubleshooting Flow Charts, continued	
24	Platform Rotate Left Function Inoperative	5 - 43
25	Platform Rotate Right Function Inoperative	5 - 44
26	Oscillate Function Inoperative	5 - 45
27	Steer Left Function Inoperative	5 - 46
28	Steer Right Function Inoperative	5 - 47
29	All Drive Functions Inoperative, All Other Functions Operate Normally	5 - 48
30	Drive Forward Or Reverse Function Inoperative	5 - 51
31	Traction Function Inoperative	5 - 52
32	Machine Will Not Drive At Full Speed	5 - 53
33	Machine Drives At Full Speed With Platform Raised or Extended	5 - 54
34	Drive Enable System Is Malfunctioning	5 - 55
35	Auxiliary Functions Inoperative	5 - 56
Section Six	Schematics	
	Introduction	6-1
	Electrical Symbols Legend	6-2
	Electrical Schematic - Gasoline/LPG Models	6-3
	Ground Control Box Legend - Gasoline/LPG Models	6-5
	Relay Panel Legend - Gasoline/LPG Models	6-6
	Platform Control Box Legend - Gasoline/LPG Models	6-7
	Electrical Schematic - Diesel Models	6-8
	Ground Control Box Legend - Diesel Models	6-10
	Platform Control Box Legend - Diesel Models	6-11
	Hydraulic Symbols Legend	6-12
	2WD Hydraulic Schematic - Non-Oscillating Axle	6-13
	2WD Hydraulic Schematic - Oscillating Axle	6-14
	4WD Hydraulic Schematic	6-15

TABLE OF CONTENTS

Section Seven Repair Procedures

Introduction	7 - 1
--------------------	-------

Platform Controls

1-1 Joystick Controllers	7 - 2
1-2 Horsepower Limiter Board	7 - 5
1-3 Foot Switch	7 - 7
1-4 Resistors	7 - 7
1-5 Toggle Switches	7 - 8

Platform Components

2-1 Platform	7 - 9
2-2 Platform Leveling Slave Cylinder	7 - 9
2-3 Platform Rotator	7 - 10

Boom Components

3-1 Plastic Cable Track	7 - 12
3-2 Boom	7 - 12
3-3 Boom Lift Cylinder	7 - 14
3-4 Extension Cylinder	7 - 15
3-5 Platform Leveling Master Cylinder	7 - 16

Turntable Covers

4-1 Turntable Covers	7 - 17
----------------------------	--------

Deutz Engine F3L 1011

5-1 RPM Adjustment	7 - 18
5-2 Flex Plate	7 - 18
5-3 Oil Temperature and Oil Pressure Gauges	7 - 18

Ford LSG-423 Engine

6-1 Governor Actuator	7 - 19
6-2 Choke Adjustments	7 - 20
6-3 Timing Adjustment	7 - 21
6-4 Carburetor Adjustment	7 - 21
6-5 RPM Adjustment	7 - 21
6-6 Flex Plate	7 - 21

TABLE OF CONTENTS

Section Seven Repair Procedures, Ford LSG-423 Engine, continued

6-7 Water Temperature and Oil Pressure Gauges 7 - 22

6-8 Vacuum Switch 7 - 22

Ground Controls

7-1 Control Relays 7 - 23

7-2 Toggle Switches, See 1-5, *Toggle Switches* 7 - 8

7-3 Wago® Components 7 - 25

7-4 Resistor 7 - 26

7-5 Power Relay 7 - 26

Hydraulic Pumps

8-1 Lift/Steer Pump 7 - 27

8-2 Drive Hydraulic Pump 7 - 28

Function Manifold

9-1 Function Manifold Components 7 - 30

9-2 Valve Adjustments - Function Manifold 7 - 32

Fuel and Hydraulic Tanks

10-1 Hydraulic Tank 7 - 35

10-2 Fuel Tank 7 - 36

Turntable Rotation Components

11-1 Rotation Hydraulic Motor 7 - 37

11-2 Turntable Rotation Manifold Components 7 - 38

2WD Steering Axle Components

12-1 Yoke and Hub 7 - 39

12-2 Steering Cylinders 7 - 40

12-3 Tie Rod 7 - 41

4WD Steering Axle Components

13-1 Yoke and Hub 7 - 42

13-2 Steering Cylinders 7 - 43

13-3 Tie Rod 7 - 43

TABLE OF CONTENTS

Section Seven Repair Procedures, continued**Oscillating Axle Components**

14-1 Oscillating Axle Cylinders	7 - 44
---------------------------------------	--------

Steer and Oscillate Manifolds

15-1 Oscillate Manifold Components	7 - 45
15-2 Valve Adjustments	7 - 46
15-3 Directional Valve Manifold Components	7 - 47
15-4 Steer Manifold Components	7 - 49

Non-steering Axle Components

16-1 Drive Motor	7 - 50
16-2 Torque Hub	7 - 50

2WD Drive Manifold

17-1 2WD Drive Manifold Components	7 - 52
17-2 Valve Adjustments	7 - 54

4WD Drive Manifold

18-1 4WD Drive Manifold Components	7 - 56
18-2 Valve Adjustments	7 - 58

Specifications

Machine Specifications

Stowed dimensions	2WD/RT	4WD/RT
Length	23 ft 11 in 7.28 m	23 ft 11 in 7.28 m
Width	7 ft 6 in 2.29 m	7 ft 6 in 2.29 m
Height	8 ft 2 in 2.48 m	8 ft 2 in 2.48 m
Weight	11,650 lbs 5,284 kg	11,650 lbs 5,284 kg
Ground clearance	12 1/2 in 31.8 cm	12 1/2 in 31.8 cm

Operational dimensions

Maximum platform height	40 ft 12.2 m	40 ft 12.2 m
Maximum horizontal reach	31 ft 8 in 9.64 m	31 ft 8 in 9.64 m
Maximum turntable tailswing	34 in 86.4 cm	34 in 86.4 cm
Wheelbase	7 ft 3 in 2.2 m	7 ft 3 in 2.2 m
Minimum turning circle, outside	15 ft 8 in 4.77 m	15 ft 8 in 4.77 m
Minimum turning circle, inside	6 ft 8 in 2.02 m	6 ft 8 in 2.02 m
Turntable rotation	continuous	continuous
Platform rotation	160°	160°

Platform dimensions	6 ft (Standard)	8 ft (Optional)
Length	6 ft 1.83 m	8 ft 2.44 m
Width	30 in 76.2 cm	36 in 91.4 cm
Maximum capacity	500 lbs 227 kg	500 lbs 227 kg

Tires and wheels	2WD Front Tires Only	2WD Rear 4WD Front & Rear
Tire size	12.5L-16SL	12-16.5 NHS
Tire ply rating	12	8
Tire contact area	88 sq in 568 sq cm	57 sq in 368 sq cm
Overall tire diameter	33.7 in 85.6 cm	33.2 in 84.3 cm
Tire pressure	45 psi 3.10 bar	45 psi 3.10 bar
Wheel diameter	16 in 40.6 cm	16 1/2 in 41.9 cm
Wheel width	10 in 25.4 cm	9.75 in 24.7 cm
Wheel lugs	8 @ 5/8 -18	9 @ 5/8 -18
Lug nut torque	125 ft-lbs 169.5 Nm	125 ft-lbs 169.5 Nm

Fluid capacities

Fuel tank	30 gallons	114 liters
LPG tank	33.5 pounds	15.2 kg
Hydraulic tank	45 gallons	170 liters
Hydraulic system (including tank)	50 gallons	189 liters
Drive torque hub	17 fl oz	0.51 liters
Turntable rotation torque hub	8 fl oz	0.24 liters

Continuous improvement of our products is a Genie policy. Product specifications are subject to change without notice.

PERFORMANCE SPECIFICATIONS

Performance Specifications

Drive speeds, maximum	2WD	4WD
Boom stowed	4.0 mph	3.5 mph
Gasoline/LPG models	6.4 km/h	5.6 km/h
	40 ft/6.8 sec	40 ft/7.8 sec
	12.2 m/6.8 sec	12.2 m/7.8 sec
Boom stowed	3.5 mph	3 mph
Deutz diesel models	5.6 km/h	4.8 km/h
	40 ft/7.8 sec	40 ft/9.1 sec
	12.2 m/7.8 sec	12.2 m/9.1 sec
Boom raised or extended	0.68 mph	0.68 mph
All models	1.1 km/h	1.1 km/h
	40 ft/40 sec	40 ft/40 sec
	12.2 m/40 sec	12.2 m/40 sec
Gradeability (boom stowed)	2WD	4WD
Rough terrain	30%	40%

Boom function speeds, maximum from platform controls	
Boom up	40 to 60 seconds
Boom down	50 to 80 seconds
Boom extend	35 to 65 seconds
Boom retract	40 to 70 seconds
Turntable rotate - 360°	70 to 110 seconds
Platform rotate - 160°	8 to 20 seconds
Platform level up	25 to 50 seconds
Platform level down	15 to 35 seconds

HYDRAULIC SPECIFICATIONS



Hydraulic Specifications

Hydraulic fluid		Dexron II equivalent
Drive pump		
Type: bi-directional variable displacement piston pump		
Displacement - 2500 rpm	0 to 31.6 gallons per minute 0 to 119.6 liters per minute	
Maximum drive pressure	3500 psi 241.3 bar	
Charge pressure		
neutral position	360 psi	25 bar
drive position	250 psi	17 bar
Medium pressure filter	3 micron	
Medium pressure filter bypass pressure	50 psi 3.4 bar	
Drive manifold		
Brake relief pressure	250 psi 17.2 bar	
4WD front motor flow regulators	2.5 to 8 gallons per minute 9.4 to 30.2 liters per minute	
4WD rear motor flow regulators	5 to 15 gallons per minute 18.9 to 56.7 liters per minute	
2WD rear motor flow regulators	8 to 22 gallons per minute 30.2 to 83.2 liters per minute	
Front drive motors		4WD models
Displacement per revolution	1.52 cu in 25 cc	
Rear drive motors		
Displacement per revolution	2.13 cu in	35 cc

Function pump	
Type: pressure balanced gear	
Displacement - static	0.98 cu in 16 cc
Displacement - 2550 rpm	10.8 gallons per minute 0 to 40.8 liters per minute
Hydraulic tank circuit return line filter	10 micron with 25 psi (1.7 bar) bypass
Function manifold	
Function relief valve pressure	2600 psi 179 bar
Boom down relief valve pressure	2200 psi 152 bar
Boom extend	1950 psi 134 bar
Steer/oscillate flow regulator	3.5 gallons per minute 13.2 liters per minute
Steer regulator	2 gallons per minute 7.6 liters per minute
Boom retract pressure	2600 psi 179 bar
Oscillate cylinder pressure	900 psi 62 bar
Auxiliary pump	
Type: fixed displacement gear pump	
Displacement - static	0.152 cu in 2.5 cc
Displacement	1.4 gallons per minute 5.3 liters per minute
Auxiliary pump relief pressure	2500 psi 176 bar

BOLT TORQUE SPECIFICATIONS

Bolt Torque Specifications

Size	Threads	SAE Grade 5 Bolts 			SAE Grade 8 Bolts 		
		Torque - Dry inch-pounds	Torque - Dry foot-pounds	Torque - Dry Newton meters	Torque - Dry inch-pounds	Torque - Dry foot-pounds	Torque - Dry Newton meters
No. 10	24	43		5	60		7
	32	49		6	68		8
1/4 inch	20	96		11	144		16
	28	120		14	168		19
5/16 inch	18		17	23		25	34
	24		19	28		25	34
3/8 inch	16		30	41		45	61
	24		35	48		50	68
7/16 inch	14		50	68		70	95
	20		55	75		80	109
1/2 inch	13		75	102		110	149
	20		90	122		120	163
9/16 inch	12		110	149		150	204
	18		120	163		170	231
5/8 inch	11		150	204		220	298
	18		170	231		240	326
3/4 inch	10		260	353		380	515
	16		300	407		420	570
7/8 inch	9		430	583		600	814
	14		470	637		660	895
1 inch	8		640	868		900	1221
	12		700	949		1000	1356

Torque specification for lubricated bolts is 25% less than dry torque specification for bolt size.

FORD ENGINE LSG-423 SPECIFICATIONS

Ford Engine LSG-423

Displacement	140 cu in 2.3 liters
Number of cylinders	4
Bore & stroke	3.780 x 3.126 inches 96 x 79.4 mm
Horsepower	63 @ 4000 rpm
Firing order	1 - 3 - 4 - 2
Low idle	1600 rpm
High idle	2500 rpm
Governor	electronic
Compression ratio	9.5:1
Compression pressure (approx.)	150 to 175 psi 10 to 12 bar
Pressure (psi) of lowest cylinder must be at least 75% of highest cylinder	
Valve clearances	0.040 to 0.050 inches 1.0 to 1.3 mm
Lubrication system	
Oil pressure (operating temp. @ 2600 rpm)	40 to 60 psi 2.75 to 4.1 bar
Oil capacity (including filter)	5 quarts 4.7 liters
Oil viscosity requirements	
Temperature below 60°F / 15.5°C	5W-30
-10°F to 90°F / -23°C to 32°C	10W-30
Temperature above -10°F / -23°C	10W-40 to 10W-50
Temperature above 25°F / -4°C	20W-40 or 20W-50
Use oils meeting API classification SF (labeled SF/CC or SF/CD) as they offer improved wear protection.	

Starter motor	
Normal engine cranking speed	110 rpm
Current draw, normal load	150A
Current draw, maximum load	460A
Current draw, no load	70A
Maximum circuit voltage drop while starting (normal temperature)	0.5V DC
Brush length, new	0.50 in 12.7 mm
Brush length wear limit	0.25 in 6.35 mm
Brush spring tension	40 ounces 11 Newtons
Bolt torque through brush	55 to 75 inch-pounds 6 to 8.5 Nm
Brush mounting bolt torque	15 to 20 foot-pounds 20 to 27 Nm
Maximum commutator run-out	0.005 inches 0.127 mm
Battery	
Type	12V, Group 31
Quantity	1
Cold cranking ampere	1000A
Reserve capacity @ 25A rate	200 minutes
Fuel pump	
Static pressure	5 to 7 psi 0.34 to 0.48 bar
Minimum volume flow (in 25 seconds)	1 pint 473 cc

FORD ENGINE LSG-423 SPECIFICATIONS

Ignition System

Ignition spark advance	10° BTDC
Ignition coil primary resistance	1.13 to 1.25Ω @ 75°F / 24°C
Ignition coil secondary resistance	7700 to 9300Ω @ 75°F / 24°C
Spark plug type	Motorcraft AWSF-52
Spark plug gap	0.042 to 0.046 inches 1.07 to 1.18 mm

Engine coolant

Capacity	11.5 quarts 10.9 liters
----------	----------------------------

Alternator

Output	35A, 14.5V
--------	------------

Fan belt deflection	$\frac{3}{8}$ to $\frac{1}{2}$ inch 9 to 12 mm
----------------------------	---

Bolt torque specifications

Bolt description (size)	torque ft-lbs	torque Nm
Auxiliary shaft gear bolt (M-10)	28 to 40	38 to 54
Auxiliary shaft thrust plate bolt (M-6)	6 to 9	8 to 12
Timing belt tensioner pivot bolt (M-10)	28 to 40	38 to 54
Timing belt tensioner adjusting bolt (M-8)	14 to 21	19 to 28
Camshaft gear bolt (M-12)	50 to 71	68 to 96
Camshaft thrust plate bolt (M-6)	6 to 9	8 to 12
Carburetor to spacer stud (M-8)	7.5 to 15	10 to 20
Carburetor spacer to manifold bolt (M-8)	10 to 14	14 to 19
Crankshaft damper bolt (M-14)	103 to 133	140 to 180
Cylinder head bolt (M-12): torque in sequence		
first step	50 to 60	68 to 81
second step	80 to 90	108 to 122

Bolt torque specifications

Bolt description (size)	torque ft-lbs	torque Nm
Distributor clamp bolt (M-10)	14 to 21	19 to 28
Distributor vacuum tube to manifold adaptor	5 to 8	7 to 11
Exhaust manifold to cylinder head bolt or nut (M-10): torque in sequence		
first step	14 to 19	19 to 26
second step	20 to 30	27 to 41
Flywheel to crankshaft bolt (M-10)	56 to 64	76 to 87
Fuel pump to cylinder block (M-8)	14 to 21	19 to 28
Intake manifold to cylinder head bolt or nut (M-8)	14 to 21	19 to 28
Oil pressure sending unit to block	8 to 18	11 to 24
Oil pan drain plug to pan (M-14)	15 to 25	20 to 34
Oil pan to block (M-6)	10 to 13.5	14 to 18
Oil filter insert to block	20 to 35	27 to 47
Rocker arm cover to cylinder head (M-6)	5 to 8	7 to 11
Spark plug to cylinder head (M-14)	5 to 10	7 to 14
Temperature sending unit to block (M-14)	8 to 18	11 to 24
Water jacket drain plug to block	23 to 28	31 to 38
Water pump to block bolt (M-8)	14 to 21	19 to 28
Auxiliary shaft cover bolt (M-6)	6 to 9	8 to 12
Water outlet connection bolt (M-8)	14 to 21	19 to 28
Cylinder front cover bolt (M-6)	6 to 9	8 to 12
Inner timing belt cover stud (M-8)	14 to 21	19 to 28
Outer timing belt cover bolt (M-6)	6 to 9	8 to 12

DEUTZ ENGINE F3L 1011 SPECIFICATIONS

Deutz Engine F3L 1011

Displacement	125.02 cu in 2.049 liters
Number of cylinders	3
Bore and stroke	3.58 x 4.13 inches 91 x 105 mm
Horsepower	36 @ 2300 rpm
Firing order	1 - 2 - 3
Compression ratio	18.5:1
Compression pressure	362 to 435 psi 25 to 30 bar
Pressure (psi) of lowest cylinder must be at least 85% of highest cylinder	
Low idle	1300 rpm
High idle	2300 rpm
Governor	centrifugal mechanical
Valve clearance, cold	
Intake	0.012 in 0.3 mm
Exhaust	0.020 in 0.5 mm
Lubrication system	
Oil pressure	26 to 87 psi 1.8 to 6.0 bar
Oil capacity (including filter)	8.5 quarts 8 liters
Oil viscosity requirements	
Temperature below 60°F / 15.5°C (synthetic)	5W-30
-10°F to 90°F / -23°C to 32°C	10W-40
Temperature above -4°F / -34°C	15W-40
Engine oil should have properties of API classification CC/SE, CD/SE, CC/SF or CD/SF grades.	
Injection system	
Injection pump make	OMAP

Injection pump pressure	4351 psi 300 bar	
Injector opening pressure	3626 psi 250 bar	
Fuel requirement	diesel number 2-D	
Alternator output	55A, 14V	
Starter motor		
Current draw, no load	90A	
Brush length, new	0.7480 in 19 mm	
Brush length, minimum	0.5 in 12.7 mm	
Battery		
Type	12V, Group 31	
Quantity	1	
Cold cranking ampere	1000A	
Reserve capacity @ 25A rate	200 minutes	
Fan belt deflection	$\frac{3}{8}$ to $\frac{1}{2}$ inch 9 to 12 mm	
Bolt tightening specifications		
Bolt description (size, grade)	torque ft-lbs	torque Nm
Camshaft/thrust bearing bolt (M-8 x 35, 8.8)	15 to 18	20 to 24
Rocker arm bolts (M-8 x 45, 8.8)	15 to 18	20 to 24
Rocker arm set screw nut	15 to 18	20 to 24
Cylinder head cover	6 to 7	8 to 10
Blower rotor nut (M-17 Valeo or M-18 Bosch)	33 to 41	45 to 55
Blower carrier bolts (M-8 x 50 Torx, 8.8)	15 to 18	20 to 24
V-belt pulley bolts (M-10 x 16, 8.8)	28 to 34	38 to 46

DEUTZ ENGINE F3L 1011 SPECIFICATIONS

Bolt tightening specifications, continued		
Bolt description (size, grade)	torque ft-lbs	torque Nm
Idler pulley/V-belt pulley bolt (M-10 x 25, 8.8)	27 to 32	36 to 44
Idler pulley for toothed belt (M-10 x 50, 8.8)	30 to 36	41 to 49
Oil pump bolts (M-8 x 35 Torx)	15 to 18	20 to 24
Oil filter bracket bolts (M-8 x 20 Torx, 8.8)	7 to 8	9 to 11
Oil intake housing bolts (M-8 x 75 Torx)	15 to 18	20 to 24
Fuel pump bolts	15 to 18	20 to 24
Injection pump bolts	15 to 18	20 to 24
Injector cap nut	30 to 37	40 to 50
Injector fastening bolt	15 to 18	20 to 24
Injection line	10 to 12	13.5 to 16.5
Air intake manifold bolts (M-8 x 30, 8.8)	15 to 18	20 to 24
Air intake manifold, 3-hole flange bolts (M-8 x 35 Torx, 8.8)	15 to 18	20 to 24
Exhaust manifold bolts (M-10 x 30 Torx, 10.9)	27 to 32	36 to 44
Starter fastening bolts (M-10 x 28, 8.8)	28 to 34	38 to 46
Starter carrier bolts (M-12 x 28, 8.8)	50 to 60	68 to 82
Oil pan bolts (M-8 x 16 Torx, 8.8)	15 to 18	20 to 24
Oil drain bolts	37 to 44	50 to 60

		torque ft-lbs	torque Nm		
Oil thermostat housing screw plug (M-38 x 1.5)		37 to 44		50 to 60	
Oil thermostat housing bolts (M-6 x 35 Torx, 8.8)		5.5 to 7		7.5 to 9	
Oil thermostat housing bolts (M-6 x 80 Torx, 8.8)		5.5 to 7		7.5 to 9	
Oil thermostat housing bolts (M-6 x 105 Torx, 8.8)		14 to 16		19 to 22	
Valve plunger housing bolts (M-8 x 30 Torx, 8.8)		14 to 16		19 to 22	
Alternator nuts (M-5)		3		4	
Fuel bracket bolts (M-8 x 20, 8.8)		15		20	
Adapter housing bolts (M-12 x 35, 10.9 or M-12 x 75, 10.9)		70 to 77		95 to 105	
		first step tightening torque	second step tightening angles		
		ft-lbs	Nm	1st	2nd
Main bearing bolts		37	50	60°	45°
Big end bolts		22	30	60°	60°
Flywheel bolts		22	30	60°	30°
Cylinder head studs	step 1	22	30		
	step 2	59	80		
	step 3	118	160	120°	NA
Camshaft/central bolt		22	30	150°	NA
Crankshaft/central bolt		96	130	210°	NA

Scheduled Maintenance Inspections



Observe and Obey:

- ☑ Maintenance inspections shall be completed by a person trained and qualified on the maintenance of this machine.
- ☑ Scheduled maintenance inspections shall be completed daily, quarterly, annually and every 2 years as specified on the *Maintenance Inspection Report*.

⚠ WARNING Failure to properly complete each inspection when required may cause death, serious injury or substantial damage.

- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating machine.
- ☑ Keep records on all inspections for three years.
- ☑ Machines that have been out of service for a period longer than 3 months must complete the quarterly inspection.

About This Section

The Schedule

There are four types of maintenance inspections that must be performed according to a schedule—daily, quarterly, annual, two year. To account for repeated procedures, the *Maintenance Tables* and the *Maintenance Inspection Report* have been divided into four subsections—A, B, C, D. Use the following chart to determine which group(s) of procedures are required to perform a scheduled inspection.

Inspection	Table or Checklist
Daily	A
Quarterly	A + B
Annual	A + B + C
Two year	A + B + C + D

Maintenance Tables

The maintenance tables contained in this section provide summary information on the specific physical requirements for each inspection.

Complete step-by-step instructions for each scheduled maintenance procedure are provided in section 4, *Scheduled Maintenance Procedures*.




Maintenance Inspection Report

The maintenance inspection report contains checklists for each type of scheduled inspection.

Make copies of the *Maintenance Inspection Report* to use for each inspection. Store completed forms for three years.

Maintenance Tables

Table A

		Tools are required	New parts required	Warm engine required	Cold engine required	Dealer service suggested
A-1	Inspect the Manuals					
A-2	Inspect the Decals and Placards					
A-3	Inspect for Damage, Loose or Missing Parts					
A-4	Check the Engine Oil Level					
A-5	Check the Engine Coolant Level - Gasoline/LPG Models					
A-6	Check for Fuel Leaks					
A-7	Check the Hydraulic Oil Level					
A-8	Check for Hydraulic Leaks					
A-9	Check the Tire Pressure					
A-10	Test the Platform and Ground Controls					
A-11	Test the Auxiliary Power Operation					
A-12	Test the Tilt Sensor					
A-13	Test the Limit Switches					
A-14	Test the Oscillate Axle (oscillating axle equipped models)					

MAINTENANCE TABLES

Table A, continued
































		Tools are required	New parts required	Warm engine required	Cold engine required	Dealer service suggested
Every 100 hours, perform the following two engine maintenance procedures.						
A-15	Replace the Engine Oil and Filter - Gasoline/LPG Models					
A-16	Replace the Engine Air Filter					

Table B

B-1	Check the Engine Belt(s)					
B-2	Check the Radiator - Gasoline/LPG Models					
B-3	Check the Oil Cooler and Cooling Fins - Deutz Diesel Models					
B-4	Check the Exhaust System					
B-5	Check the Battery					
B-6	Check the Hydraulic Tank Filter Condition Indicator					
B-7	Inspect the Electrical Wiring					
B-8	Inspect the Tires and Wheels (including lug nut torque)					
B-9	Confirm the Proper Brake Configuration					
B-10	Check the Oil Level in the Torque Hubs					
B-11	Check and Adjust the Engine Idle Mixture - Gasoline/LPG Models					
B-12	Check and Adjust the Engine RPM					










































MAINTENANCE TABLES

Table B, continued

		Tools are required	New parts required	Warm engine required	Cold engine required	Dealer service suggested
B-13	Test the Key Switch					
B-14	Test the Emergency Stop Buttons					
B-15	Test the Ground Control Override					
B-16	Check the Directional Valve Linkage					
B-17	Test the Platform Self-leveling					
B-18	Test the Service Horn					
B-19	Test the Foot Switch					
B-20	Test the Engine Idle Select					
B-21	Test the Fuel Select Operation - Gasoline/LPG Models					
B-22	Test the Drive Enable System					
B-23	Test the Drive Brakes					
B-24	Test the Drive Speed - Stowed Position					
B-25	Test the Alarm Package - Optional Equipment					
B-26	Perform Hydraulic Oil Analysis See D-1 <i>Test or Replace the Hydraulic Oil</i>					
Every 500 hours, perform the following engine maintenance procedure.						
B-27	Replace the Engine Oil and Filter - Deutz Diesel Models					
























MAINTENANCE TABLES

Table C

		Tools are required	New parts required	Warm engine required	Cold engine required	Dealer service suggested
C-1	Check the Boom Wear Pads					
C-2	Check the Turntable Rotation Bearing Bolts					
C-3	Check the Free-wheel Configuration					
C-4	Grease the Turntable Rotation Bearing and Rotate Gear					
C-5	Replace the Torque Hub Oil					
C-6	Replace the Hydraulic Tank Filter					
C-7	Replace the Drive Loop Hydraulic Filter					
C-8	Replace the Diesel Fuel Filter - Deutz Diesel Models					
C-9	Replace the Gasoline Fuel Filter - Gasoline/LPG Models					
C-10	Replace the PCV Valve - Gasoline/LPG Models					
C-11	Clean or Replace the Distributor Cap and Rotor - Gasoline/LPG Models					
C-12	Replace the Spark Plugs - Gasoline/LPG Models					
C-13	Check and Adjust the Air/LPG Mixture - Gasoline/LPG Models					
C-14	Check and Adjust the Ignition Timing - Gasoline/LPG Models					
C-15	Check the Engine Valve Clearances - Deutz Diesel Models					

MAINTENANCE TABLES

Table D

		Tools are required	New parts required	Warm engine required	Cold engine required	Dealer service suggested
D-1	Test or Replace the Hydraulic Oil					
D-2	Change or Recondition the Engine Coolant - Gasoline/LPG Models					
D-3	Change the Fuel Lines					
D-4	Check the Engine Valve Clearance - Gasoline/LPG Models					
D-5	Check the Engine Cylinder Compression - Gasoline/LPG Models					
D-6	Clean the PCV Hoses and Fittings - Gasoline/LPG Models					
D-7	Check the Fuel Injection Pumps and Injectors - Deutz Diesel Models					
D-8	Check the Toothed Belt - Deutz Diesel Models					
D-9	Replace the Timing Belt - Gasoline/LPG Models					

Maintenance Inspection Report

Model
Serial number
Date
Hour meter
Machine owner
Inspected by (print)
Inspector signature
Inspector title
Inspector company
Instructions
<ul style="list-style-type: none"> Make copies of this page to use for each inspection. Select the appropriate checklist(s) for the type of inspection to be performed.
<input type="checkbox"/> Daily Inspection: A
<input type="checkbox"/> Quarterly Inspection: A+B
<input type="checkbox"/> Annual Inspection: A+B+C
<input type="checkbox"/> 2 Year Inspection: A+B+C+D
<ul style="list-style-type: none"> Place a check in the appropriate box after each inspection procedure is completed. Use the maintenance tables in this section and the step-by-step procedures in section 4 to learn how to perform these inspections. If any inspection receives an "N", tag and remove the machine from service, repair and re-inspect it. After repair, place a check in the "R" box.
Legend
Y = yes, acceptable
N = no, remove from service
R = repaired

Comments	Y	N	R
Checklist A			
Refer to Table A			
A-1 Manuals			
A-2 Decals and placards			
A-3 Damage, loose or missing parts			
A-4 Engine oil level			
A-5 Engine coolant-gasoline			
A-6 Fuel leaks			
A-7 Hydraulic oil level			
A-8 Hydraulic leaks			
A-9 Tire pressure			
A-10 Platform and ground controls			
A-11 Auxiliary power			
A-12 Tilt sensor			
A-13 Limit switches			
A-14 Oscillate Axle			
Perform every 100 hours:			
A-15 Replace engine oil and filter-gasoline			
A-16 Replace air filter			
Checklist B	Y	N	R
Refer to Table B			
B-1 Engine belt(s)			
B-2 Engine radiator			
B-3 Oil cooler and fins-Deutz			
B-4 Exhaust system			
B-5 Battery			
B-6 Hydraulic tank filter			
B-7 Electrical wiring			
B-8 Tires and wheels			
B-9 Brake configuration			
B-10 Torque hub oil level			
B-11 Idle mixture-gasoline			
B-12 Engine RPM			
B-13 Key Switch			
B-14 Emergency Stop			
B-15 Ground control override			
B-16 Valve linkage			
B-17 Platform leveling			

	Y	N	R
B-18 Service horn			
B-19 Foot switch			
B-20 Engine idle select			
B-21 Fuel select-gasoline			
B-22 Drive enable system			
B-23 Drive brakes			
B-24 Drive speed-stowed			
B-25 Alarm package			
B-26 Hydraulic oil analysis			
Perform every 500 hours:			
B-27 Replace engine oil and filter-Deutz			
Checklist C	Y	N	R
Refer to Table C			
C-1 Boom wear pads			
C-2 Turntable bearing bolts			
C-3 Free-wheel configuration			
C-4 Grease rotation bearing			
C-5 Torque hub oil			
C-6 Hydraulic tank filter			
C-7 Drive loop hydraulic filter			
C-8 Fuel filter-diesel			
C-9 Fuel filter-gasoline			
C-10 PCV valve-gasoline			
C-11 Distributor cap-gasoline			
C-12 Spark plugs-gasoline			
C-13 Air/LPG mixture			
C-14 Ignition timing-gasoline			
C-15 Valves-Deutz			
Checklist D	Y	N	R
Refer to Table D			
D-1 Hydraulic oil			
D-2 Engine coolant-gasoline			
D-3 Change fuel lines			
D-4 Valves-gasoline			
D-5 Compression-gasoline			
D-6 PCV hoses-gasoline			
D-7 Fuel injection-Deutz			
D-8 Toothed belt-Deutz			
D-9 Timing belt-Ford			

This page intentionally left blank.

Scheduled Maintenance Procedures



Observe and Obey:

- ☑ Maintenance inspections shall be completed by a person trained and qualified on the maintenance of this machine.
- ☑ Scheduled maintenance inspections shall be completed daily, quarterly, annually and every 2 years as specified on the *Maintenance Inspection Report*.

⚠ WARNING Failure to perform each procedure as presented and scheduled may cause death, serious injury or substantial damage.

- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating machine.
- ☑ Keep records on all inspections for three years.
- ☑ Unless otherwise specified, perform each repair procedure with the machine in the following configuration:
 - machine parked on a flat, level surface
 - boom in stowed position
 - turntable rotated with the boom between the non-steering wheels
 - turntable secured with the turntable rotation lock pin
 - key switch in the OFF position with the key removed
 - wheels chocked

About This Section

This section contains detailed procedures for each scheduled maintenance inspection.

Each procedure includes a description, safety information and step-by-step instructions.

Symbols Legend

⚠ DANGER Indicates the presence of a hazard that **will** cause death or serious injury.

⚠ WARNING Indicates the presence of a hazard that **may** cause death or serious injury.

⚠ CAUTION Indicates the presence of a hazard that **will** or **may** cause serious injury or damage to the machine.

NOTICE Indicates special operation or maintenance information.

- ⦿ Indicates that a specific result is expected after performing a step.

Table A Procedures

A-1

Inspect the Manuals

Maintaining the operator's and safety manuals in good condition is essential to safe machine operation. Manuals are included with each machine and should be stored in the container provided in the platform. An illegible or missing manual will not provide safety and operational information necessary for a safe operating condition.

- 1 Check to be sure that the storage container is present and in good condition.
- 2 Check to make sure that the operator's, responsibilities and safety manual are present and complete in the storage container in the platform.
- 3 Examine the pages of each manual to be sure that they are legible and in good condition.
- 4 Always return the manuals to the storage container after use.

NOTICE

Contact your authorized Genie distributor or Genie Industries if replacement manuals are needed.

A-2

Inspect the Decals and Placards

Maintaining all of the safety and instructional decals and placards in good condition is mandatory for safe machine operation. Decals alert operators and personnel to the many possible hazards associated with using this machine. They also provide users with operation and maintenance information. An illegible decal will fail to alert personnel of a procedure or hazard and could result in unsafe operating conditions.

- 1 Refer to the *Decals* section in the *Genie S-40 Operator's Manual* and use the decal list and illustrations to determine that all decals and placards are in place.

- 2 Inspect all decals for legibility and damage. Replace any damaged or illegible decal immediately.

NOTICE

Contact your authorized Genie distributor or Genie Industries if replacement decals are needed.

A-3

Inspect for Damage, Loose or Missing Parts

Daily machine condition inspections are essential to safe machine operation and good machine performance. Failure to locate and repair damage, and discover loose or missing parts may result in an unsafe operating condition.

- 1 Inspect the entire machine for damage and improperly installed or missing parts including:
 - electrical components, wiring and electrical cables
 - hydraulic hoses, fittings, cylinders and manifolds
 - fuel and hydraulic tanks
 - drive and turntable rotation motors and torque hubs
 - boom components and wear pads
 - dents or damage to machine
 - tires and wheels
 - engine and related components
 - limit switches, alarms, horn and beacon
 - nuts, bolts and other fasteners
 - platform entry mid-rail or gate
 - cracks in welds or structural components
 - compartment covers and latches

TABLE A PROCEDURES

A-4**Check the Engine Oil Level**

Maintaining the proper engine oil level is essential to good engine performance and service life. Operating the machine with an improper oil level can damage engine components.

NOTICE Check the oil level with the engine off.

- 1 Check the oil level dipstick. Add oil as needed.

- ⦿ Result: The oil level should be in the "safe" zone.

Ford Engine LSG-423	5 quarts
Oil capacity (including filter)	4.7 liters

Ford Engine LSG-423 Oil viscosity requirements

below 60°F / 15.5°C	5W-30
-10 to 90°F / -23 to 32°C	10W-30
above -10°F / -23°C	10W-40 or 10W-50
above 25°F / -4°C	20W-40 or 20W-50

Use oils meeting API classification SF (labeled SF/CC or SF/CD) as they offer improved wear protection.

Deutz Engine F3L 1011	8.5 quarts
Oil capacity (including filter)	8 liters

Deutz Engine F3L 1011 Oil viscosity requirements

below 60°F / 15.5°C (synthetic)	5W-30
-10°F to 90°F / -23°C to 32°C	10W-40
above -4°F / -34°C	15W-40

Engine oil should have properties of API classification CC/SE, CD/SE, CC/SF or CD/SF grades.

A-5**Check the Engine Coolant Level - Gasoline/LPG Models**

Maintaining the engine coolant at the proper level is essential to engine service life. Improper coolant level will affect the engine's cooling capability and damage engine components. Daily checks will allow the inspector to identify changes in coolant level that might indicate cooling system problems.

- 1 Check the fluid level in the coolant recovery tank. Add fluid as needed.

- ⦿ Result: The fluid level should be in the NORMAL range.

A-6**Check for Fuel Leaks**

Failure to detect and correct fuel leaks will result in an unsafe condition. An explosion or fuel fire may cause death or serious injury.

⚠ DANGER

Engine fuels are combustible. Inspect the machine in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

- 1 Open the shutoff valve on the liquid petroleum gas (LPG) tank by turning it counterclockwise.

TABLE A PROCEDURES

- 2 Perform a visual inspection around the following areas. (An LPG detector may be necessary to locate LPG leaks.)

Gasoline/LPG models:

- LPG tank, hoses and fittings, solenoid shutoff valve, LPG regulator and carburetor
- gasoline tank, shutoff valve, solenoid shutoff valve, hoses and fittings, fuel pump and carburetor

Deutz Diesel models:

- fuel tank, shutoff valve, hoses and fittings, fuel pump, fuel filter, fuel injection pumps and fuel injectors

⚠ DANGER

If a fuel leak is discovered, keep any additional personnel from entering the area and do not operate the machine. Repair the leak immediately.

A-7**Check the Hydraulic Oil Level**

Maintaining the hydraulic oil at the proper level is essential to machine operation. Improper hydraulic oil levels can damage hydraulic components. Daily checks allow the inspector to identify changes in oil level that might indicate the presence of hydraulic system problems.

- 1 Be sure that the boom is in the stowed position, then visually inspect the sight gauge located on the side of the hydraulic oil tank.
- ⓘ Result: The hydraulic oil level should be within the top 2 inches (5 cm) of the sight gauge.

Hydraulic oil specifications

Hydraulic oil type	Dexron II equivalent
Tank capacity	45 gallons 170 liters
Hydraulic system (including tank)	50 gallons 189 liters

A-8**Check for Hydraulic Leaks**

Detecting hydraulic fluid leaks is essential to operational safety and good machine performance. Undiscovered leaks can develop into hazardous situations, impair machine functions and damage machine components.

- 1 Inspect for hydraulic oil puddles, dripping or residue on or around the following areas:
 - hydraulic tank–filter, fittings, hoses, auxiliary power unit and turntable surface
 - engine compartment–fittings, hoses, main pump, filter and turntable surface
 - all hydraulic cylinders
 - all hydraulic manifolds
 - boom
 - the underside of the turntable
 - the underside of the drive chassis
 - ground area under the machine

TABLE A PROCEDURES

A-9 Check the Tire Pressure

NOTICE This procedure does not need to be performed on machines equipped with the foam-filled tire option.

WARNING An over-inflated tire can explode and may cause death or serious injury.

To safeguard maximum stability, achieve optimum machine handling and minimize tire wear, it is essential to maintain proper pressure in all air-filled tires.

- 1 Check each tire with an air pressure gauge and add air as needed.

Tire specifications	2WD front	2WD rear 4WD front & rear
Tire size	12.5L-16SL	12-16.5NHS
Pressure	45 psi 3.10 bar	45 psi 3.10 bar

A-10 Test the Platform and Ground Controls

Testing the machine functions and the Emergency Stop buttons for malfunctions is essential for safe machine operation. An unsafe working condition exists if any function fails to operate properly or either Emergency Stop button fails to stop all the machine functions and shut off the engine. Each function should activate, operate smoothly and be free of hesitation, jerking and unusual noise.

- 1 Start the engine from the ground controls, and then operate each machine function through a full cycle.
 - ⦿ Result: All machine functions should operate smoothly.
- 2 Push in the Emergency Stop button to the OFF position.
 - ⦿ Result: No function should operate, the engine should stop.

NOTICE Deutz Diesel models:
All functions should stop immediately. The engine will shut off after 2 to 3 seconds.

- 3 Start the engine from the platform controls, and then operate each machine function through a full cycle.
 - ⦿ Result: All machine functions should operate smoothly.
- 4 Push in the Emergency Stop button to the OFF position.
 - ⦿ Result: No function should operate, the engine should stop.


NOTICE As a safety feature, selecting and operating the ground controls will override the platform controls, including the Emergency Stop button.

TABLE A PROCEDURES

A-11**Test the Auxiliary Power Operation**

Detection of auxiliary power system malfunctions is essential for safe machine operation. An unsafe working condition exists if the auxiliary powered functions do not operate in the event of a main power loss. When operating the machine on engine power, selecting auxiliary power will stop the engine immediately. Auxiliary power is designed for short term emergency use only, and excessive use will result in battery drain and component damage.

- 1 Turn the key switch to ground control and pull out the Emergency Stop button to the **ON** position.
- 2 Simultaneously hold the auxiliary power switch **ON** while activating the following functions through a partial cycle:
 - boom up/down
 - extend and retract
 - turntable rotate right/left



⦿ Result: Each function should operate smoothly.

- 3 Turn the key switch to platform control.

- 4 At the platform controls, pull out the Emergency Stop button to the **ON** position, then press down the foot switch.
- 5 Simultaneously hold the auxiliary power switch **ON** while activating the following functions through a partial cycle:
 - boom up/down
 - extend and retract
 - turntable rotate right/left
 - steer right/left





TABLE A PROCEDURES

A-12 Test the Tilt Sensor

The tilt sensor sounds an alarm in the platform when the incline of the drive chassis exceeds 5 degrees.

NOTICE Select a level test area. The tilt alarm should not be sounding prior to test.

- 1 Start the engine from the platform controls.
 - 2 Open the tank side cover and press down on one side of the tilt sensor.
- ⦿ Result: After a 1 second delay, the alarm in the platform should sound.



A-13 Test the Limit Switches

Drive Limit Switches

Detecting limit switch malfunctions is essential to safe machine operation. The drive limit switches are used to restrict drive speed when the boom is raised or extended. An improperly functioning drive limit switch will allow the machine to operate in an unsafe position.

- 1 Start the engine from the ground controls. Raise the boom 10 ft. (3 m) off the ground. Turn the engine off.
- 2 Visually inspect the drive limit switch located next to the boom lift cylinder for the following:
 - broken or missing actuator arm
 - missing fasteners
 - loose wiring





TABLE A PROCEDURES

- 3 Remove the turntable end cover to access the limit switch mounted inside the boom.
- 4 Visually inspect the drive limit switch located in the pivot end of the boom. Inspect for the following:

- broken or missing actuator arm
- missing fasteners
- loose wiring



- a drive limit switch
b boom
c extension boom tube
d extension cylinder

- 5 Lower the boom to the stowed position.
- 6 Start the engine from the platform controls. Then slowly move the drive control handle off center.
- ⦿ Result: The machine should move at normal drive speeds.
- 7 Raise the boom above the drive limit switch.
- 8 Slowly move the drive control handle off center.
- ⦿ Result: The machine should move at a reduced drive speed.


- 9 Lower the boom to the stowed position, then extend the boom 1 foot (30 cm).
- 10 Slowly move the drive control handle off center.
- ⦿ Result: The machine should move at a reduced drive speed.

Drive speed, maximum, raised or extended

All models	1 foot per second 0.3 meter per second
------------	---

Drive Enable Limit Switch

- 1 With the engine off and the boom in the stowed position, visually inspect the drive enable limit switch for the following:
- broken or missing rollers or arms
 - missing fasteners
 - loose wiring



- a turntable
b drive enable limit switch
c turntable rotation bearing

TABLE A PROCEDURES

- 2 Manually activate the drive enable limit switch.
- ⦿ Result: The drive enable limit switch roller should move freely and spring return to center. A distinct click should be felt and heard.
- 3 Start the engine from the platform controls.
- 4 Rotate the turntable to the left until the boom is past the left non-steer wheel.
- ⦿ Result: The drive enable indicator light should be on. Drive function should not operate until the drive enable switch is activated.
- 5 Rotate the turntable to the right until the boom is past the right non-steer wheel.
- ⦿ Result: The drive enable indicator light should be on. Drive function should not operate until the drive enable switch is activated.

A-14

Test the Oscillate Axle (oscillating axle-equipped models)

Proper axle oscillation is essential to safe machine operation. If the axle oscillation system is not operating correctly, the stability of the machine is compromised and it may tip over.

- 1 Start the engine from the platform controls.
- 2 Drive the right steer tire up onto a 6 inch (15.2 cm) block or curb.
- ⦿ Result: The three remaining tires should stay in firm contact with the ground.
- 3 Drive the left steer tire up onto a 6 inch (15.2 cm) block or curb.
- ⦿ Result: The three remaining tires should stay in firm contact with the ground.
- 4 Drive both steer tires up onto a 6 inch (15.2 cm) block or curb.
- ⦿ Result: The non-steer tires should stay in firm contact with the ground.

TABLE A PROCEDURES

A-15**Replace the Engine Oil and Filter - Gasoline/LPG Models****NOTICE**

Ford engine specifications require that this procedure be performed every 100 hours. Perform this procedure more often if dusty conditions exist or the machine is subjected to extended low idle operation.

Periodic replacement of the engine oil and filter is essential to good engine performance. Operating the machine with an improper oil level or neglecting periodic oil and filter changes can damage engine components. A daily check of elapsed machine hours against the hours noted on the oil filter will allow the inspector to anticipate and perform oil and filter changes at the 100 hour interval.

NOTICE


Perform this procedure after warming the engine to normal operating temperature.

CAUTION

Beware of hot engine parts and oil. Contact with hot engine oil and/or engine parts may cause severe burns.

- 1 Remove the oil filler cap located on the valve cover.

- 2 Pull the end of the oil drain hose out from under the engine.



- a engine pivot plate
- b pivot plate retaining bolts
- c oil drain hose

- 3 Remove the plug from the end of the drain hose and allow all of the oil from the engine to drain into a suitable container.
- 4 Install the plug into the drain hose.
- 5 Remove the 2 bolts from the engine pivot plate. Swing the engine pivot plate away from the machine to access the oil filter.
- 6 Use an oil filter wrench and remove the filter.
- 7 Apply a thin layer of oil to the new oil filter gasket (filter part no. 28656). Then install the filter and tighten it securely by hand.

TABLE A PROCEDURES

- 8 Use a permanent ink marker to write the date and number of hours from the hour meter on the oil filter.
- 9 Fill the engine with new oil per specifications and install the filler cap.
- 10 Start the engine from the ground controls. Allow the engine to run for 30 seconds, then turn the engine off.
- 11 Check the oil filter and the oil drain hose for leaks.
- 12 Swing the engine pivot plate back to its original position and replace the two retaining bolts.
- 13 Check the engine oil level dipstick. Add oil if needed.

Ford Engine LSG-423	5 quarts
Oil capacity (including filter)	4.7 liters

Ford Engine LSG-423 Oil viscosity requirements

below 60F / 15.5C	5W-30
-10 to 90F / -23 to 32C	10W-30
above -10F / -23C	10W-40 or 10W-50
above 25F / -4C	20W-40 or 20W-50

Use oils meeting API classification SF (labeled SF/CC or SF/CD) as they offer improved wear protection.

A-16**Replace the Engine Air Filter****NOTICE**

Engine specifications require that this procedure be performed every 100 hours. Perform this procedure more often if dusty conditions exist.

Maintaining the engine air filter in good condition is essential to good engine performance and service life. Failure to perform this procedure can lead to poor engine performance and component damage.

NOTICE

Perform this procedure with the engine off.

- 1 Remove the end cap from the air cleaner canister.
- 2 Remove the mounting fastener from the air filter, then remove the filter.
- 3 Clean the inside of the canister and the gasket with a dry cloth.
- 4 Insert the new filter and replace the mounting fastener.
- 5 Replace the end cap on the canister.

Air filters - Genie part numbers

Ford LSG-423 Engine	27916
Deutz F3L 1011	29553

Table B Procedures

B-1

Check the Engine Belt(s)

Maintaining the engine belt(s) is essential to good engine performance and service life. The machine will not operate properly with a loose or defective belt and continued use may cause component damage.


⚠ WARNING

Do not inspect while the engine is running. Remove the key to secure from operation.

⚠ CAUTION

Beware of hot engine components. Contact with hot engine components may cause severe burns.

- 1 **Deutz Diesel models:** Remove front engine cover to access belt.
- 2 **All models:** Inspect the engine belt(s) for:
 - cracking
 - glazing
 - separation
 - breaks
- 3 Check the engine belt(s) for proper tension.



Ford engine

Deutz Diesel engine

Belt deflection - all models

$\frac{3}{8}$ inch to $\frac{1}{2}$ inch
9 mm to 12 mm

B-2

Check the Radiator - Gasoline/LPG Models

Maintaining the radiator in good condition is essential for good engine performance. Operating a machine with a damaged or leaking radiator may result in engine damage. Also, restricting air flow through the radiator (i.e., dirt or debris) will affect the performance of the cooling system. A frequent check allows the inspector to identify changes in the condition of the radiator that might indicate cooling system problems.

⚠ WARNING

Do not inspect while the engine is running. Remove the key to secure from operation.

⚠ CAUTION

Beware of hot engine components. Contact with hot engine components may cause severe burns.

- 1 Inspect the radiator for leaks and physical damage.
- 2 Clean the radiator fins of debris and foreign materials.

B-3

Check the Oil Cooler and Cooling Fins - Deutz Diesel Models

Maintaining the oil cooler in good condition is essential for good engine performance. Operating a machine with a damaged oil cooler may result in engine damage. Also, restricting air flow through the oil cooler will affect the performance of the cooling system.

⚠ WARNING

Do not inspect while the engine is running. Remove the key to secure from operation.


⚠ CAUTION

Beware of hot engine components. Contact with hot engine components may cause severe burns.

TABLE B PROCEDURES

Oil Cooler

- 1 Remove the cover from the side of the engine, then remove the oil cooler top cover.
- 2 Inspect the oil cooler for leaks and physical damage.



- a oil cooler
b cylinder head cooling fins
c blower fins

- 3 Clean the oil cooler of debris and foreign material.

Cooling and Blower Fins

- 4 Inspect the blower fins for physical damage.
- 5 Clean the blower fins of debris and foreign material.
- 6 Inspect the head cooling passages and fins for physical damage or foreign material, using a flashlight.
- 7 Clean the cylinder head cooling passages of debris and foreign material.

B-4**Check the Exhaust System**

Maintaining the exhaust system is essential to good engine performance and service life. Running the engine with a damaged or leaking exhaust system can cause component damage and unsafe operating conditions.


⚠ WARNING

Do not inspect while the engine is running. Remove the key to secure from operation.

⚠ CAUTION

Beware of hot engine components. Contact with hot engine components may cause severe burns.

- 1 **Deutz Diesel models:** Remove the 2 bolts from the engine pivot plate. Swing the engine pivot plate away from the machine to access the exhaust system.



- a pivot plate retaining bolts
b engine pivot plate

TABLE B PROCEDURES

- 2 Be sure that all nuts and bolts are tight.
- 3 Inspect all welds for cracks.
- 4 Inspect for exhaust leaks; i.e., carbon buildup around seams and joints.

B-5 Check the Battery

Proper battery condition is essential to good engine performance and operational safety. Improper fluid levels or damaged cables and connections can result in engine component damage and hazardous conditions.


WARNING Do not inhale or ingest acid. Avoid spillage or contacting battery acid. Neutralize battery acid spills with baking soda and water.

- 1 Put on protective clothing and eye wear.
- 2 Be sure that the battery cable connections are free of corrosion.
- 3 Be sure that the battery hold downs and cable connections are tight.
- 4 Remove the battery vent caps and check the specific gravity with a hydrometer.
- 5 Check the battery acid level. If needed, replenish with water to the bottom of the battery fill tube. Do not overfill.
- 6 Install the vent caps.

B-6 Check the Hydraulic Tank Filter Condition Indicator

Maintaining the hydraulic tank filter in good condition is essential to good system performance and safe machine operation. The filter condition indicator will show when the hydraulic flow is bypassing a clogged filter. If the filter is not frequently checked and replaced, impurities will remain in the hydraulic system and cause component damage.

- 1 Start the engine from the platform controls.
- 2 Move the engine speed control switch to high idle (rabbit symbol).
- 3 Inspect the filter condition indicator.



- a filter condition indicator
- b filter
- c hydraulic tank

- ⦿ Result: The filter should be operating with the plunger in the green area. If the display shows the plunger in the red area, this indicates that the hydraulic filter is being bypassed and the filter should be replaced. See C-6, *Replace the Hydraulic Tank Filter*.

TABLE B PROCEDURES

B-7**Inspect the Electrical Wiring**

Maintaining electrical wiring in good condition is essential to safe operation and good machine performance. Failure to find and replace burnt, chafed, corroded or pinched wires could result in unsafe operating conditions and may cause component damage.

⚠WARNING Electrocutation hazard. Contact with hot or live circuits may result in death or serious injury. Remove all rings, watches and other jewelry.

- 1 Inspect the following areas for burnt, chafed, corroded and loose wires:
 - engine compartment electrical panel
 - engine wiring harness
 - inside of the ground control box
 - turntable manifold wiring
- 2 Start the engine from the ground controls, then raise the boom above the turntable covers.
- 3 Inspect the turntable area for burnt, chafed and pinched cables.
- 4 Lower the boom into the stowed position and turn the engine off.
- 5 Inspect the following areas for burnt, chafed, corroded, pinched and loose wires:
 - cable track on the boom
 - boom to platform cable harness
 - inside of the platform control box

B-8**Inspect the Tires and Wheels (including lug nut torque)**

Maintaining the tires and wheels in good condition is essential to safe operation and good performance. Tire and/or wheel failure could result in a machine tip-over. Component damage may also result if problems are not discovered and repaired in a timely fashion.

⚠WARNING An over-inflated tire can explode and may cause death or serious injury.

- 1 Check all tire treads and sidewalls for cuts, cracks, punctures and unusual wear.
- 2 Check each wheel for damage, bends and cracked welds.
- 3 Check each lug nut for proper torque.
- 4 Check the pressure in each air-filled tire.


Tires and wheels	2WD front	2WD rear 4WD front & rear
Tire size	12.5L-16SL	12-16.5NHS
Tire ply rating	12	8
Overall tire diameter	33.7 in 85.6 cm	33.2 in 84.3 cm
Tire pressure	45 psi 3.10 bar	45 psi 3.10 bar
Wheel diameter	16 in 40.6 cm	16.5 in 41.9 cm
Wheel width	10 in 25.4 cm	9.75 in 24.7 cm
Wheel lugs	8 @ 5/8-18	9 @ 5/8-18
Lug nut torque	125 ft-lbs 169.5 Nm	125 ft-lbs 169.5 Nm

TABLE B PROCEDURES


B-9 Confirm the Proper Brake Configuration

Proper brake configuration is essential to safe operation and good machine performance. Hydrostatic brakes and hydraulically-released, spring-applied individual wheel brakes can appear to operate normally when they are actually not fully operational.

- 1 Check each torque hub disconnect cap to be sure it is in the engaged position.



- 2 Be sure the free-wheel valve on the drive pump is closed (clockwise).



- a drive pump
- b free-wheel valve
- c screwdriver
- d lift pump

NOTICE


The free-wheel valve should always remain closed.

B-10 Check the Oil Level in the Torque Hubs

Failure to maintain proper torque hub oil levels may cause the machine to perform poorly and continued use may cause component damage.

Drive Torque Hubs

- 1 Drive the machine to rotate the hub until the plugs are located one on top and the other at 90 degrees.



- 2 Remove the plug located at 90 degrees and check the oil level.
 - ⦿ Result: The oil level should be even with the bottom of the plug hole.
- 3 If necessary, remove the top plug and add oil until the oil level is even with the bottom of the side plug hole.
- 4 Apply pipe thread sealant to the plug, and then install it in the torque hub.
- 5 Repeat this procedure for each drive torque hub.

Drive torque hub oil


Capacity	17 fluid ounces
	0.51 liters

Type: SAE 90 multipurpose hypoid gear oil - API service classification GL5

TABLE B PROCEDURES

Turntable Rotate Torque Hub

- 1 Remove the plug located on the side of the hub and check the oil level.
- ② Result: The oil level should be even with the bottom of the plug hole.



- 2 If necessary, add oil until the oil level is even with the bottom of the side plug hole.
- 3 Apply pipe thread sealant to the plug, and then install it in the torque hub.

Turntable rotate torque hub oil

Capacity	8 fluid ounces
	0.24 liters

TypeSAE 90 multipurpose hypoid gear oil - API service classification GL5

B-11**Check and Adjust the Engine Idle Mixture - Gasoline/LPG Models**

Complete information to perform this procedure is available in the *Ford LSG-423 2.3 Liter Industrial Engine Service Manual* (Ford number: 194-216). Genie part number 29586.

B-12**Check and Adjust the Engine RPM**

Maintaining the engine rpm at the proper setting for both low and high idle is essential to good engine performance and service life. The machine will not operate properly if the rpm is incorrect and continued use may cause component damage.

Gasoline/LPG Models**NOTICE**

Perform this procedure in gasoline mode with the engine at normal operating temperature.

- 1 Disconnect the blue/black wire from the governor actuator.


TABLE B PROCEDURES

- 2 Connect an rpm gauge to the engine, then start the engine from the ground controls.

☉ Result: Carburetor low idle should be 900 rpm.

Skip to step 4 if the low idle rpm is correct.

- 3 Turn the idle adjustment screw on the carburetor clockwise to increase rpm or counterclockwise to decrease rpm.




Gasoline/LPG low idle adjustment
a carburetor
b adjustment screw

- 4 Turn the engine off and reconnect the blue/black wire to the governor actuator.
- 5 Start the engine from the ground controls.
- ☉ Result: Electronic governor low idle should be 1600 rpm.
- 6 Move the engine idle control switch to high idle (rabbit symbol) from the ground controls.
- ☉ Result: High idle should be 2500 rpm.
- 7 Turn the engine off.

If low and high idle rpm's are correct, disregard adjustment steps 8 and 9.

- 8 Remove the mounting fasteners from the electronic governor located on the engine side bulkhead, then remove the back panel from the governor.
- 9 Restart the engine, turn the low or high speed set screw clockwise to increase the rpm or counterclockwise to decrease the rpm.

NOTICE Do not use any trimpot other than specified in this procedure.



Gasoline/LPG idle adjustment
a low idle adjustment
b high idle adjustment

- 10 Re-assemble the governor and recheck low and high idle.

Gasoline/LPG models

Low idle - carburetor	900 rpm
Low idle - electronic governor	1600 rpm
High idle	2500 rpm


Deutz Diesel models

- 1 Connect an rpm gauge to the engine, and then start the engine from the ground controls.
- ☉ Result: Low idle should be 1300 rpm.

Skip to step 3 if the low idle rpm is correct.

TABLE B PROCEDURES

- 2 Loosen the lock nut, then turn the adjustment screw clockwise to increase the rpm or counterclockwise to decrease the rpm. Tighten the lock nut and recheck the rpm.



- a solenoid boot
- b high idle adjustment nut
- c lock nut
- d yoke
- e low idle adjustment screw
- f lock nut

- 3 Move the engine idle control switch to high idle (rabbit symbol) from the ground controls.

⊙ Result: High idle should be 2300 rpm.

If high idle rpm is correct, disregard adjustment step 4.

- 4 Loosen the yoke lock nut, then turn the adjustment nut and solenoid boot counterclockwise to increase the rpm or clockwise to decrease the rpm. Tighten the yoke lock nut and recheck the rpm.

Deutz Diesel models

Low idle	1300 rpm
High idle	2300 rpm

B-13

Test the Key Switch

Proper key switch action and response is essential to safe machine operation. The machine can be operated from the ground or platform controls and the activation of one or the other is accomplished with the key switch. Failure of the key switch to activate the appropriate control panel could cause a hazardous operating situation.

- 1 Pull out the Emergency Stop button to the ON position at both the ground and platform controls.
- 2 Turn the key switch to ground control, start the engine and then turn the key switch to **platform control**.
- 3 Check any machine function from the **ground controls**.
- ⊙ Result: The machine functions should **not** operate.
- 4 Turn the key switch to ground control.
- 5 Check any machine function from the **platform controls**.
- ⊙ Result: The machine functions should **not** operate.
- 6 Turn the key switch to the OFF position.
- ⊙ Result: The engine should stop and no functions should operate.

NOTICE

Deutz Diesel models: All functions should stop immediately. The engine will shut off after 2 to 3 seconds.

TABLE B PROCEDURES

B-14**Test the Emergency Stop Buttons**

Properly functioning Emergency Stop buttons are essential for safe machine operation. An improperly operating Emergency Stop button will fail to shut off power and stop all machine functions, resulting in a hazardous situation for ground and platform personnel.

NOTICE As a safety feature, selecting and operating the ground controls will override the platform controls, including the Emergency Stop button.

- 1 Start the engine from the ground controls.
- 2 Push down the Emergency Stop button to the OFF position.

⦿ Result: The engine should shut off and no machine functions should operate.

NOTICE Deutz Diesel models: All functions should stop immediately. The engine will shut off after 2 to 3 seconds.

- 3 Start the engine from the platform controls.
- 4 Push down the Emergency Stop button to the OFF position.

⦿ Result: The engine should shut off and no machine functions should operate.

NOTICE The ground Emergency Stop button will stop all machine operation, even if the key switch is switched to platform control.

B-15**Test the Ground Control Override**

A properly functioning ground control override is essential to safe machine operation. The ground control override function is intended to allow ground personnel to operate the machine from the ground controls whether or not the Emergency Stop button on the platform controls is in the ON or OFF position. This function is particularly useful if the operator at the platform controls cannot return the boom to the stowed position.

- 1 Push in the platform Emergency Stop button to the OFF position.
- 2 Start the engine from the ground controls.
- 3 Operate each boom function through a partial cycle.


⦿ Result: All boom functions should operate.

TABLE B PROCEDURES

B-16 Check the Directional Valve Linkage

Proper axle oscillation is essential to safe machine operation. If the directional valve linkage is not operating correctly, the stability of the machine is compromised and it may tip over.

- 1 Remove the drive chassis cover from the non-steer end.
- 2 Inspect the linkage for the following:
 - lock nuts are tight against yokes
 - yoke clevis pins are installed
 - cotter pins are installed through clevis pins
 - linkage is properly attached to directional valve



- a directional valve
b lock nut
c yoke
d clevis pin with cotter pin

B-17 Test the Platform Self-leveling

Automatic platform self-leveling throughout the full cycle of boom raising and lowering is essential for safe machine operation. The platform is maintained at level by the platform leveling slave cylinder which is controlled by the master cylinder located at the base of the boom. A platform self-leveling failure creates an unsafe working condition for platform and ground personnel.

- 1 Start the engine from the ground controls, then lower the boom into the stowed position.
 - 2 Adjust the platform to a level position using the platform leveling switch.
 - 3 Raise and lower the boom through a full cycle.
- ⓘ Result: The platform should remain level at all times to within ± 5 degrees.

B-18 Test the Service Horn

A functional service horn is essential to safe machine operation. The service horn is activated at the platform controls and sounds at the ground as a warning to ground personnel. An improperly functioning horn will prevent the operator from alerting ground personnel of hazards or unsafe conditions.

- 1 Turn the key switch to platform control and pull out the Emergency Stop button to the ON position at both the ground and platform controls.
 - 2 Push down the service horn button at the platform controls.
- ⓘ Result: The service horn should sound.

TABLE B PROCEDURES

B-19**Test the Foot Switch**

A properly functioning foot switch is essential to safe machine operation. Machine functions should activate and operate smoothly as long as the foot switch is pressed down, and promptly stop when the foot switch is released. The foot switch will also shift the engine into high idle if the idle select is switched to the rabbit and foot switch symbol. An improperly functioning foot switch can cause an unsafe working condition and endanger platform and ground personnel.

NOTICE The engine should not start if the foot switch is pressed down.

- 1 Start the engine from the platform controls.
- 2 Without pressing down the foot switch, check the machine functions.
- ⦿ Result: The machine functions should **not** operate.
- 3 Press down the foot switch and operate the machine functions.
- ⦿ Result: The machine functions should operate.

B-20**Test the Engine Idle Select**

A properly operating engine idle select switch is essential to good engine performance and safe machine operation. There are three settings.

Low idle (turtle symbol) allows the operator to control individual boom functions only. Drive functions do not operate at low idle.

High idle (rabbit symbol) allows the operator to control multiple boom and/or drive functions simultaneously. This setting maintains a consistent high idle and is usually selected only when the generator option is being used.

Foot switch activated high idle (rabbit and foot switch symbols) should be used for normal machine operation. This selection activates high idle only when the foot switch is pressed down.

- 1 Pull out the Emergency Stop button to the **ON** position at both the ground and platform controls.
- 2 Start the engine from the ground controls. Then move the engine idle control switch to high idle (rabbit symbol) and hold in the **ON** position.
- ⦿ Result: The engine should change to high idle.
- 3 Release the engine idle control switch.
- ⦿ Result: The engine should return to low idle.
- 4 Turn the key switch to platform controls.
- 5 At the platform controls, move the engine idle control switch to high idle (rabbit symbol).
- ⦿ Result: The engine should change to high idle.
- 6 Move the engine idle control switch to low idle (turtle symbol).
- ⦿ Result: The engine should change to low idle.
- 7 Move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol).
- ⦿ Result: The engine should **not** change to high idle.
- 8 Press down the foot switch.
- ⦿ Result: The engine should change to high idle.

Gasoline/LPG models

Low idle	1600 rpm
----------	----------

High idle	2500 rpm
-----------	----------

Deutz Diesel models

Low idle	1300 rpm
----------	----------

High idle	2300 rpm
-----------	----------

TABLE B PROCEDURES

B-21**Test the Fuel Select Operation
- Gasoline/LPG Models**

The ability to select and switch between gasoline and LPG fuels as needed is essential to safe machine operation. A fuel selection can be made when the engine is running or not. Switching malfunctions and/or the failure of the engine to start and run properly in both fuel modes and through all idle speeds can indicate fuel system problems that could develop into a hazardous situation.

NOTICE Perform this test after checking the gasoline and LPG fuel levels, and warming the engine to normal operating temperature.


- 1 Move the fuel select switch to gasoline and then move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol).
- 2 Start the engine from the platform controls and allow it to run at low idle.
- 3 Press down the foot switch to allow the engine to run at high idle.
- ⦿ Result: The engine should start promptly and operate smoothly in low and high idle.
- 4 Release the foot switch and stop the engine.
- 5 Move the fuel select switch to LPG.
- 6 Restart the engine and allow it to run at low idle.
- 7 Press down the foot switch to allow the engine to run at high idle.
- ⦿ Result: The engine should start promptly and operate smoothly in low and high idle.

NOTICE The engine may hesitate momentarily and then continue to run on the selected fuel if the fuel source is switched while the engine is running.

B-22**Test the Drive Enable System**

Proper drive enable system operation is essential to safe machine operation. When the boom is past the non-steering wheels, drive movement is stopped and the indicator light turns on. The drive enable switch must be used to reactivate the drive function and should inform the operator that the machine will move in the opposite direction that the drive and steer controls are moved. An improperly functioning drive enable system may allow the machine to be moved into an unsafe position.

- 1 Start the engine from the platform controls.
- 2 Rotate the turntable to the right until the boom is past the right non-steering wheel.
- ⦿ Result: The drive enable indicator light should turn on.
- 3 Slowly move the drive control handle off center.
- ⦿ Result: The drive function should **not** operate.
- 4 Hold the drive enable toggle switch to either side and slowly move the drive control handle off center.



CAUTION Always use the color-coded direction arrows on the platform control panel and the drive chassis to identify which direction the machine will travel.

- ⦿ Result: The drive function should operate.
- 5 Rotate the turntable to the left until the boom is past the left non-steering wheel.
- ⦿ Result: The drive enable indicator light should come on.
- 6 Repeat steps 3 and 4.

TABLE B PROCEDURES

B-23**Test the Drive Brakes**

Proper brake action is essential to safe machine operation. The drive brake function should operate smoothly, free of hesitation, jerking and unusual noise. Hydrostatic brakes and hydraulically-released individual wheel brakes can appear to operate normally when they are actually not fully operational.

AWARNING Be sure that the machine is not in free-wheel or partial free-wheel configuration. Refer to B-9 in this section, *Confirm the Proper Brake Configuration*.

NOTICE Select a test area that is firm, level and free of obstructions.

- 1 Mark a test line on the ground for reference.
- 2 Start the engine from the platform controls.
- 3 Move the engine idle control switch to foot switch activated high idle (rabbit and foot switch), then lower the boom into the stowed position.
- 4 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the test line.
- 5 Bring the machine to top drive speed before reaching the test line. Release the drive joystick when your reference point on the machine crosses the test line.
- 6 Measure the distance between the test line and your machine reference point.

**Braking:
paved surface**

Stopping distance	2 to 4 ft 0.60 to 1.21 m
-------------------	-----------------------------

NOTICE The brakes must be able to hold the machine on any slope it is able to climb.

B-24**Test the Drive Speed
- Stowed Position**

Proper drive function movement is essential to safe machine operation. The drive function should respond quickly and smoothly to operator control. Drive performance should also be free of hesitation, jerking and unusual noise over the entire proportionally controlled speed range.

NOTICE Select a test area that is firm, level and free of obstructions.

- 1 Create start and finish lines by marking two lines on the ground 40 feet (12.2 m) apart.
- 2 Start the engine from the platform controls.
- 3 Move the engine idle control switch to foot switch activated high idle (rabbit and foot switch), then lower the boom into the stowed position.
- 4 Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the start and finish lines.
- 5 Bring the machine to top drive speed before reaching the start line. Begin timing when your reference point on the machine crosses the start line.
- 6 Continue at full speed and note the time when the machine reference point crosses the finish line.

Drive speed: stowed position	2WD	4WD
Gasoline/LPG models	40 ft/6.8 sec 12.2 m/6.8 sec	40 ft/7.8 sec 12.2 m/7.8 sec
Deutz Diesel models	40 ft/7.8 sec 12.2 m/7.8 sec	40 ft/9.1 sec 12.2 m/9.1 sec

TABLE B PROCEDURES

B-25

Test the Alarm Package - Optional Equipment

The alarm package includes:

- travel alarm
- descent alarm
- flashing beacon

Alarms and a beacon are installed to alert operators and ground personnel of machine proximity and motion. The alarm package is installed on the turntable covers.

NOTICE The alarms and beacon will operate with the engine running or not running.

- 1 At the ground controls, pull out the Emergency Stop button to the **ON** position and turn the key switch to ground control.
 - ⦿ Result: The flashing beacon should be on and flashing.
- 2 Move the boom switch to the **DOWN** position, hold for a moment and then release it.
 - ⦿ Result: The descent alarm should sound when the switch is held down.
- 3 Turn the key switch to platform control.
- 4 At the platform controls pull out the Emergency Stop button to the **ON** position.
 - ⦿ Result: The flashing beacon should be on and flashing.
- 5 Press down the foot switch. Move the boom control handle to the **DOWN** position, hold for a moment and then release it.
 - ⦿ Result: The descent alarm should sound when the control handle is held down.
- 6 Press down the foot switch. Move the drive control handle off center, hold for a moment and then release it. Move the drive control handle off center in the opposite direction, hold for a moment and then release it.
 - ⦿ Result: The travel alarm should sound when the drive control handle is moved off center in either direction.

B-26

Perform Hydraulic Oil Analysis

See D-1, *Test or Replace the Hydraulic Oil*.

TABLE B PROCEDURES

B-27**Replace the Engine Oil and Filter - Deutz Diesel Models**


NOTICE Engine specifications require that this procedure be performed every 500 hours. Perform this procedure more often if dusty conditions exist.

Periodic replacement of the engine oil and filter is essential to good engine performance. Operating the machine with an improper oil level or neglecting periodic oil and filter changes can damage engine components. A frequent check of elapsed machine hours against the hours noted on the oil filter will allow the inspector to anticipate and perform oil and filter changes at the 500 hour interval.

NOTICE Perform this procedure after warming the engine to normal operating temperature.

CAUTION Beware of hot engine parts and oil. Contact with hot engine oil and/or engine parts may cause severe burns.

- 1 Remove the oil filler cap located on the valve cover.
- 2 Pull the end of the drain hose out from under the engine.
- 3 Remove the plug from the end of the drain hose and allow all of the oil from the engine to drain into a suitable container.
- 4 Install the plug into the drain hose.
- 5 Use an oil wrench and remove the oil filter.



- a engine oil level dipstick
b oil filter
c fuel filter

- 6 Apply a thin layer of oil to the new filter gasket (filter part no. 29561). Then install the filter and tighten it securely by hand.
- 7 Use a permanent ink marker to write the date and number of hours from the hour meter on the oil filter.
- 8 Fill the engine with new oil per specifications and replace the oil filler cap.
- 9 Start the engine from the ground controls. Allow the engine to run for 30 seconds then turn the engine off.
- 10 Check the oil filter and oil pan for leaks.
- 11 Check the engine oil level dipstick. Add oil if needed.

Deutz Engine F3L 1011	8.5 quarts
Oil capacity (including filter)	8 liters

Deutz Engine F3L 1011 Oil viscosity requirements

Temperature below 60°F / 15.5°C (synthetic)	5W-30
-10°F to 90°F / -23°C to 32°C	10W-40
Temperature above -4°F / -34°C	15W-40

Engine oil should have properties of API classification CC/SE, CD/SE, CC/SF or CD/SF grades.

Table C Procedures

C-1

Check the Boom Wear Pads

Maintaining the boom wear pads in good condition is essential to safe machine operation. Wear pads are placed on boom tube surfaces to provide a low friction, replaceable wear pad between moving parts. Improperly shimmed wear pads or continued use of worn out wear pads may result in component damage and unsafe operating conditions.

- 1 Start the engine from the ground controls.
- 2 Raise the end of the boom to a comfortable working height (chest high), then extend the boom 1 foot (30 cm).
- 3 Measure each wear pad. Replace the wear pad if it is less than $\frac{7}{16}$ inch (11 mm) thick. If the wear pad is more than $\frac{7}{16}$ inch (11 mm) thick, shim as necessary to obtain zero clearance and zero drag.
- 4 Extend and retract the boom through the entire range of motion to check for tight spots that could cause binding or scraping.

NOTICE


Always maintain squareness between the boom outer and inner tubes.

C-2

Check the Turntable Rotation Bearing Bolts


Maintaining proper torque on the turntable bearing bolts is essential to safe machine operation. Improper bolt torque could result in an unsafe operating condition and component damage.

- 1 Raise the boom approximately 7 to 8 feet (2.1 to 2.4 m).
- 2 Be sure that each turntable mounting bolt is torqued in sequence to 210 foot-pounds (285 Newton meters).



Bolt torque sequence

- 3 Lower the boom to the stowed position.
- 4 Check to ensure that each bearing mounting bolt under the drive chassis is torqued in sequence to 210 foot-pounds (285 Newton meters).



Bolt torque sequence

TABLE C PROCEDURES


C-3**Check the Free-wheel Configuration**

Proper use of the free-wheel configuration is essential to safe machine operation. The free-wheel configuration is used primarily for towing. A machine configured to free-wheel without operator knowledge may cause death or serious injury and property damage.

⚠ WARNING Collision hazard. Select a work site that is firm and level.

Non-steering wheels: All models

- 1 Chock the steer wheels to prevent the machine from rolling.
- 2 Center a lifting jack of ample capacity (15,000 lbs/6,804 kg) under the drive chassis between the non-steering wheels.
- 3 Lift the wheels off the ground and then place jack stands under the drive chassis for support.
- 4 Disengage the torque hubs by turning over the torque hub disconnect caps on each non-steering wheel hub.




- 5 Manually rotate each non-steering wheel.
- ⦿ Result: Each non-steering wheel should rotate with minimum effort.
- 6 Re-engage the torque hubs by turning over the hub disconnect caps. Carefully remove the jack stands, lower the machine and remove the jack.

⚠ WARNING Collision hazard. Failure to re-engage the torque hubs may cause death or serious injury and property damage.

Steer wheels: 4WD models

- 7 Chock the non-steering wheels to prevent the machine from rolling.
- 8 Position the lifting jack under the steering axle and center it between the steering wheels.
- 9 Lift the wheels off the ground and then place jack stands under the drive chassis for support.
- 10 Disengage the torque hubs by turning over the torque hub disconnect caps on each steer wheel hub.




- 11 Manually rotate each steer wheel.
- ⦿ Result: Each steer wheel should rotate with minimum effort.
- 12 Re-engage the torque hubs by turning over the hub disconnect caps. Carefully remove the jack stands, lower the machine and remove the jack.

⚠ WARNING Collision hazard. Failure to re-engage the torque hubs may cause death or serious injury and property damage.

TABLE C PROCEDURES

All models:

- 13 Be sure the free-wheel valve on the drive pump is closed (clockwise).



- a drive pump
b free-wheel valve
c screwdriver
d lift pump

NOTICE

The free-wheel valve should always remain closed.

C-4**Grease the Turntable Rotation Bearing and Rotate Gear**

Yearly application of lubrication to the turntable bearing and rotate gear is essential to good machine performance and service life. Continued use of an improperly greased bearing and gear will result in component damage.

- 1 Locate the grease fitting on the platform end of the tank side bulkhead.
- 2 Pump grease into the turntable rotation bearing. Rotate the turntable in increments of 4 to 5 inches (10 to 13 cm) at a time and repeat this step until the entire bearing has been greased.
- 3 Apply grease to each tooth of the drive gear, located under the turntable.

Oil type

Multipurpose grease

C-5**Replace the Torque Hub Oil**


Replacing the torque hub oil is essential for good machine performance and service life. Failure to replace the torque hub oil at yearly intervals may cause the machine to perform poorly and continued use may cause component damage.

Drive Torque Hubs:

- 1 Select the drive torque hub to be serviced. Then drive the machine until one of the two plugs is at the lowest point.
- 2 Remove both plugs and drain the oil.

TABLE C PROCEDURES

- 3 Drive the machine until one plug is at the top and the other is at 90 degrees.




- 4 Fill the hub with oil from the top hole until the oil level is even with the bottom of the side hole. Apply pipe thread sealant to the plugs, and then install the plugs.
- 5 Repeat steps 1 through 4 for all the other drive torque hubs.

Oil capacity per hub 17 fluid ounces
0.51 liters


Type: SAE 90 multipurpose hypoid gear oil - API service classification GL5

Turntable Rotate Torque Hub

- 1 Secure the turntable from rotating with the turntable rotation lock pin.



- 2 Remove the motor/brake mounting bolts, and then remove the motor and brake from the torque hub and set them to the side.



a motor/brake mounting bolt
b motor
c torque hub
d torque hub mounting bolt
e plug
f brake

- 3 Remove the torque hub mounting bolts, and then remove the torque hub from the machine.
- 4 Remove the plug from the side of the torque hub. Then drain the oil from the hub.
- 5 Install the torque hub. Torque the hub mounting bolts to 180 foot-pounds (244 Newton meters).
- 6 Install the brake and motor onto the torque hub.
- 7 Fill the hub with oil from the side hole until the oil level is even with the bottom of the hole. Apply pipe thread sealant to the plugs, and then install the plugs.

Capacity 8 fluid ounces
0.24 liters

Type: SAE 90 multipurpose hypoid gear oil - API service classification GL5

TABLE C PROCEDURES

C-6**Replace the Hydraulic Tank Filter**

Replacement of the hydraulic tank filter is essential for good machine performance and service life. A dirty or clogged filter may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often.

CAUTION Beware of hot oil. Contact with hot oil may cause severe burns.

NOTICE Perform this procedure with the engine off.

- 1 Remove the filter with an oil filter wrench.
- 2 Apply a thin layer of oil to the new oil filter gasket.
- 3 Install the new filter (part no. 20293) and tighten it securely by hand. Clean up any oil that may have spilled during the installation procedure.
- 4 Start the engine from the ground controls.
- 5 Inspect the filter and related components to be sure that there are no leaks.

C-7**Replace the Drive Loop Hydraulic Filter**

Replacing the drive loop hydraulic filter is essential to good machine performance and service life. A dirty or clogged filter may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often.

CAUTION Beware of hot oil. Contact with hot oil may cause severe burns.

NOTICE Perform this procedure with the engine off.

- 1 Open the engine side turntable cover and locate the drive loop hydraulic filter mounted on the engine near the main pump.
- 2 Rotate the filter housing counterclockwise and remove the housing.
- 3 Remove the filter element from the housing.
- 4 Inspect the housing seal and replace it if necessary.
- 5 Install the new filter (part no. 20880) and hand tighten the housing onto the filter head. Clean up any oil that may have spilled during the installation procedure.
- 6 Start the engine from the ground controls.
- 7 Inspect the filter assembly to be sure that there are no leaks.

TABLE C PROCEDURES


C-8**Replace the Diesel Fuel Filter - Deutz Diesel Models**

Replacing the diesel fuel filter is essential to good engine performance and service life. A dirty or clogged filter may cause the engine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often.

⚠ DANGER Engine fuels are combustible. Replace the fuel filter in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

NOTICE Perform this procedure with the engine off.

- 1 Turn the manual fuel shutoff valve, located at the fuel tank, to the **CLOSED** position.
- 2 Remove the fuel filter with a filter wrench.



- 3 Apply a thin layer of oil or diesel fuel to the new fuel filter gasket.
- 4 Install the new filter (part no. 29560) and tighten it securely by hand. Clean up any diesel fuel that might have spilled during the procedure.
- 5 Turn the manual fuel shutoff valve, located at the fuel tank, to the **OPEN** position.
- 6 Start the engine from the ground controls, then inspect the fuel filter for leaks.

⚠ DANGER If a fuel leak is discovered, keep any additional personnel from entering the area and do not operate the machine. Repair the leak immediately.

C-9**Replace the Gasoline Fuel Filter - Gasoline/LPG Models**


Replacing the gasoline fuel filter is essential to good engine performance and service life. A dirty or clogged filter may cause the engine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often.

⚠ DANGER Engine fuels are combustible. Replace the fuel filter in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

NOTICE Perform this procedure with the engine off.


TABLE C PROCEDURES

- 1 Remove the 2 bolts from the engine pivot plate. Swing the engine pivot plate away from the machine to access the fuel filter, located near the carburetor.



- a pivot plate retaining bolts
b engine pivot plate

- 2 Loosen the filter bracket mounting bolt. Disconnect the fuel hoses from the filter, then slide the filter out of the bracket.



Gasoline/LPG models

- a fuel filter
b hose from the fuel filter to the carburetor
c hose from the fuel pump to the fuel filter
d hose from the fuel shutoff valve to the fuel pump

- 3 Install the new fuel filter in the bracket with the flow direction arrow on the filter, pointing toward the carburetor. Tighten the bracket mounting bolt, then connect the fuel hoses to the filter.
- 4 Clean up any fuel that may have spilled during the installation procedure.
- 5 Start the machine from the ground controls, then inspect the fuel filter and hoses for leaks.

⚠ DANGER

If a fuel leak is discovered, keep any additional personnel from entering the area and do not operate the machine. Repair the leak immediately.

- 6 Swing the engine pivot plate back to its original position and replace the two retaining bolts.

TABLE C PROCEDURES


C-10

Replace the PCV Valve - Gasoline/LPG Models

Yearly replacement of the PCV valve is essential to good engine performance. A malfunctioning valve can impair crankcase ventilation and may cause engine damage.


NOTICE Perform this procedure with the engine off.

- 1 Remove the 2 bolts from the engine pivot plate. Swing the engine pivot plate away from the machine to access the PCV valve.



- a pivot plate retaining bolts
b engine pivot plate

- 2 Remove the hoses from the PCV valve, then remove the valve.



Shown with distributor cap removed

- a PCV valve
b hose, PCV valve to carburetor
c hose, PCV valve to crankcase

- 3 Install the new PCV valve. Connect the hoses.
- 4 Swing the engine pivot plate back to its original position and replace the two retaining bolts.

C-11


Clean or Replace the Distributor Cap and Rotor - Gasoline/LPG Models

A distributor cap and rotor that are clean and free of damage, wear and corrosion are essential to good engine performance and service life. A dirty or worn cap and rotor may cause the engine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the cap and rotor be replaced more often.

NOTICE Perform this procedure with the engine off.

TABLE C PROCEDURES

- 1 Remove the 2 bolts from the engine pivot plate. Swing the engine pivot plate away from the machine to access the distributor.



- 2 Label and disconnect the coil and spark plug wires from the distributor cap.
- 3 Remove the cap and rotor from the distributor.
- 4 Clean the cap and rotor using electrical contact cleaner or a damp cloth.
- 5 Completely dry the cap and rotor.

NOTICE Moisture in the distributor cap will cause the engine to run poorly.

- 6 Inspect the cap and rotor for corrosion, cracks and abrasion. Replace the cap and rotor if they are damaged.
- 7 Install the rotor and cap, then connect the coil and spark plug wires.
- 8 Swing the engine pivot plate back to its original position and replace the two retaining bolts.
- 9 Start the engine from the ground controls and check the engine for proper operation.

C-12 Replace the Spark Plugs - Gasoline/LPG Models

Periodic replacement of the spark plugs is essential to good engine performance and service life. Worn, loose or corroded spark plugs will cause the engine to perform poorly and may result in component damage.

NOTICE Perform this procedure with the engine off.

- 1 Label, then disconnect the plug wires from the spark plugs by grasping the molded boot. Do not pull on the plug wire.
- 2 Blow out any debris around spark plugs.
- 3 Remove all the spark plugs from the engine.
- 4 Adjust the gap on each new spark plug.
- 5 Install the new spark plugs, then connect the wires. Be sure that each spark plug wire is attached to the correct spark plug.

Spark plug specifications

Spark plug type	Motorcraft AWSF-42
Spark plug gap	0.042 to 0.046 inches 1.07 to 1.18 mm
Spark plug torque	5 to 10 foot-pounds 7 to 14 Nm

TABLE C PROCEDURES

C-13**Check and Adjust the Air/LPG Mixture - Gasoline/LPG Models**

Maintaining the proper air-to-fuel mixture during LPG operation is essential to good engine performance.


⚠ DANGER Engine fuels are combustible. Perform this procedure in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

NOTICE The engine rpm needs to be preset for gasoline fuel operation before adjusting the LPG idle mixture. Refer to B-12, *Check and Adjust the Engine RPM*.

NOTICE The engine should be warmed to normal operating temperature before performing this procedure.

- 1 Move the fuel select switch to LPG fuel and start the engine from the ground controls.

- 2 Loosen the high idle mixture adjustment lock nut.




a high idle mixture adjustment screw

- 3 Load the system by pressing the boom retract switch, then move the engine idle control switch to high idle (rabbit symbol).
- 4 Adjust the high idle adjustment screw to obtain an air-to-fuel mixture ratio of 13.0:1 to 13.2:1, using an exhaust gas analyzer.

NOTICE If an exhaust gas analyzer is not available, adjust to obtain peak or optimum rpm.

TABLE C PROCEDURES

- 5 Hold the adjustment screw and tighten the lock nut.
- 6 Move the engine idle control switch to low idle (turtle symbol) and adjust the low idle screw to obtain an air-to-fuel mixture ratio of 13.0:1 to 13.2:1.



a low idle mixture adjustment screw

C-14

Check and Adjust the Ignition Timing - Gasoline/LPG Models

Complete information to perform this procedure is available in the *Ford LSG-423 2.3 Liter Industrial Engine Service Manual* (Ford number: 194-216). Genie part number 29586.

C-15

Check the Engine Valve Clearances - Deutz Diesel Models

Complete information to perform this procedure is available in the *Deutz FL 1011 Workshop Manual* (Deutz Number 02611642). Genie part number 29789.

Table D Procedures

D-1

Test or Replace the Hydraulic Oil

Replacement or testing of the hydraulic oil is essential for good machine performance and service life. Dirty oil and suction strainers may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require oil changes to be performed more often.


NOTICE

The machine uses Dexron II equivalent hydraulic oil. Before replacing the hydraulic oil, the oil may be tested by an oil distributor for specific levels of contamination to verify that changing the oil is necessary. **If the hydraulic oil is not replaced at the two year inspection, quarterly testing (B-26) thereafter should be completed.**

NOTICE

Perform this procedure with the boom in the stowed position.

- 1 Close the two hydraulic shutoff valves located at the hydraulic tank.



CAUTION

Component damage hazard. The engine must not be started with the hydraulic tank shutoff valves in the **CLOSED** position or component damage will occur. If the tank valves are closed, remove the key from the key switch and tag the machine to inform personnel of the condition.

- 2 Remove the drain plug from the hydraulic tank.
- 3 Completely drain the tank into a suitable container. See capacity specifications listed below.
- 4 Disconnect and cap the two suction hoses that are attached to the hydraulic tank shutoff valves.
- 5 Remove the strainer assemblies from the tank.
- 6 Carefully clean any foreign material from the strainers. Clean the strainers from the inside out.
- 7 Apply pipe thread sealant to the strainer mounting threads, and then install them.
- 8 Apply pipe thread sealant to the drain plug, and then install it in the tank.
- 9 Install the two suction hoses.
- 10 Fill the tank with hydraulic oil until the level is within the top 2 inches (5 cm) of the sight gauge. Do not overfill.
- 11 Clean up any oil that may have spilled and open the hydraulic tank valves.
- 12 Prime the pump by doing the following:

Connect a 0 to 600 psi (0 to 41 bar) pressure gauge to the test port on the drive pump.

Gasoline/LPG models:

Remove the high tension lead from the center of the ignition coil.


WARNING

Electrocution hazard. Contact with electrically charged circuits may cause death or serious injury. Remove all rings, watches and other jewelry.

TABLE D PROCEDURES

Deutz Diesel models:

Hold the manual fuel shutoff valve counterclockwise to the CLOSED position.



a manual fuel shutoff valve

All models:

Crank the engine with the starter motor for 15 seconds, wait 15 seconds, then crank the engine an additional 15 seconds or until the pressure reaches 320 psi (22 bar).

- 13 Connect the wiring and start the engine from the ground controls. Check the hydraulic tank for leaks.

Hydraulic system

Hydraulic tank capacity	45 gallons 170 liters
Hydraulic system capacity (including tank)	50 gallons 189 liters
Hydraulic fluid	Dexron II equivalent

D-2

Change or Recondition the Engine Coolant

- Gasoline/LPG Models

Replacing or reconditioning the engine coolant is essential to good engine performance and service life. Old or dirty coolant may cause the engine to perform poorly and continued use may cause engine damage. Extremely dirty conditions may require coolant to be changed more frequently.

CAUTION

Beware of hot engine parts and coolant. Contact with hot engine parts and/or coolant will cause severe burns.


NOTICE

Perform this procedure with the engine off and cooled.

- 1 Put on protective clothing and eye wear.
- 2 Disconnect the coolant return hose at the radiator and drain the coolant return tank.
- 3 Remove the radiator cap from the radiator.

TABLE D PROCEDURES


- 4 Remove the 2 bolts from the engine pivot plate. Swing the engine pivot plate away from the machine to access the radiator petcock.



a pivot plate retaining bolts
b engine pivot plate

- 5 Open the petcock on the radiator and allow all the coolant to drain into a container.
- 6 After all the coolant has drained, close the petcock. Connect the coolant return hose to the radiator.
- 7 Open the petcock on the engine block and allow the coolant to drain into a container. After the fluid is drained, close the petcock.
- 8 Replace all coolant hoses and clamps.
- 9 Pour the proper coolant mixture (anti-freeze and water) for your climate into the radiator until it is full.

- 10 Disconnect hose A from hard line B and hold until coolant starts to pour out of the open hose. Then immediately reconnect the hose.



a hose A
b hard line B

- 11 Fill the radiator and then fill the coolant recovery tank to the NORMAL range.
- 12 Clean up any coolant spilled during this procedure.
- 13 Start the engine from the ground controls, run it for 30 seconds, and then turn it off.
- 14 Inspect for leaks and then check the fluid level in the coolant recovery tank. Add water if needed.
- 15 Start the engine from the ground controls and run it until reaching normal operating temperature.
- 16 Allow engine to cool and check the fluid level in the coolant recovery tank. Add water if needed.

Ford Engine LSG-423
Coolant capacity

11.5 quarts
10.9 liters

TABLE D PROCEDURES

D-3**Change the Fuel Lines**


Maintaining the fuel lines in good condition is essential to safe operation and good engine performance. Failure to detect a worn, cracked or leaking fuel line may cause an unsafe operating condition.

⚠ DANGER Engine fuels are combustible. Replace the fuel lines in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

NOTICE Perform this procedure with the engine off.

- 1 Close the manual fuel shutoff valve, located next to the fuel tank.
- 2 Remove and replace the fuel line hoses and clamps according to the following illustrations:


⚠ DANGER Fuel may be expelled under pressure. Wrap a cloth around fuel hoses to absorb leaking fuel before disconnecting them.



Deutz Diesel models

- a hose from the injector to the fuel tank
- b hoses connecting injectors
- c hose from the fuel shutoff valve to the fuel pump
- d hose from the fuel pump to the fuel filter
- e hose from the fuel filter to the injection pump
- f hose from the injection pump to the injectors

TABLE D PROCEDURES



Gasoline/LPG models

- a fuel filter
- b hose from the fuel filter to the carburetor
- c hose from the fuel pump to the fuel filter
- d hose from the fuel shutoff valve to the fuel pump

- 3 Clean up any fuel that may have spilled during this procedure.
- 4 Start the engine from the ground controls, then inspect the fuel filter and hoses for leaks.

⚠ DANGER

If a fuel leak is discovered, keep any additional personnel from entering the area and do not operate the machine. Repair the leak immediately.

D-4 Check the Engine Valve Clearance - Gasoline/LPG Models

Complete information to perform this procedure is available in the *Ford LSG-423 2.3 Liter Industrial Engine Service Manual* (Ford number: 194-216). Genie part number 29586.

D-5 Check the Engine Cylinder Compression - Gasoline/LPG Models

Complete information to perform this procedure is available in the *Ford LSG-423 2.3 Liter Industrial Engine Service Manual* (Ford number: 194-216). Genie part number 29586.

TABLE D PROCEDURES


D-6 Clean the PCV Hoses and Fittings - Gasoline/LPG Models

Maintaining PCV hoses is essential to good engine performance. Improperly functioning PCV hoses will fail to ventilate the crankcase and continued use of neglected hoses could result in component damage.

NOTICE


Perform this procedure with the engine off.

- 1 Remove the 2 bolts from the engine pivot plate. Swing the engine pivot plate away from the machine to access the PCV hoses.



- a pivot plate retaining bolts
b engine pivot plate

- 2 Disconnect the hoses from the PCV valve, then disconnect the hoses from the engine.



Shown with distributor cap removed

- a PCV valve
b hose, PCV valve to carburetor
c hose, PCV valve to crankcase

- 3 Clean the hoses with a mild cleaning solvent.
- 4 Dry both hoses and inspect them for cracks and damage. Replace the hoses if they are damaged.

TABLE D PROCEDURES

D-7**Check the Fuel Injection Pumps and Injectors****- Deutz Diesel Models**

Complete information to perform this procedure is available in the *Deutz FL 1011 Workshop Manual* (Deutz number: 0291 1942). Genie part number 29789.

D-8**Check the Toothed Belt****- Deutz Diesel Models**

Complete information to perform this procedure is available in the *Deutz FL 1011 Operation Manual* (Deutz number: 0297 4706 EN). Genie part number 29790.

D-9**Replace the Timing Belt****- Gasoline/LPG Models**

Complete information to perform this procedure is available in the *Ford LSG-423 2.3 Liter Industrial Engine Service Manual* (Ford number: 194-216). Genie part number 29586.

Troubleshooting Flow Charts



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.
- ☑ Unless otherwise specified, perform each repair procedure with the machine in the following configuration:
 - machine parked on a flat level surface
 - boom in stowed position
 - turntable rotated with the boom between the non-steering wheels
 - turntable secured with the turntable rotation lock pin
 - key switch in the OFF position with the key removed
 - wheels chocked

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions printed in the *Genie S-40 Operator's Manual*.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.
- ☑ Read each appropriate flow chart thoroughly. Attempting shortcuts may produce hazardous conditions.
- ☑ Be aware of the following hazards and follow generally accepted safe workshop practices.

⚠ DANGER

Crushing hazard. When testing or replacing any hydraulic component, always support the structure and secure it from movement.

⚠ DANGER

Electrocution hazard. Contact with electrically charged circuits may result in death or serious injury. Remove all rings, watches and other jewelry.

⚠ WARNING

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

NOTICE

Perform all troubleshooting on a firm level surface.

NOTICE

Two persons will be required to safely perform some troubleshooting procedures.

TROUBLESHOOTING FLOW CHARTS

About This Section

When a malfunction is discovered, the flow charts in this section will help a service professional pinpoint the cause of the problem. To use this section, basic hand tools and certain pieces of test equipment are required—voltmeter, ohmmeter, pressure gauges.

The location of terminals mentioned in this section can be found on the appropriate electrical or hydraulic schematics provided in Section 6, *Schematics*.

Since various degrees of a particular function loss may occur, selecting the appropriate flow chart may be troublesome. When a function will not operate with the same speed or power as a machine in good working condition, refer to the flow chart which most closely describes the problem.

General Repair Process




Chart 1

Engine Will Not Crank Over

Be sure the key switch is in the appropriate position.

Be sure the emergency stop buttons are pulled up into the on position.

Be sure the circuit breaker(s) are not tripped.




CHART 1




Chart 2

Engine Cranks Over But Will Not Start - Gasoline/LPG Models

Be sure to check the engine oil level and fill as needed.

Be sure to check fuel levels and engine coolant level.

Be sure the gasoline shut-off valve is in the on position.

Be sure that automatic choke is not sticking closed.

Perform following tests in gasoline mode only.




CHART 2




CHART 2




Chart 2A

Engine Cranks Over But Will Not Start - Gasoline/LPG Models

or

Engine Runs While Cranking Then Dies

Continuation of "good spark" fault path.

Perform these tests in gasoline mode only.




CHART 2A




CHART 2A




Chart 2B

Engine Runs While Cranking Then Dies




Chart 3

Engine Cranks Over But Will Not Start - Deutz Diesel Models

Be sure to check the engine oil level and fill as needed.

Be sure to check fuel level.

Be sure the diesel shut-off valve is in the on position.




CHART 3




CHART 3




Chart 4

Engine Will Not Start On LPG, But Will Start On Gasoline - Gasoline/LPG Models

Be sure fuel select switch is switched to LPG.

Be sure to check LPG fuel level.




CHART 4




Chart 5

Engine Will Not Start On Gasoline, But Will Start On LPG - Gasoline/LPG Models

Be sure fuel select switch is switched to gasoline.

Be sure to check gasoline fuel level.

Be sure that engine choke is operating properly.




CHART 5




Chart 6

Engine High Idle Inoperative - Gasoline/LPG Models

If high idle operates on LPG but not on gasoline, see Ford service manual for carburetor troubleshooting.

If high idle operates on gasoline but not on LPG, see Repair section for LPG regulator adjustments.

Be sure throttle linkage from governor to carburetor is not binding, see Repair section.

Be sure high idle can be achieved by grasping the governor actuator arm and momentarily pulling to throttle the carburetor.




CHART 6




Chart 7

Engine Low Idle Inoperative - Gasoline/LPG Models

If low idle operates on LPG but not on gasoline, see Ford service manual for carburetor troubleshooting.

If low idle operates on gasoline but not on LPG, see Repair section for LPG regulator adjustments.

Be sure throttle linkage from governor to carburetor is not binding, see Repair section.




Chart 8

Engine High Idle Inoperative - Deutz Diesel Models

Be sure mechanical linkage is not binding or defective.

Be sure PR2 relay and 2-speed solenoid grounding wires are free of corrosion and have full continuity to ground.




CHART 8




Chart 9

Engine Low Idle Inoperative - Deutz Diesel Models

Check if mechanical linkage from 2-speed solenoid to fuel injection system is binding or defective.




Chart 10

All Functions Inoperative, Engine Starts and Runs




Chart 11

All Lift and Steer Functions Inoperative, Drive Functions Operational

Be sure the hydraulic suction line shutoff valve for the lift/steer pump is in the open position.

Be sure all grounding wires for the hydraulic manifold valves are free of corrosion and have full continuity to ground.




Chart 12

Ground Controls Inoperative, Platform Controls Operate Normally

Be sure all other functions operate normally, including platform controls.




Chart 13

Platform Controls Inoperative, Ground Controls Operate Normally

Be sure all cables are in good condition with no kinks or abrasions.




Chart 14

Boom Up Function Inoperative

Be sure all other functions operate normally.

If boom up function operates normally from the ground controls but not from the platform controls, troubleshoot the platform controller. See Repair section.

If boom up function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




CHART 14




Chart 15

Boom Down Function Inoperative

Be sure all other functions operate normally including boom up function.

If boom down function operates normally from the ground controls but not from the platform controls, troubleshoot the platform controller. See Repair section.

If boom down function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




CHART 15




Chart 16

Boom Extend Function Inoperative

Be sure all other functions operate normally.

If boom extend function operates normally from the ground controls but not from the platform controls, troubleshoot the platform controller. See Repair section.

If boom extend function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




CHART 16




Chart 17

Boom Retract Function Inoperative

Be sure all other functions operate normally including boom extend function.

If boom retract function operates normally from the ground controls but not from the platform controls, troubleshoot the platform controller. See Repair section.

If boom retract function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




Chart 18

Turntable Rotate Function Inoperative

Be sure all other functions operate normally.

If turntable rotate function operates normally from the ground controls but not from the platform controls, troubleshoot the platform controller. See Repair section.

If turntable rotate function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




CHART 18




Chart 19

Turntable Rotate Left Function Inoperative

Be sure all other functions operate normally including turntable rotate right function.

If turntable rotate left function operates normally from the ground controls but not from the platform controls, troubleshoot the platform controller. See Repair section.

If turntable rotate left function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




Chart 20

Turntable Rotate Right Function Inoperative

Be sure all other functions operate normally including turntable rotate right function.

If turntable rotate right function operates normally from the ground controls but not from the platform controls, troubleshoot the platform controller. See Repair section.

If turntable rotate right function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




Chart 21

All Platform Leveling Functions Inoperative

Be sure all other functions operate normally.

Be sure both automatic and manual platform leveling do not operate.

If automatic leveling operates but manual leveling does not, troubleshoot *Platform Leveling Up Function Inoperative*.




Chart 22

Platform Level Up Function Inoperative

Be sure all other functions operate normally.

If platform level up function operates normally from the ground controls but not from the platform controls, troubleshoot the platform control toggle switch. See Repair section.

If platform level up function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




Chart 23

Platform Level Down Function Inoperative

Be sure all other functions operate normally.

If platform level down function operates normally from the ground controls but not from the platform controls, troubleshoot the platform control toggle switch. See Repair section.

If platform level down function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




Chart 24

Platform Rotate Left Function Inoperative

Be sure all other functions operate normally.

If platform rotate left function operates normally from the ground controls but not from the platform controls, troubleshoot the platform control toggle switch. See Repair section.

If platform rotate left function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




Chart 25

Platform Rotate Right Function Inoperative

Be sure all other functions operate normally.

If platform rotate right function operates normally from the ground controls but not from the platform controls, troubleshoot the platform control toggle switch. See Repair section.

If platform rotate right function operates normally from the platform controls but not from the ground controls, troubleshoot the ground control toggle switch. See Repair section.




Chart 26

Oscillate Function Inoperative

Be sure all other function operate normally.




Chart 27

Steer Left Function Inoperative

Be sure all other functions operate normally.




Chart 28

Steer Right Function Inoperative

Be sure all other functions operate normally.




Chart 29

All Drive Functions Inoperative, All Other Functions Operate Normally

Be sure the hydraulic suction line valve is in the open position.

Be sure machine is not in the free wheel configuration.




CHART 29




CHART 29




Chart 30

Drive Forward Or Reverse Function Inoperative

Be sure all other functions operate normally including drive in opposite direction of malfunction.




Chart 31

Traction Function Inoperative

Be sure all other functions operate normally.

Any type of traction problem, consult Genie Industries Service Department.

Chart 32

Machine Will Not Drive At Full Speed

Be sure all other functions operate normally.

Be sure the free-wheel valve is closed on the drive pump.




Chart 33

Machine Drives At Full Speed With Platform Raised or Extended

Remove machine from service immediately.

Be sure boom lift drive limit switch or boom extend drive limit switch is not being held down or up.

Be sure wiring to limit switches is intact and shows no sign of tampering.

Be sure orange wire (cable 1) is properly attached to horsepower limiter.




Chart 34

Drive Enable System Is Malfunctioning




Chart 35


Auxiliary Functions Inoperative

Be sure all other functions operate normally.

Be sure key switch is in the appropriate position and the emergency stop buttons are pulled up into the on position.

Be sure engine is not running when using auxiliary power.

Note: Operating auxiliary power with the engine running should immediately kill the engine.



Schematics



Observe and Obey:

- ☑ Troubleshooting and repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Troubleshooting:

- ☑ Read, understand and obey the safety rules and operating instructions printed in the *Genie S-40 Operator's Manual*.
- ☑ Be sure that all necessary tools and test equipment are available and ready for use.

About This Section

There are two groups of schematics in this section. An illustration legend precedes each group of drawings.


Electrical Schematics

⚠WARNING Electrocution hazard. Contact with electrically charged circuits may result in death or serious injury. Remove all rings, watches and other jewelry.







































Hydraulic Schematics

⚠WARNING Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.


General Repair Process




Electrical Symbols Legend

 <p>Wire color with cable number</p>	 <p>Circuit breaker</p>	 <p>Ground suppression circuit</p>	 <p>Water temperature switch normally closed</p>	 <p>Starter motor relay</p>
 <p>Terminal</p>	 <p>Solenoid or relay coil</p>	 <p>Limit switch</p>	 <p>Foot switch</p>	 <p>Time delay relay</p>
 <p>Quick disconnect terminal</p>	 <p>Horn</p>	 <p>Limit switch normally open held closed</p>	 <p>Key switch</p>	 <p>Time delay relay</p>
 <p>T-circuits connect at terminal</p>	 <p>Light</p>	 <p>Limit switch normally open held closed</p>	 <p>Horn button normally open</p>	 <p>Toggle switch SPDI</p>
 <p>T-circuits connect</p>	 <p>Resistor</p>	 <p>Limit switch normally closed held open</p>	 <p>Emergency Stop button normally closed</p>	 <p>Toggle switch DPDT</p>
 <p>Connection no terminal</p>	 <p>Tilt sensor</p>	 <p>Vacuum switch</p>	 <p>Relay contact normally open</p>	 <p>Single axis proportional controller</p>
 <p>Circuits crossing no connection</p>	 <p>Spark plug</p>	 <p>Oil pressure switch normally closed</p>	 <p>Relay panel contactor</p>	 <p>Dual axis proportional controller</p>
 <p>Diode</p>	 <p>Glow plug</p>			
 <p>Battery</p>				


**Electrical Schematic -
Gasoline/LPG Models**




Electrical Schematic -
Gasoline/LPG Models




Electrical Schematic - Gasoline/LPG Models




Ground Control Box Legend -
Gasoline/LPG Models




Relay Panel Legend -
Gasoline/LPG Models




Platform Control Box Legend -
Gasoline/LPG Models




**Electrical Schematic -
Diesel Models**




Electrical Schematic -
Diesel Models




Electrical Schematic - Diesel Models




Ground Control Box Legend - Diesel Models































Platform Control Box Legend - Diesel Models




2WD Hydraulic Schematic
- Non-Oscilating Axle




Hydraulic Symbols Legend

			
Pressure gauge	Cylinder	Differential sensing valve	Solenoid operated 2 pos., 4 way, directional valve
			
Filter	Accumulator	Solenoid operated proportional valve	Solenoid operated 3 pos., 4 way, directional valve (DO1)
			
Fixed displacement pump	Orifice with size 0.035	Flow regulator valve	2 pos., 3 way, shuttle valve
			
Bi-directional, variable displacement pump	Variable orifice or shut-off valve	Solenoid operated 2 pos., 3 way, directional valve	3 pos., 4 way, directional valve
			
Bi-directional motor	Check valve	Counterbalance valve	Sequencing valve
			
2-speed, bi-directional motor	Priority flow divider	Pilot operated flow control valve	Unloader valve
			
Pump prime mover (engine or motor)	Solenoid operated dump valve	Pressure compensating valve	Pressure compensating valve


2WD Hydraulic Schematic
- Non-Oscilating Axle




2WD Hydraulic Schematic - Oscilating Axle




2WD Hydraulic Schematic
Oscilating Axle





4WD Hydraulic Schematic



4WD Hydraulic Schematic





Repair Procedures



Observe and Obey:

- ☑ Repair procedures shall be completed by a person trained and qualified on the repair of this machine.
- ☑ Immediately tag and remove from service a damaged or malfunctioning machine.
- ☑ Repair any machine damage or malfunction before operating the machine.

Before Repairs Start:


- ☑ Read, understand and obey the safety rules and operating instructions in the *Genie S-40 Operator's Manual*.
- ☑ Be sure that all necessary tools and parts are available and ready for use.
- ☑ Read each procedure completely and adhere to the instructions. Attempting shortcuts may produce hazardous conditions.
- ☑ Unless otherwise specified, perform each repair procedure with the machine in the following configuration:
 - machine parked on a flat, level surface
 - boom in stowed position
 - turntable rotated with the boom between the non-steering wheels
 - turntable secured with the turntable rotation lock pin
 - key switch in the OFF position with the key removed
 - wheels chocked

About This Section

Most of the procedures in this section should only be performed by a trained service professional in a suitably equipped workshop. Select the appropriate repair procedure after troubleshooting the problem.

Perform disassembly procedures to the point where repairs can be completed. Then to re-assemble, perform the disassembly steps in reverse order.

General Repair Process



Symbols Legend

⚠ DANGER Indicates the presence of a hazard that **will** cause death or serious injury.

⚠ WARNING Indicates the presence of a hazard that **may** cause death or serious injury.

⚠ CAUTION Indicates the presence of a hazard that **will** or **may** cause serious personal injury or damage to the machine.


ℹ NOTICE Indicates normal operation or maintenance information.

- ⦿ Indicates that a specific result is expected after performing a series of steps.

Platform Controls


1-1 Joystick Controllers

Maintaining joystick controllers at the proper settings is essential to safe machine operation. Every joystick controller should operate smoothly and provide proportional speed control over its entire range of motion.



Platform control box
 a horsepower limiter board
 b quick disconnect terminal strip
 c drive proportional controller
 d boom proportional controller
 e turntable rotate proportional controller

- 1 Check the battery condition with a volt meter. The reading should be 12V DC or more to accurately adjust the controller.
- 2 Turn the key switch to platform control and pull out the Emergency Stop button to the ON position at both the ground and platform controls. Do not start the engine.
- 3 Open the platform control box lid and locate the boom up/down controller.



a ramp rate adjustable trimpot
 b dual (lo) range adjustable trimpot
 c terminal "R", activates max-out range
 d terminal unused
 e terminal "X", auxiliary
 f terminal "-", ground
 g terminal "+", battery, positive
 h terminal "A", proportional output
 i threshold adjustable trimpot
 j max-out adjustable trimpot

Boom Up/Down Controller Adjustments

NOTICE

Do not adjust the joystick controllers unless the static battery voltage is above 12V DC and the alternator is operating properly with 12.5 to 14.5V DC output.

WARNING

Electrocution hazard. Contact with electrically charged circuits may result in death or serious injury. Remove all rings, watches and other jewelry.

- 4 Set the preliminary ramp rate: Turn the trimpot adjustment screw clockwise 15 turns or until you hear a repeated click.
- 5 Connect the red(+) lead from a volt meter to the "A" terminal on the controller printed circuit board. Connect the black(-) lead to ground.
- 6 Set the threshold: Press down the foot switch, then slowly move the control handle off center until the moment a voltage reading appears. Adjust the voltage to 2.5V DC. Turn the threshold trimpot adjustment screw clockwise to increase the voltage or counterclockwise to decrease the voltage.

PLATFORM CONTROLS

- 7 Set the max-out: Press down the foot switch, then move the control handle all the way to the UP position. Adjust the voltage to 5.9V DC. Turn the max-out trimpot adjustment screw clockwise to increase the voltage or counterclockwise to decrease the voltage.
- 8 Set the dual (lo) range: Press down the foot switch, then move the control handle all the way to the DOWN position. Adjust the voltage to 5.9V DC. Turn the dual range trimpot adjustment screw clockwise to increase the voltage or counterclockwise to decrease the voltage.
- 9 Start the engine and move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol). Lower the boom to the stowed position.

NOTICE Engine should be at normal operating temperature.

- 10 Start a timer and record how long it takes for the boom to fully raise. Adjust the max-out trimpot to achieve a 40 to 60 second cycle time.
- 11 Start a timer and record how long it takes for the boom to fully lower. Adjust the dual range trimpot to achieve an 50 to 80 second cycle time.

NOTICE If the function cycle time is not achievable, check the relief valve pressure. See 9-2, *Valve Adjustments - Function Manifold*.

- 12 Turn the engine off and re-connect the volt meter.
- 13 Pull out the Emergency Stop button to the ON position.
- 14 Press down the foot switch and then move the control handle all the way to the UP position. Record the maximum voltage reading.
- 15 Start the engine.

- 16 Start a timer and simultaneously move the control handle all the way to the UP position. Note how long it takes to reach the maximum voltage recorded in step 14. This is the ramp speed.
- 17 Set the ramp rate: turn the trimpot to obtain a 3 to 4 second ramp speed. Turn the trimpot clockwise to increase the time or counterclockwise to decrease the time.

Boom up/down specifications

Threshold	2.58V DC
Boom up - Max-out Cycle time	5.9V DC 40 to 60 seconds
Boom down - Dual (lo) range Cycle time	5.9V DC 50 to 80 seconds
Ramp rate	3 to 4 seconds

Turntable Rotation Controller Adjustments


NOTICE Do not adjust the joystick controllers unless the static battery voltage is above 12V DC and the alternator is operating properly with 12.5 to 14.5V DC output.

⚠WARNING Electrocution hazard. Contact with electrically charged circuits may result in death or serious injury. Remove all rings, watches and other jewelry.

- 1 Check the battery condition with a volt meter. The reading should be 12V DC or more to accurately adjust the controller.
- 2 Turn the key switch to platform control and pull out the Emergency Stop button to the ON position at both the ground and platform controls. Do not start the engine.

PLATFORM CONTROLS

- 3 Open the platform control box lid and locate the turntable rotation controller. Refer to the platform control box illustration, page 7-2.



- a ramp rate adjustable trimpot
- b dual (lo) range adjustable trimpot
- c terminal "R", activates max-out range
- d terminal unused
- e terminal "X", auxiliary
- f terminal "-", ground
- g terminal "+", battery, positive
- h terminal "A", proportional output
- i threshold adjustable trimpot
- j max-out adjustable trimpot

- 4 Set the preliminary ramp rate: Turn the trimpot adjustment screw clockwise 15 turns or until you hear a repeated click.
- 5 Connect the red(+) lead from a volt meter to the "A" terminal on the controller printed circuit board. Connect the black(-) lead to ground.
- 6 Set the threshold: Press down the foot switch, then slowly move the control handle off center until the moment a voltage reading appears. Adjust the voltage to 2.5V DC. Turn the threshold trimpot adjustment screw clockwise to increase the voltage or counterclockwise to decrease the voltage.
- 7 Set the dual (lo) range: Turn the trimpot adjustment screw clockwise 15 turns or until you hear a click. This is the only dual range adjustment for this controller.

- 8 Set the max-out: Press down the foot switch, then move the control handle all the way to the left or right. Adjust the voltage to 5.5V DC. Turn the max-out trimpot adjustment screw clockwise to increase the voltage or counterclockwise to decrease the voltage.
- 9 Start the engine and move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol).

NOTICE Be at normal operating temperature.

- 10 Start a timer and record how long it takes the turntable to rotate through a complete circle. Adjust the max-out trimpot to achieve a 70 to 110 second cycle time.
- 11 Turn the engine off and re-connect the volt meter.
- 12 Pull out the Emergency Stop button to the ON position.
- 13 Press down the foot switch and then move the control handle all the way to the left or right. Record the maximum voltage reading.
- 14 Start the engine.
- 15 Start a timer and simultaneously move the control handle all the way to the left or right. Note how long it takes to reach the maximum voltage recorded in step 13. This is the ramp rate.
- 16 Set the ramp rate: Turn the trimpot to obtain a 3 to 4 second ramp speed. Turn the trimpot clockwise to increase the time or counterclockwise to decrease the time.

Turntable rotation specifications

Threshold	2.5V DC
Turntable rotation - Max-out	5.5V DC
Cycle time	70 to 110 seconds
Ramp rate	3 to 4 seconds

PLATFORM CONTROLS

1-2 Horsepower Limiter Board

The horsepower limiter board is responsible for governing drive pump output. It senses engine rpm from the alternator. The horsepower limiter board senses drops in rpm normally due to increased drive resistance (rough terrain or incline), and decreases voltage to the drive controller which in turn decreases voltage to the drive pump, thereby reducing pump output to maintain optimum engine rpm and horsepower. Three adjustments are required for optimum performance.

How to Adjust the Horsepower Limiter Board

NOTICE

The engine rpm must be correct before performing this procedure. See Maintenance Procedure B-12, *Check and Adjust the Engine RPM*.

NOTICE

Do not adjust the horsepower limiter board unless the static battery voltage is above 12V DC and the alternator is operating properly with 12.5 to 14.5V DC output.


NOTICE

Gasoline/LPG models: Perform this procedure in gasoline mode.

- 1 Remove the fasteners from the platform control box lid.
- 2 Open the control box lid and locate the horsepower limiter board.


⚠ WARNING

Electrocution hazard. Contact with electrically charged circuits may result in death or serious injury. Remove all rings, watches and other jewelry.



Platform control box
a horsepower limiter board

- 3 Connect the black(-) lead from a DC volt meter to the no. 2 terminal, and the red(+) lead to the no. 10 terminal.



Horsepower limiter board

- a "A" potentiometer-maximum voltage output to the controller in the stowed position
- b "B" potentiometer-maximum voltage output to the drive controller in the boom raised position
- c "C" potentiometer-reaction rate or how fast the voltage output reacts to the change in engine rpm

- 4 Start the engine from the platform controls.
- 5 Move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol).

PLATFORM CONTROLS

- 6 Press down the foot switch and adjust the "A" potentiometer counterclockwise to increase voltage or clockwise to decrease voltage.

"A" potentiometer specifications - all models

Voltage setting	9.5V DC
-----------------	---------


- 7 Move the engine idle control switch to low idle (turtle symbol).
- 8 Press down the foot switch and then adjust the "C" potentiometer to obtain a 0.01V DC to 0.03V DC voltage reading.
- 9 Move the engine idle control switch to foot switch activated high idle (rabbit and foot switch symbol).
- 10 Press down the foot switch and re-adjust the "A" potentiometer to the previous voltage setting in step 6.
- 11 Be sure that the boom is in the stowed position, then drive the machine and observe how the engine rpm reacts to drive control handle movement. If the engine surges or hunts, adjust the "C" potentiometer counterclockwise until surging is minimized.

NOTICE

Under an extreme load, an excessive counterclockwise adjustment to the "C" potentiometer will cause the engine to stall. The "C" potentiometer adjustment is a compromise between engine stability (surging) and engine rpm droop.

- 12 Disconnect the volt meter.

- 13 Raise the boom above the drive limit switch.



- 14 Drive the machine for 40 feet (12 m) and record the elapsed time. Repeat this step in the opposite drive direction.
- 15 Adjust the "B" potentiometer to obtain the correct raised drive speed of 1 foot per second (30.5 cm per second). Turn the "B" potentiometer counterclockwise to increase voltage or clockwise to decrease voltage.
- 16 Close the platform control box lid and install the fasteners.

Drive speed specifications

Stowed position	distance: 40 ft / 12 m	
	2WD	4WD
Gasoline/LPG models	40 ft/6.8 sec 12.2 m/6.8 sec	40 ft/7.8 sec 12.2 m/7.8 sec
Deutz Diesel models	40 ft/7.8 sec 12.2 m/7.8 sec	40 ft/9.1 sec 12.2 m/9.1 sec
Boom raised or extended	distance: 40 ft / 12 m	
All models	1 foot per second 30.5 cm per second	

PLATFORM CONTROLS

1-3 Foot Switch

How to Test the Foot Switch

- 1 Turn the key switch to the OFF position and separate the wiring quick disconnect plug from the platform toe board.
- 2 Do not press down the foot switch. Connect the leads from an ohmmeter or continuity tester to each wire combination listed below and check for continuity.

Test	Desired result
green to black	continuity (zero Ω)
green to white	no continuity (infinite Ω)
black to white	no continuity

NOTICE Do not use the color of the connector as a guide for these tests. Use the actual wire color to identify which connector to use for testing.

- 3 Press down the foot switch. Connect the leads from an ohmmeter or continuity tester to each wire combination listed below and check for continuity.

Test	Desired result
green to black	no continuity (infinite Ω)
green to white	no continuity
black to white	continuity (zero Ω)

1-4 Resistors

The resistor is used to maintain proper control of boom extend/retract. The resistor is located in the platform control box.

NOTICE Refer to the schematic legends for resistor locations and values.

How to Test the Resistors

- 1 Turn the key switch to the OFF position.
- 2 Connect the leads from an ohmmeter to each end of the resistor being tested.
- 3 Compare the ohmmeter reading with the resistance rating printed on the resistor.

PLATFORM CONTROLS

1-5 Toggle Switches


Toggle switches used for single function switching are single pole double throw (SPDT) switches. Dual function switching requires a double pole double throw (DPDT) switch.

How to Test a Toggle Switch


NOTICE Continuity is the equivalent of 0 to 3 ohms. A simple continuity tester may not accurately test the switch.

This procedure covers fundamental switch testing and does not specifically apply to all varieties of toggle switches.


- 1 Turn the key switch to the OFF position. Tag and disconnect all wiring from the toggle switch to be tested.
- 2 Connect the leads of an ohmmeter to the switch terminals in the following combinations listed below to check for continuity.



Single pole
double throw
(SPDT)



Double pole
double throw
(DPDT)



Test	Desired result
Left position	
terminal 1 to 2, 3, 4, 5 & 6	no continuity (infinite Ω)
terminal 2 to 3	continuity (zero Ω)
terminal 2 to 4, 5 & 6	no continuity
terminal 3 to 4, 5 & 6	no continuity
terminal 4 to 5 & 6	no continuity
terminal 5 to 6	continuity
Center position	There are no terminal combinations that will produce continuity (infinite Ω)
Right position	
terminal 1 to 2	continuity (zero Ω)
terminal 1 to 3, 4, 5 & 6	no continuity (infinite Ω)
terminal 2 to 3, 4, 5 & 6	no continuity
terminal 3 to 4, 5 & 6	no continuity
terminal 4 to 5	continuity
terminal 4 to 6	no continuity
terminal 5 to 6	no continuity

Platform Components

2-1

Platform

How to Remove the Platform

- 1 Remove the cable harness from the cable clamp located on the platform mounting bracket and separate the foot switch quick disconnect plug.
- 2 Remove the platform control box mounting bolts, then lower the control box and set it aside.
- 3 Remove the platform mounting bolts and lift the platform off the mount.

any lifting pressure.

- 4 Remove the pin retainer fastener from both the barrel and rod-end pins.
- 5 Drive the rod-end pin out using a soft metal drift.
- 6 Manually pivot the rotator up and secure it to the boom.
- 7 Use a soft metal drift and drive the barrel-end pin out.
- 8 Carefully pull the cylinder out of the boom.
- 9 Disconnect the hydraulic hoses from the slave cylinder and connect them together with a connector. Cap the fittings on the cylinder.

2-2

Platform Leveling Slave Cylinder

The slave cylinder and the rotator pivot are the two primary supports for the platform. The slave cylinder keeps the platform level through the entire range of boom motion. It operates in a closed-circuit hydraulic loop with the master cylinder. The slave cylinder is equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure.

How to Remove the Slave Cylinder

NOTICE

Before cylinder removal is considered, bleed the slave cylinder to be sure there is no air in the closed loop.

- 1 Remove the platform. See 2-1, *How to Remove the Platform*.
- 2 Extend the boom until the slave cylinder barrel-end pivot pin is accessible.
- 3 Support the platform rotator, but do not apply

CAUTION

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

PLATFORM COMPONENTS

How to Bleed the Slave Cylinder

NOTICE

Do not start the engine. Use auxiliary power for all machine functions in this procedure.

- 1 Raise the boom to a horizontal position.
- 2 Move the platform level switch up and down through two platform leveling cycles to remove any air that might be in the system.

2-3

Platform Rotator

The platform rotator is a hydraulically activated helical gear assembly used to rotate the platform 160 degrees.

How to Remove the Platform Rotator

⚠CAUTION

Component damage hazard. Mark the platform mounting weldment and the rotator flange before removing the platform mounting weldment. The platform mounting weldment must be replaced in the exact same position on the rotator flange as it was before removal. If a new rotator is installed or the rotator is disassembled, proper alignment can be achieved by rotating the rotator all the way to the left and then installing the platform mounting weldment all the way in the left position.

- 1 Remove the platform. See 2-1, *How to Remove the Platform*.
- 2 Disconnect and plug the hydraulic hoses from the platform rotator.

⚠CAUTION

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Support the platform mounting weldment, but do not apply any lifting pressure.
- 4 Remove the six mounting bolts from the platform mounting weldment, then remove the center bolt and slide the platform mounting weldment off of the platform rotator.
- 5 Support the platform rotator. Do not apply any lifting pressure.

PLATFORM COMPONENTS

- 6 Support the platform leveling slave cylinder.
- 7 Remove the pin retainer from the slave cylinder barrel-end pivot pin.
- 8 Use a soft metal drift to remove the barrel-end pin.
- 9 Disconnect and plug the hydraulic hoses from the slave cylinder. Pull the hoses up through the platform rotator.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.


- 10 Remove the pin retainer from the slave cylinder rod-end pivot pin and the rotator pivot pin.
- 11 Use a soft metal drift to drive both pins out, then remove the platform rotator from the machine.

How to Bleed the Platform Rotator

NOTICE Do not start the engine. Use auxiliary power for all machine functions in this procedure.

- 1 Move the platform rotate switch to the right then the left through two platform rotation cycles, then hold the switch to the RIGHT position until the platform is fully rotated to the right.
- 2 Connect a clear hose to the top bleed valve. Place the other end of the hose in a container to collect any drainage. Secure the container to the boom.

- 3 Open the top bleed valve on the rotator, but do not remove it.



- a top bleed valve
- b bottom bleed valve
- c clear hose
- d container

- 4 Hold the platform rotate switch to the LEFT position until the platform is fully rotated. Continue holding the switch until air stops coming out of the bleed valve. Then close the bleed valve.

CAUTION Crushing hazard. Keep clear of the platform during rotation.

- 5 Connect the clear hose to the bottom bleed valve and open the valve. Do not remove the bleed valve.
- 6 Hold the platform rotate switch to the RIGHT position until the platform is fully rotated. Continue holding the switch until air stops coming out of the bleed valve. Then close the bleed valve.

CAUTION Crushing hazard. Keep clear of the platform during rotation.

- 7 Remove the hose from the bleed valve and clean up any hydraulic oil that may have spilled.
- 8 Rotate the platform full right then left and inspect the bleed valves for leaks.


Boom Components

3-1 Plastic Cable Track

The boom cable track guides cables and hoses running up the boom. It can be repaired link by link without removing the cables and hoses that run through it. Removing the entire boom cable track is only necessary when performing major repairs that involve removing the boom.

How to Repair the Plastic Cable Track

CAUTION Component damage hazard. The boom cable track can be damaged if it is twisted.



- 1 Use a screwdriver to pry down on the lower clip.
- 2 Repeat step 1 for each link.
- 3 To remove a single link, open the lower clip and then use a screwdriver to pry the link to the side.

3-2 Boom

How to Shim the Boom

NOTICE Measure each wear pad. Replace the pad if it is less than $\frac{7}{16}$ inch (11 mm) thick. If the pad is more than $\frac{7}{16}$ inch (11 mm) thick, perform the following procedure.

- 1 Extend the boom 10 inches (25 cm).
- 2 Remove the wear pad mounting fasteners.
- 3 Install the new shims under the wear pad to obtain zero clearance and zero drag.
- 4 Use a round punch to align the shim to the wear pad. Install the mounting fasteners.
- 5 Extend and retract the boom through an entire cycle. Check for tight spots that could cause scraping or binding.

NOTICE Always maintain squareness between the outer and inner boom tubes.

How to Remove the Boom

WARNING This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools may cause death or serious injury and significant component damage. Dealer service is strongly recommended.

NOTICE Perform this procedure with the boom in the stowed position.

- 1 Remove the platform. See 2-1, *How to Remove the Platform*.
- 2 Remove the platform rotator and leveling slave cylinder. See 2-3, *How to Remove the Platform Rotator*.

BOOM COMPONENTS

- 3 Remove the mounting fasteners from the counterbalance valve manifold on the end of the boom. Then remove the manifold and set it aside.
- 4 Support the cable track with an overhead crane.
- 5 Remove the hose/cable cover from the pivot end of the boom.
- 6 Remove the cable track mounting bolts at the platform end of the boom.
- 7 Remove the side panel from the cable track to access the cable track mounting bolts.
- 8 Remove the cable track mounting fasteners, then remove the cable track from the boom and lay it off to the side.

CAUTION Component damage hazard. The boom cable track can be damaged if it is twisted.

- 9 Carefully raise the boom enough to access the master cylinder rod-end pivot pin.
- 10 Remove the turntable end cover.
- 11 Remove the retaining bolt from the master cylinder rod-end pivot pin. Use a soft metal drift to remove the pin. Pull the cylinder back and secure it from moving.
- 12 Remove the drive speed limit switch mounted on the inside of the pivot end of the boom. Do not disconnect the wiring.
- 13 Disconnect and plug the extension cylinder hydraulic hoses. Cap the fittings on the cylinder.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 14 Attach an overhead crane to the center point of the boom.

- 15 Attach a similar lifting device to the lift cylinder.
- 16 Place support blocks under the cylinder, across the turntable.
- 17 Remove the pin retaining fastener from the boom lift cylinder rod-end pin. Use a soft metal drift to remove the pin.

CAUTION Crushing hazard. The boom lift cylinder will fall unless it is properly supported.

- 18 Lower the rod end of the lift cylinder onto support blocks. Protect the cylinder rod from damage.
- 19 Use the crane to lift the boom to a horizontal position.
- 20 Remove the pin retaining fastener from the boom pivot pin.
- 21 Remove the boom pivot pin with a soft metal drift, then carefully remove the boom from the machine.

WARNING Crushing hazard. If the overhead crane is not properly attached, the boom may become unbalanced and fall when it is removed from the machine.

How to Disassemble the Boom

NOTICE Complete disassembly of the boom is only necessary if the outer or inner boom tubes must be replaced. The extension cylinder can be removed without completely disassembling of the boom. See 3-4, *How to Remove the Extension Cylinder*.

- 1 Remove the boom. See 3-2, *How to Remove the Boom*.
- 2 Place blocks under the extension cylinder for support.

BOOM COMPONENTS

- 3 Remove the retaining fastener from the extension cylinder barrel-end pivot pin. Use a soft metal drift to remove the pin.
- 4 Remove and label the wear pads from the platform end of the boom.

NOTICE Pay careful attention to the location and amount of shims used with each wear pad.

- 5 Support and slide the extension tube out of the platform end of the boom.

CAUTION Crushing hazard. The extension tube will fall when it is removed from the boom if it is not properly supported.

- 6 Remove the snap rings from the extension cylinder rod-end pins. Use a soft metal drift to remove the pins.
- 7 Support and slide the extension cylinder out of the platform end of the extension boom.
- 8 Remove and label the wear pads from the extension boom.

NOTICE Pay careful attention to the location and amount of shims used with each wear pad.

3-3 Boom Lift Cylinder

How to Remove the Boom Lift Cylinder

WARNING This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools may result in death or serious injury and significant component damage. Dealer service is strongly recommended.

- 1 Raise the boom until the boom lift cylinder rod-end pin is above the turntable covers.
- 2 Place blocks under the cylinder for support.
- 3 Support the boom with an overhead crane. Do not lift the boom.
- 4 Support the balance point of the boom lift cylinder with an overhead crane or similar lifting device.

WARNING Crushing hazard. If the overhead crane is not properly attached, the lift cylinder may become unbalanced and fall when it is disconnected from the machine.

- 5 Remove the pin retaining fastener from the lift cylinder rod-end pivot pin. Use a soft metal drift to remove the pin, then allow the lift cylinder to rest on the blocks. Protect the cylinder rod from damage.

CAUTION Crushing hazard. The lift cylinder will fall unless it is properly supported.

- 6 Use the crane to lift the boom to a horizontal position.
- 7 Remove the turntable end cover to access the lift cylinder mounting bracket (label and disconnect the alarm wiring, if equipped).

BOOM COMPONENTS

- 8 Disconnect and plug the boom lift cylinder hydraulic hoses. Cap the fittings on the cylinder.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 9 Remove the mounting fasteners from the lift cylinder mounting bracket.

- 10 With the lift cylinder being supported by the overhead crane, pull the cylinder toward the platform until it is out.

CAUTION Component damage hazard. The cables and hydraulic hoses can be damaged if the lift cylinder is pulled across them.

3-4 Extension Cylinder

The extension cylinder extends and retracts the boom extension tube. The extension cylinder is equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure.

How to Remove the Extension Cylinder

WARNING This procedure requires specific repair skills, lifting equipment and a suitable workshop. Attempting this procedure without these skills and tools may cause death or serious injury and significant component damage. Dealer service is strongly recommended.

- 1 Raise the boom to a horizontal position.
- 2 Extend the boom until the extension cylinder rod-end mounting pins are accessible.

- 3 Remove the snap rings from the extension cylinder rod-end pins. Use a soft metal drift to remove the pins.

- 4 Remove the turntable end cover (label and disconnect the alarm wiring, if equipped).

- 5 Disconnect and plug the master cylinder hydraulic hoses. Cap the fittings on the cylinder.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 6 Remove the pin retaining fasteners from both master cylinder pins.
- 7 Use a soft metal drift to remove the pins. Then remove the master cylinder from the machine.
- 8 Disconnect and plug the extension cylinder hydraulic hoses. Cap the fittings on the cylinder.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 9 Place a small block under the cylinder for support.
- 10 Remove the pin retaining fastener from the extension cylinder barrel-end pivot pin. Use a soft metal drift to remove the pin.
- 11 Support and slide the extension cylinder out of the extension boom.

CAUTION Crushing hazard. The extension cylinder will fall when it is removed from the extension boom if it is not properly supported.

BOOM COMPONENTS

3-5**Platform Leveling
Master Cylinder**

The master cylinder acts as a pump for the slave cylinder. It's part of the closed circuit hydraulic loop that keeps the platform level through the entire range of boom motion. The master cylinder is attached to the lift cylinder and is located at the base of the boom.

**How to Remove the Platform
Leveling Master Cylinder**

- 1 Raise the boom to a horizontal position.
- 2 Remove the turntable end cover to access the master cylinder.
- 3 Disconnect and plug the master cylinder hydraulic hoses. Cap the fittings on the cylinder.

⚠ CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Remove the pin retaining fasteners from both master cylinder pins.
- 5 Use a soft metal drift to remove the pins.

Turntable Covers

4-1

Turntable Covers

How to Remove a Turntable Cover

- 1 Raise the turntable cover. Support the open cover with an overhead crane or forklift. Do not lift it.

⚠ CAUTION Crushing hazard. Due to its heavy weight, do not attempt to support the cover by hand.

- 2 Remove the upper and lower retaining clips from the gas strut.
- 3 Gently pry the strut pivot sockets off of the ball studs and remove the strut. Protect the strut cylinder rod from damage.
- 4 Remove the cover hinge bolts, that fasten the hinge support bracket to the bulkhead.
- 5 Carefully lift and remove the cover from the machine.

⚠ WARNING If a turntable cover must be replaced, be sure that all appropriate safety and instructional decals are applied to the new cover.

NOTICE Alignment adjustments may be necessary when a new cover is installed.

Deutz Engine F3L 1011

5-1 RPM Adjustment

Refer to Maintenance Procedures, B-12,
Check and Adjust the Engine RPM.

5-2 Flex Plate

The flex plate acts as a coupler between the engine and the pump. It is bolted to the engine flywheel and has a splined center to drive the pump.

How to Remove the Flex Plate

- 1 Disconnect the wiring plug at the electronic displacement controller (EDC), located on the drive pump.
- 2 Support the drive pump with an appropriate lifting device. Then remove all of the pump mounting plate to engine bell housing bolts.
- 3 Carefully pull the pump away from the engine and secure it from moving.
- 4 Remove the flex plate mounting fasteners, then remove the flex plate from the engine.

How to Install the Flex Plate

- 1 Install the flex plate onto the flywheel with the flat side of the spline against the flywheel. Torque the flex plate mounting bolts to 34 ft-lbs (46 Nm).
- 2 Install the coupler onto the pump shaft with the set screw toward the pump. Leave a $\frac{3}{16}$ inch (4.7 mm) gap between the coupler and pump end plate.

- 3 Apply Loctite® removable thread sealant to the coupler set screw. Torque the set screw to 45 ft-lbs (61 Nm).

CAUTION Component damage hazard. Do not force the drive pump during installation or the flex plate teeth may become damaged.

- 4 Assemble the engine and torque the pump mountint plate to 34 ft-lbs (46 Nm).

5-3 Oil Temperature and Pressure Gauges


The oil temperature gauge is an electrical gauge. The sending unit has limit contacts that are factory set. The contacts will close at 300° F (147° C). When the contacts close, the engine will shut off to prevent damage and will not start until the temperature drops below the contact point. Temperature will be indicated when the key is on and the Emergency Stop Button is pulled out to the ON position.

CAUTION Component damage hazard. Do not crank the engine with the over-temperature light on.

The oil pressure gauge is an electrical gauge. The sending unit has limit contacts that are factory set. The contacts will close at 7 psi (0.48 bar). When the contacts close, the engine will shut off to prevent damage. Oil pressure will be indicated when the engine is running.

CAUTION Component damage hazard. Do not continue to run the engine with the low oil pressure light on.

Ford LSG-423 Engine



6-1 Governor Actuator

How to Set Up the Governor Actuator and Linkage

NOTICE

Adjustment of the governor actuator is only necessary when the governor actuator or the linkage has been replaced.

- 1 Connect the linkage rod to the throttle plate shaft, then tighten the lock nut.
- 2 Fasten the lock nut and clevis yoke to the linkage rod. Do not tighten the lock nut against the clevis yoke.
- 3 Loosen the fastener on the actuator arm. Rotate the actuator arm until it is at a 110 degree angle to the linkage rod.
- 4 Position the linkage rod so that the throttle is in the idle position. Then adjust the clevis yoke on the linkage rod to obtain the proper length. Install the yoke onto the actuator arm and tighten the lock nut.
- 5 With the throttle in the idle position and the actuator arm at a 110 degree angle to the linkage, rotate the actuator shaft slightly counterclockwise to pre-load the spring. Tighten the fastener on the actuator arm without releasing the shaft.

Governor actuator and linkage

- a clevis yoke
- b linkage rod
- c carburetor
- d throttle plate shaft
- e governor actuator
- f actuator shaft
- g actuator arm

FORD LSG-423 ENGINE

- 6 Manually pull the actuator arm through a full cycle to be sure that the linkage moves freely. Be sure that the linkage activates the throttle shaft to approximately half throttle.

NOTICE

The linkage must be free of friction and obstruction. Do not let it rub against the engine, brackets or hoses.

CAUTION

Component damage hazard. If the throttle linkage is improperly adjusted and allowed to reach full throttle, the engine will over-rev and cause component damage.

6-2**Choke Adjustments**


This engine is equipped with an electrically heated automatic choke. The choke has a poppet valve to enhance cold starting ability on LPG fuel.

NOTICE

Choke adjustments are affected by climate. Richer adjustment will be necessary in colder climates, leaner adjustment in warmer climates.

Automatic Choke with Poppet Valve

The choke functions in both gasoline and LPG mode. The choke butterfly may be adjusted to a fully closed (rich) position for colder climates and the poppet valve will provide a flow path during LPG fueled operation.



FORD LSG-423 ENGINE

6-3 Timing Adjustment

Complete information to perform this procedure is available in the *Ford LSG-423 2.3 Liter Industrial Engine Service Manual* (Ford number: 194-216).
Genie part number 29586.

6-4 Carburetor Adjustment

Complete information to perform this procedure is available in the *Ford LSG-423 2.3 Liter Industrial Engine Service Manual* (Ford number: 194-216).
Genie part number 29586.

6-5 RPM Adjustment

Refer to Maintenance Procedures, B-12, *Check and Adjust the Engine RPM*.

6-6 Flex Plate

The flex plate acts as a coupler between the engine and the pump. It is bolted to the engine flywheel and has a splined center to drive the pump.

Flex Plate Removal

- 1 Disconnect and remove the hose between the carburetor venturi and the air cleaner.
- 2 Disconnect the linkage from the governor, then remove the governor linkage from the carburetor. Do not alter the length of the linkage.
- 3 Disconnect the wiring plug at the electronic displacement controller (EDC), located on the drive pump.
- 4 Remove the mounting fasteners from the regulator mounting bracket, then pull the bracket up past the bell housing. Secure the bracket before continuing.
- 5 Support the drive pump with an appropriate lifting device. Then remove all of the pump mounting plate to engine bell housing bolts.
- 6 Carefully pull the pump away from the engine and secure it from moving.
- 7 Remove the flex plate mounting fasteners, then remove the flex plate from the engine.

How to Install the Flex Plate

- 1 Install the flex plate onto the flywheel with the raised spline against the flywheel. Torque the flex plate mounting bolts to 34 ft-lbs (46 Nm).
- 2 Install the coupler onto the pump shaft with the set screw towards the pump. Leave a $\frac{3}{16}$ inch (4.7 mm) gap between the coupler and pump end plate.
- 3 Apply Loctite® removable thread sealant to the coupler set screw. Torque the set screw to 45 ft-lbs (61 Nm).

⚠ CAUTION Component damage hazard. Do not force the drive pump during installation or the flex plate teeth may become damaged.

- 4 Assemble the engine and torque the pumpmountint plate to 34 ft-lbs (46 Nm).

FORD LSG-423 ENGINE


6-7**Water Temperature and Oil Pressure Gauges**

The water temperature gauge is an electrical gauge. The sending unit has limit contacts that are factory set. The contacts will close at 230° F (109° C). When the contacts close, the engine will shut off to prevent damage and will not start until the temperature drops below the contact point. Temperature will be indicated when the key is on and the Emergency Stop Button is pulled out to the ON position.

CAUTION Component damage hazard.
Do not crank the engine with the over-temperature light on.

The oil pressure gauge is an electrical gauge. The sending unit has limit contacts that are factory set. The contacts will close at 8 psi (0.55 bar). When the contacts close, the engine will shut off to prevent damage. Oil pressure will be indicated when the engine is running.

CAUTION Component damage hazard.
Do not continue to run the engine with the low oil pressure light on.

6-8**Vacuum Switch****How to Test the Vacuum Switch**

- 1 Connect the leads from an ohmmeter or continuity tester to the common and normally open terminals.
- ⊙ Result: There should be no continuity (infinite Ω).
- 2 Apply mild suction to the vacuum port.
- ⊙ Result: The switch should close and show full continuity (zero Ω).

CAUTION Component damage hazard.
Do not short the vacuum switch terminals to ground.

Ground Controls

7-1 Control Relays


Relays used for single function switching are single pole double throw (SPDT) relays. (There are two types of single pole double throw relays used for ground controls.) Dual function switching requires a double pole double throw (DPDT) relay.

How to Test a Double Pole Double Throw Relay

⚠WARNING Electrocutation hazard. Contact with electrically charged circuits may cause death or serious injury. Remove all rings, watches and other jewelry.

This procedure covers fundamental relay testing and does not specifically apply to all varieties of relays.

- 1 Turn the key switch to the OFF position and remove the key.
- 2 Label and then disconnect all the wiring from the relay to be tested.
- 3 Connect the leads from an ohmmeter to each terminal combination and check for continuity. Terminals 13 and 14 represent the coil and should not be tested in any other combination.



- a terminal no. 5
- b terminal no. 1
- c relay
- d terminal no. 13
- e terminal no. 9
- f terminal no. 12
- g terminal no. 14
- h terminal no. 4
- i terminal no. 8

Test	Desired result
terminal 13 to 14	160 to 170Ω
terminal 8 to 5, 4, 1, 12 & 9	no continuity (infinite Ω)
terminal 5 to 4, 1, 12 & 9	no continuity
terminal 4 to 1 & 9	no continuity
terminal 1 to 12	no continuity
terminal 4 to 12	continuity (zero Ω)
terminal 1 to 9	continuity

- 4 Connect 12V DC to terminal 14 and a ground wire to terminal 13, then test the following terminal combinations.

Test	Desired result
terminal 8 to 1, 5, 9 & 4	no continuity (infinite Ω)
terminal 5 to 1, 4 & 12	no continuity
terminal 4 to 1, 9 & 12	no continuity
terminal 1 to 9 & 12	no continuity
terminal 8 to 12	continuity (zero Ω)
terminal 5 to 9	continuity (zero Ω)


GROUND CONTROLS

How to Test a Single Pole Double Throw Relay

This procedure covers fundamental relay testing and does not specifically apply to all varieties of relays.

Socket Connection Relay

- 1 Turn the key switch to the OFF position and remove the key.
- 2 Label and then disconnect all the wiring from the relay to be tested.
- 3 Connect the leads from an ohmmeter or continuity tester to each terminal combination and check for continuity. Terminals 13 and 14 represent the coil and should not be tested in any other combination.



- a terminal no. 5
- b terminal no. 1
- c relay
- d terminal no. 13
- e terminal no. 9
- f terminal no. 14

Test	Desired result
terminal 13 to 14	190 to 200Ω
terminal 5 to 1 & 9	no continuity (infinite Ω)
terminal 1 to 9	continuity (zero Ω)


- 4 Connect 12V DC to terminal 14 and a ground wire to terminal 13, then test the following terminal combinations.

Test	Desired result
terminal 1 to 5 & 9	no continuity (infinite Ω)
terminal 5 to 9	continuity (zero Ω)

GROUND CONTROLS

Direct Connection Relay

- 1 Label and then disconnect all the wiring from the relay to be tested.
- 2 Connect the leads from an ohmmeter or continuity tester to each terminal combination and check for continuity. Terminals 85 and 86 represent the coil and should not be tested in any other combination.



- a terminal no. 87a
- b terminal no. 85
- c terminal no. 30
- d terminal no. 86
- e terminal no. 87

Test	Desired result
terminal 85 to 86	85 to 95 Ω
terminal 87 to 87a & 30	no continuity (infinite Ω)
terminal 87a to 30	continuity (zero Ω)

- 3 Connect 12V DC to terminal 85 and a ground wire to terminal 86, then test the following terminal combinations.

Test	Desired result
terminal 87 to 87a & 30	no continuity (infinite Ω)
terminal 87 to 30	continuity (zero Ω)

7-2**Toggle Switches**

See 1-5, *Toggle Switches*.

7-3**Wago® Components****How to Remove a Wago® Component****⚠ WARNING**

Electrocution hazard. Contact with electrically charged circuits may cause death or serious injury. Remove all rings, watches and other jewelry.

NOTICE

A small screwdriver is provided and should be used when removing a Wago® component. This screwdriver is located in the operator's manual storage box in the platform.

- 1 Label the wiring from the component to be removed.
- 2 Use the provided screwdriver to push in and release the wire from the component.
- 3 Locate the removal tab on the bottom or top side of the component.
- 4 Use the provided screwdriver to gently pry up on the tab of the component and remove it.

GROUND CONTROLS

7-4 Resistors

How to Test the Resistor

The resistor is used to maintain proper control of boom function speeds. A 10 ohm resistor reduces voltage to all the boom function switches.

NOTICE Turn the key switch to the OFF position and remove the key.

- 1 Disconnect either end of one of the wires connected to the resistor to be tested.
- 2 Connect the leads from an ohmmeter to each end or wiring of the resistor being tested.
- 3 Compare the ohmmeter reading with the resistance rating printed on the resistor.

7-5 Power Relay

⚠WARNING Electrocutation hazard. Contact with electrically charged circuits may result in death or serious injury. Remove all rings, watches and other jewelry.

How to Test the Power Relay


⚠WARNING Electrocutation hazard. Disconnect the ground cable from the battery before performing this procedure.

- 1 Connect the leads from an ohmmeter to each terminal combination and check for continuity.

Test	Desired result
2 small posts	13 to 17Ω
2 large posts	no continuity (infinite Ω)
Any small post to any large post	no continuity (infinite Ω)

- 2 Connect 12V DC to one of the small posts and a ground wire to the other small post, then test the following terminal combination.

Test	Desired result
2 large posts	continuity (zero Ω)



- a high amp power contact terminal (large post)
- b solenoid activate coil terminal (small post)

Hydraulic Pumps

8-1 Lift/Steer Pump

How to Test the Lift/Steer Pump

- 1 Disconnect and plug the high pressure hydraulic hose from the lift/steer pump.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Connect a 0 to 5000 psi (0 to 350 bar) pressure gauge to the high pressure port.
- 3 **Gasoline/LPG models:** Remove the high tension lead from the center of the ignition coil.

WARNING Electrocutation hazard. Contact with electrically charged circuits may cause death or serious injury. Remove all rings, watches and other jewelry.

- 4 Turn the key switch to ground control and pull out the Emergency Stop button to the ON position.

- 5 **Deutz Diesel models:** Hold the manual fuel shutoff valve counterclockwise to the CLOSED position.

All models: Observe the pressure gauge while cranking the engine. Immediately stop cranking if the pressure reaches or exceeds 3000 psi (206 bar).


CAUTION Component damage hazard. Hydraulic pressure in excess of 3000 psi (206 bar) will cause damage to the machine.

- ⦿ Result: If the pressure gauge reads 3000 psi (206 bar), immediately stop cranking the engine. The pump is good.
 - ⦿ Result: If the pressure fails to reach 3000 psi (206 bar), the pump is bad and will need to be serviced or replaced.
- 6 **Gasoline/LPG models:** Reconnect the high tension lead to the ignition coil.

HYDRAULIC PUMPS

How to Remove the Lift/Steer Pump

- 1 Close the two hydraulic tank valves located at the hydraulic tank.



CAUTION Component damage hazard. The engine must not be started with the hydraulic tank shutoff valves in the **CLOSED** position or component damage will occur. If the tank valves are closed, remove the key from the key switch and tag the machine to inform personnel of the condition.

- 2 Disconnect and plug the lift/steer pump hydraulic hoses. Cap the fittings.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Remove the pump mounting bolts. Carefully remove the pump.

CAUTION Component damage hazard. Be sure to open the two hydraulic tank valves and prime the pump after installing the pump.


8-2 Drive Hydraulic Pump

The drive hydraulic pump is a bi-directional variable displacement piston pump. The pump output is controlled by the electronic displacement controller (EDC), located on the pump. The only adjustment that can be made to the pump is the neutral or null adjustment. Any internal service to the pump should only be performed at an authorized Sundstrand-Sauer service center.

How to Remove the Drive Hydraulic Pump

CAUTION Component damage hazard. The work area and surfaces where this procedure will be performed must be clean and free of debris that could get into the hydraulic system and cause severe component damage. Dealer service is recommended.

- 1 Disconnect the electrical connection at the electronic displacement controller (EDC) located on the drive pump.
- 2 Close the two hydraulic tank valves located at the hydraulic tank.



CAUTION Component damage hazard. The engine must not be started with the hydraulic tank shutoff valves in the **CLOSED** position or component damage will occur. If the tank valves are closed, remove the key from the key switch and tag the machine to inform personnel of the condition.

HYDRAULIC PUMPS

- 3 Disconnect the hydraulic hoses from the pumps and cap them.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Support the pump and remove the two drive pump mounting bolts. Carefully remove the pump.

CAUTION Component damage hazard. Be sure to open the two hydraulic tank valves and prime the pump after installing the pump.

How to Prime the Pump

- 1 Connect a 0 to 600 psi (0 to 41 bar) pressure gauge to the test port on the drive pump.
- 2 **Gasoline/LPG models:** Remove the high tension lead from the center of the ignition coil.

WARNING Electrocutation hazard. Contact with electrically charged circuits may cause death or serious injury. Remove all rings, watches and other jewelry.

Deutz Diesel models: Hold the manual fuel shutoff valve counterclockwise to the CLOSED position.

- 3 Crank the engine with the starter motor for 15 seconds, wait 15 seconds, then crank the engine an additional 15 seconds or until the pressure reaches 320 psi (22 bar).


Function Manifold

9-1

Function Manifold Components

Index No.	Description	Schematic Item	Function	Torque
1	3 position 4 way D03 valve	N	Platform rotate	30-35 in-lbs / 3-4 Nm
2	Counterbalance valve	B	Platform level up	35-40 ft-lbs / 47-54 Nm
3	Sandwich valve manifold	A	Platform level	
4	3 position 4 way D03 valve	O	Platform level	30-35 in-lbs / 3-4 Nm
5	3 position 4 way D03 valve	P	Turntable rotate	30-35 in-lbs / 3-4 Nm
6	Cover plate	Q		30-35 in-lbs / 3-4 Nm
7	3 position 4 way D03 valve	R	Boom up/down	30-35 in-lbs / 3-4 Nm
8	3 position 4 way D03 valve	S	Boom extend/retract	30-35 in-lbs / 3-4 Nm
9	Counterbalance valve	C	Platform level down	35-40 ft-lbs / 47-54 Nm
10	Check valve	K	Turntable rotate	
	differential sensing	11-13 ft-lbs / 15-18 Nm		
11	Check valve	M	Boom up/down	
	differential sensing	11-13 ft-lbs / 15-18 Nm		
12	Flow regulator valve	Y	Boom up/down	10-12 ft-lbs / 14-16 Nm
13	Relief valve, 1950 psi (134 bar)	D	Boom extend	25-30 ft-lbs / 34-41 Nm
14	Relief valve, 2200 psi (152 bar)	F	Boom down	25-30 ft-lbs / 34-41 Nm
15	Proportional solenoid valve	AA	Boom	10-12 ft-lbs / 14-16 Nm
16	Flow regulator valve	X	Turntable rotate/ boom extend/retract	10-12 ft-lbs / 14-16 Nm
17	Normally closed poppet valve	J	Platform level	25-30 ft-lbs / 34-41 Nm
18	Proportional solenoid valve	Z	Turntable rotate/ boom extend/retract	10-12 ft-lbs / 14-16 Nm
19	Flow regulator valve	V	Platform level	10-12 ft-lbs / 14-16 Nm
20	Differential sensing valve	AC	All functions	10-12 ft-lbs / 14-16 Nm
21	Flow regulator valve	U	Platform rotate	10-12 ft-lbs / 14-16 Nm
22	Flow regulator valve	W	Differential sensing circuit	10-12 ft-lbs / 14-16 Nm
23	Diagnostic fitting		Testing	
24	Relief valve, 2600 psi (179 bar)	AB	System relief	35-40 ft-lbs / 47-54 Nm
25	Priority flow regulator valve	T	Steering	10-12 ft-lbs / 14-16 Nm
26	Check valve	I	Platform rotate right -	
	differential sensing	11-13 ft-lbs / 15-18 Nm		
27	Check valve	H	Platform rotate left -	
	differential sensing	11-13 ft-lbs / 15-18 Nm		
28	Check valve	L	Platform level -	
	differential sensing	11-13 ft-lbs / 15-18 Nm		

FUNCTION MANIFOLD



FUNCTION MANIFOLD

9-2 Valve Adjustments - Function Manifold

How to Adjust the Main Relief Valve

Perform this procedure with the boom in the
NOTICE stowed position.

- 1 Connect a 0 to 3000 psi (0 to 206 bar) pressure gauge to the test port on the function manifold.
- 2 Start the engine from the ground controls.
- 3 Hold the retract switch with the boom fully retracted, and observe the pressure reading on the pressure gauge.
- 4 Turn the engine off. Hold the relief valve and remove the cap (item 24, function manifold).
- 5 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Then install the relief valve cap.

WARNING Tip-over hazard. Do not adjust the relief valves higher than recommended.

- 6 Restart the engine. Hold the retract switch with the boom fully retracted, and recheck the valve pressure.

Main relief valve specifications

Pressure	2600 psi 179 bar
----------	---------------------

How to Adjust the Boom Down Relief Valve

NOTICE Perform this procedure with the boom in the stowed position.

- 1 Connect a 0 to 3000 psi (0 to 206 bar) pressure gauge to the test port on the function manifold.
- 2 Start the engine from the ground controls.
- 3 Hold the boom down switch with the boom fully lowered, and observe the pressure reading on the pressure gauge.
- 4 Turn the engine off. Hold the relief valve and remove the cap (item 14, function manifold).
- 5 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Then install the relief valve cap.

WARNING Tip-over hazard. Do not adjust the relief valves higher than recommended.

- 6 Restart the engine. Hold the boom down switch with the boom fully lowered and recheck the valve pressure.

Boom down relief valve specifications

Pressure	2200 psi 152 bar
----------	---------------------

FUNCTION MANIFOLD

How to Adjust the Boom Extend Relief Valve

NOTICE Procedure with the boom in the stowed position.

- 1 Connect a 0 to 3000 psi (0 to 206 bar) pressure gauge to the test port on the function manifold.
- 2 Start the engine from the ground controls.
- 3 Hold the extend switch with the boom fully extended, and observe the pressure reading on the pressure gauge.
- 4 Turn the engine off. Hold the relief valve and remove the cap (item 13, function manifold).
- 5 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Then install the relief valve cap.

WARNING Tip-over hazard. Do not adjust the relief valves higher than recommended.

- 6 Restart the engine. Hold the extend switch with the boom fully extended, and recheck the valve pressure.


Boom extend relief valve specifications

Pressure	1950 psi 134 bar
----------	---------------------

How to Override a Valve

A hydraulic valve may need to be manually overridden to troubleshoot a malfunction. The proportional boom functions (boom up/down and turntable rotate) use a variable position proportional valve and a three position directional valve. Example: one position for boom up, one position for neutral and one position for boom down. The platform rotate function uses a three position valve. The platform level uses a three position and a two position valve. The three position valves and the proportional valves can be manually overridden. To identify the manifold valves see 9-1, *Function Manifold*, in this section.

- 1 Push the button on the end of the valve in $\frac{1}{4}$ inch (6 mm).




- 2 Move the ground control function switch for the function being overridden to operate function.

WARNING Collision hazard. Impact with moving boom components may cause death or serious injury. Use extreme caution when overriding a machine function. Identify the direction of machine movement before overriding a valve.

FUNCTION MANIFOLD

How to Check the Resistance of a Valve Coil

- 1 Turn the key switch to the OFF position and disconnect the wires from the valve coil to be tested.
- 2 Connect the leads from an ohmmeter to the valve coil terminals.



Valve coil specifications

Proportional solenoid valve	5 Ω
3 position 4 way directional valve	4.5 Ω
Normally closed poppet valve	7 Ω

Fuel and Hydraulic Tanks

10-1


Hydraulic Tank

The primary functions of the hydraulic tank are to cool, clean and deaerate the hydraulic fluid during operation. This tank has a 45 gallon (170 liter) capacity and an oil level gauge with a temperature indicator. It utilizes internal suction strainers for the pump supply suction lines and has an external return line filter with a condition indicator.

How to Remove the Hydraulic Tank

CAUTION Component damage hazard. The work area and surfaces where this procedure will be performed must be clean and free of debris that could get into the hydraulic system.

- 1 Remove the fuel tank. See 10-2, *How to Remove the Fuel Tank*.
- 2 Close the two hydraulic tank valves located at the hydraulic tank.



- 3 Completely drain the oil from the tank by removing the drain plug located in the bottom of the tank.

CAUTION Burn hazard. Contact with hot oil may cause severe burns.

- 4 Disconnect the hydraulic hoses from the tank.
- 5 Remove the mounting fasteners from the bottom of the tank.
- 6 Use an appropriate lifting device to remove the tank from the machine.

NOTICE Always use pipe thread sealant when installing the drain plug.

NOTICE Use only Dexron II equivalent hydraulic fluid.

CAUTION Component damage hazard. Be sure to open the two hydraulic tank valves and prime the pump after installing the hydraulic tank.

How to Prime the Pump

- 1 Connect a 0 to 600 psi (0 to 41 bar) pressure gauge to the test port on the drive pump.
- 2 **Gasoline/LPG models:** Remove the high tension lead from the center of the ignition coil.

WARNING Electrocutation hazard. Contact with electrically charged circuits may cause death or serious injury. Remove all rings, watches and other jewelry.

Deutz Diesel models: Hold the manual fuel shutoff valve counterclockwise to the CLOSED position.

- 3 Crank the engine with the starter motor for 15 seconds, wait 15 seconds, then crank the engine an additional 15 seconds or until the pressure reaches 320 psi (22 bar).

FUEL AND HYDRAULIC TANKS

10-2**Fuel Tank****How to Remove the Fuel Tank**

⚠ DANGER Explosion hazard. Engine fuels are combustible. Remove the fuel tank in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

⚠ DANGER Explosion hazard. When transferring fuel, connect a grounding wire between the machine and pump or container.

- 1 Turn the manual fuel shutoff valve to the CLOSED position.
- 2 **Gasoline/LPG models:** Disconnect, drain and plug the fuel hose.
Deutz Diesel models: Disconnect, drain and plug the supply and return fuel lines. Cap the fuel return fitting on the fuel tank.
- 3 Remove the mounting fasteners from the bottom of the tank.
- 4 Use an appropriate lifting device to remove the tank from the machine.

NOTICE Clean the fuel tank and inspect for rust and corrosion before installing.


Turntable Rotation Components

11-1


Rotation Hydraulic Motor

How to Remove the Rotation Hydraulic Motor

- 1 Secure the turntable from rotating with the turntable rotation lock pin.



Unlocked position




Locked position

- 2 Disconnect the hydraulic hoses from the motor and manifold, and cap them.

CAUTION

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 3 Remove the motor mounting bolts, then remove the motor from the brake.



- a motor/brake mounting bolts
- b motor
- c brake
- d torque hub mounting bolts
- e plug
- f torque hub


How to Remove the Turntable Rotation Brake or Torque Hub

Refer to Maintenance Procedures, C-5, *How to Replace the Torque Hub Oil*.

TURNTABLE ROTATION COMPONENTS

11-2**Turntable Rotation Manifold Components**

Index No.	Description	Schematic Item	Function	Torque
1	Shuttle valve 2 position 3 way	C	Turntable rotation brake release	10-13 ft-lbs / 14-18 Nm
2	Counterbalance valve	A	Turntable rotate - right	35-40 ft-lbs / 47-54 Nm
3	Counterbalance valve	B	Turntable rotate - left	35-40 ft-lbs / 47-54 Nm

**Plug Torque Specifications**


Description	Hex size	Torque
SAE No. 2	$\frac{1}{8}$	50 in-lbs / 6 Nm
SAE No. 4	$\frac{3}{16}$	13 ft-lbs / 18 Nm
SAE No. 6	$\frac{1}{4}$	18 ft-lbs / 24 Nm
SAE No. 8	$\frac{5}{16}$	50 ft-lbs / 68 Nm
SAE No. 10	$\frac{9}{16}$	55 ft-lbs / 75 Nm
SAE No. 12	$\frac{5}{8}$	75 ft-lbs / 102 Nm

2WD Steering Axle Components

12-1 Yoke and Hub

How to Remove the Yoke and Hub

- 1 Remove the retaining bolt, then the pivot pin from both the steering cylinder and the tie rod.



- a tie rod
- b axle
- c king pin/retaining bolt
- d yoke
- e hub
- f pivot pin/retaining bolt
- g steering cylinder

- 5 Remove the lug nuts, then the tire and wheel assembly.
- 6 Remove the retaining bolt from the king pin.
- 7 Attach a strap from a lifting device to the yoke/hub assembly for support.
- 8 Use a slide hammer to remove the upper king pin, then use a soft metal drift to drive the lower king pin down and out.

⚠ WARNING

Crushing hazard. The yoke/hub assembly will fall when the king pins are removed if it is not properly supported.

Torque specifications

Lug nut	125 ft-lbs 169.5 Nm
---------	------------------------

- 2 Loosen the wheel lug nuts. Do not remove them.
- 3 Block the non-steering wheels, and then center a lifting jack under the steering axle.
- 4 Raise the machine 6 inches (15 cm) and place blocks under the chassis for support.

2WD STEERING AXLE COMPONENTS

How to Remove the Hub and Bearings

- 1 Loosen the wheel lug nuts. Do not remove them.
- 2 Block the non-steering wheels and place a lifting jack under the steering axle.
- 3 Raise the machine and place blocks under the chassis for support.
- 4 Remove the lug nuts. Then remove the tire and wheel assembly.
- 5 Remove the dust cap, cotter pin and slotted nut.
- 6 Pull the hub off the spindle. The washer and outer bearing should fall loose from the hub.
- 7 Place the hub on a flat surface and gently pry the bearing seal out of the hub. Remove the rear bearing.
- 6 Install the washer and slotted nut.
- 7 Tighten the slotted nut to 35 foot-pounds (47 Nm).
- 8 Loosen the slotted nut, then re-tighten to 8 foot-pounds (11 Nm).
- 9 Install a new cotter pin. Bend the cotter pin to lock it in.
- 10 Install the dust cap, then the tire and wheel assembly. Torque the wheel lug nuts to 125 foot-pounds (169.5 Nm).

How to Install the Hub and Bearings

NOTICE When replacing a wheel bearing, both the inner and outer bearings including the pressed-in races must be replaced.

- 1 Be sure that both bearings are packed with grease.
- 2 Place the large inner bearing into the rear of the hub.
- 3 Press the bearing seal evenly into the hub until it is flush.
- 4 Slide the hub onto the yoke spindle.

CAUTION Component damage. Do not apply excessive force or damage to the lip of the seal may occur.

- 5 Place the outer bearing into the hub.

12-2 Steering Cylinders

How to Remove a Steering Cylinder

There are two identical steering cylinders that work in parallel. They are part of the same hydraulic circuit, but move in opposite directions. The tie rod maintains equal movement of the tires. Bushings are used at both ends of each steering cylinder clevis.

- 1 Disconnect and plug the hydraulic hoses from the steering cylinder. Cap the fittings.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Remove the pin retaining fasteners. Then remove the pivot pin from each end of the steering cylinder.
- 3 Remove the steering cylinder.

2WD STEERING AXLE COMPONENTS

12-3 Tie Rod

How to Remove the Tie Rod


- 1 Remove the pin retaining fasteners, then remove the pivot pin from each end of the tie rod.
- 2 Remove the tie rod.

How to Perform the Toe-in Adjustment

NOTICE

Perform this procedure on a firm, level surface. Block the non-steering tires and be sure that the machine is in the stowed position.

- 1 Straighten the steer wheels.
- 2 Measure the steer tires, front to front and back to back, using a measuring fixture.



- 3 Center a lifting jack under the steering axle, then raise the machine.
- 4 Loosen the jam nut on the adjustable end of the tie rod.
- 5 Remove the pin retaining fasteners, then remove the pivot pin from the adjustable end of the tie rod.
- 6 Slide the tie rod off the yoke and adjust it by turning the end.

NOTICE

One turn on the adjustable end equals approximately $\frac{1}{8}$ inch (3.2 mm) change in the front and rear measurements.

- 7 Slide the tie rod onto the yoke. Install the pivot pin, then install the retaining bolt.
- 8 Tighten the jam nut against the tie rod.
- 9 Lower the machine and recheck the front and back measurements (step 2). If further adjustment is needed, repeat steps 3 through 8.

Toe-in specification

$0 \pm \frac{1}{8}$ inch (6.35 mm)

4WD Steering Axle Components


13-1

Yoke and Hub

How to Remove the Yoke and Hub

The yoke installation utilizes bushings and a thrust washer that may require periodic replacement. The yoke must be removed before the torque hub can be removed.

- 1 Start the engine from the ground controls. Rotate the turntable until the platform is between the steer tires.
- 2 Remove the pin retaining fasteners, then remove the pivot pin from both the steering cylinder and the tie rod.



from the wheel motor. Cap the wheel motor hydraulic fittings.

⚠ CAUTION

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 4 Loosen the wheel lug nuts. Do not remove them.
- 5 Block the non-steering wheels, and then center a lifting jack under the steering axle.
- 6 Raise the machine 15 inches (38 cm) and place blocks under the chassis for support.
- 7 Remove the lug nuts, then remove the tire and wheel assembly.
- 8 Remove the hydraulic hose mounting bracket from the top of the yoke.
- 9 Remove the roll pin from the upper king pin.
- 10 Remove the retaining bolts from the upper and lower king pins.
- 11 Remove the drive motor mounting fasteners.
- 12 Slide the drive motor shaft out of the brake and then remove it.
- 13 Attach a strap from a lifting device to the yoke/torque hub assembly for support.

- 3 Disconnect and plug the hydraulic hoses

4WD STEERING AXLE COMPONENTS

14 Use a slide hammer to remove the upper king pin, then use a soft metal drift to drive the lower king pin down and out.

⚠WARNING Crushing hazard. The yoke/torque hub assembly will fall when the lower king pin is removed if it is not properly supported.

15 Place the yoke/torque hub assembly on a flat surface with the torque hub down. Remove the bolts that secure the yoke to the torque hub.

Torque specifications	
Lug nut	125 ft-lbs 169.5 Nm
Torque hub mounting bolts	120 ft-lbs 163 Nm
Drive motor mounting bolts	75 ft-lbs 102 Nm

13-2
Steering Cylinders

How to Remove a
Steering Cylinder

This procedure is the same as the 2WD procedure. See repair procedure 12-2, *How to Remove a Steering Cylinder*.

13-3
Tie Rod

How to Remove the Tie Rod

This procedure is the same as the 2WD procedure. See Repair Procedure 12-3, *How to Remove the Tie Rod*.

How to Perform the Toe-in
Adjustment

This procedure is the same as the 2WD procedure. See Repair Procedure 12-3, *How to Perform the Toe-in Adjustment*.

Oscillating Axle Components

14-1

Oscillating Axle Lock-out Cylinders

The oscillating axle cylinders extend and retract between the drive chassis and the oscillating axle. The cylinders are equipped with counterbalance valves to prevent movement in the event of a hydraulic line failure. The valves are not adjustable.

How to Remove an Oscillating Axle Cylinder

⚠ WARNING This procedure requires specific repair skills and a suitable workshop. Attempting this procedure without these skills and tools may result in death or serious injury and significant component damage. Dealer service is strongly recommended.

NOTICE Perform this procedure on a firm, level surface with the boom in the stowed position.

- 1 Block the non-steering wheels, then center a lifting jack between the steering wheels under the axle pivot pin.
- 2 Raise the machine 6 inches (15 cm) and place blocks under the drive chassis.
- 3 Disconnect and plug the oscillating axle cylinder hydraulic hoses, and cap the cylinder fittings.

⚠ CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.


- 4 Remove the pin retaining fasteners from both pivot pins.
- 5 Attach a strap from a lifting device to the cylinder for support.
- 6 Use a soft metal drift to remove the pins.

Steer and Oscillate Manifolds

15-1

Oscillate Manifold Components

Index No.	Description	Schematic Item	Function	Torque
1	Diagnostic fitting		Testing	
2	Differential sensing valve	A	Differential sensing	10-12 ft-lbs / 14-16 Nm
3	Check valve	D	Oscillate check - left	35-40 ft-lbs / 47-54 Nm
4	Pilot operated unloader valve 1200 psi (82.7 bar)	B	Sequencing	10-12 ft-lbs / 14-16 Nm
5	Shuttle valve 2 position 3 way	C	Pilot	10-12 ft-lbs / 14-16 Nm
6	Piston	G	Check valve circuit	
7	Check valve	E	Oscillate check - right	35-40 ft-lbs / 47-54 Nm
8	Shuttle valve 2 position 3 way	F	Unloading	35-40 ft-lbs / 47-54 Nm



Plug Torque Specifications

Description	Hex size	Torque
SAE No. 2	$\frac{1}{8}$	50 in-lbs / 6 Nm
SAE No. 4	$\frac{3}{16}$	13 ft-lbs / 18 Nm
SAE No. 6	$\frac{1}{4}$	18 ft-lbs / 24 Nm

Description	Hex size	Torque
SAE No. 8	$\frac{5}{16}$	50 ft-lbs / 68 Nm
SAE No. 10	$\frac{9}{16}$	55 ft-lbs / 75 Nm
SAE No. 12	$\frac{5}{8}$	75 ft-lbs / 102 Nm

STEER AND OSCILLATE MANIFOLDS

15-2**Valve Adjustments****How to Adjust the Sequencing Valve Pressure**

- 1 Connect a 0 to 600 psi (0 to 41 bar) pressure gauge to the test port located on the oscillate manifold.

▲ CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Disconnect the directional valve linkage, by removing the clevis yoke from the drive chassis.
- 3 Start the engine from the platform controls.
- 4 With the engine running, manually activate the valve and observe the pressure reading on the pressure gauge.
- 5 Turn the engine off. Hold the valve and remove the cap (index 4).
- 6 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Then install the valve cap.
- 7 Restart the engine. manually activate the valve and recheck the valve pressure.
- 8 Turn the engine off, then remove the pressure gauge and assemble the directional valve linkage.

Unloader valve specifications


Pressure	1200 psi 82.7 bar
----------	----------------------

STEER AND OSCILLATE MANIFOLDS

15-3

Directional Valve Manifold Components

Index No.	Description	Schematic Item	Function	Torque
1	Cap	Breather	20-25 ft-lbs / 27-33	
Nm				
2	Spool valve	Directional control		



STEER AND OSCILLATE MANIFOLDS

How to Set Up the Directional Valve Linkage

NOTICE

Adjustment of the directional valve linkage is only necessary when the linkage or valve has been replaced.

- 1 Lower the boom to the stowed position.
- 2 Use a "bubble type" level to be sure the floor is completely level.


WARNING

Failure to perform this procedure on a level floor will compromise the stability of the machine and may result in the machine tipping over.

- 3 Remove the drive chassis cover from the non-steer end.
- 4 Disconnect the linkage clevis yoke from the drive chassis (if not already disconnected).
- 5 Place a "bubble type" level across the drive chassis non-steer end. Check to be sure the drive chassis is completely level.
- 6 To level the drive chassis, start the engine and push up or pull down on the linkage adjustment rod until the machine is completely level.
- 7 Verify that the ground and drive chassis are completely level.
- 8 Adjust the length of the rod by turning the clevis yoke until the clevis yoke can be pinned to the drive chassis.
- 9 Install the clevis yoke pin then the cotter pin. Be sure to bend the cotter pin.
- 10 Measure the distance between the drive chassis and the non-steer axle on both sides (from the inside of the drive chassis).

NOTICE

If the distance is not equal and the adjustment to the linkage was completed with the ground and drive chassis level, consult Genie Industries Service Department.




STEER AND OSCILLATE MANIFOLDS

15-4

Steer Manifold Components

Index No.	Description	Schematic Item	Function	Torque
1	3 position 4 way D03 valve		Steering	30-35 in-lbs / 3-4 Nm
2	Priority flow regulator valve	A	Oscillate	10-12 ft-lbs / 14-16 Nm



Plug Torque Specifications

Description	Hex size	Torque
SAE No. 2	$\frac{1}{8}$	50 in-lbs / 6 Nm
SAE No. 4	$\frac{3}{16}$	13 ft-lbs / 18 Nm
SAE No. 6	$\frac{1}{4}$	18 ft-lbs / 24 Nm

Description	Hex size	Torque
SAE No. 8	$\frac{5}{16}$	50 ft-lbs / 68 Nm
SAE No. 10	$\frac{9}{16}$	55 ft-lbs / 75 Nm
SAE No. 12	$\frac{5}{8}$	75 ft-lbs / 102 Nm

Non-steering Axle Components

16-1 Drive Motor

⚠ CAUTION

Component damage hazard. Repairs to the motor should only be performed by an authorized Sundstrand-Sauer dealer.

How to Remove a Drive Motor

A drive motor can only be removed from the inside of the chassis.

⚠ CAUTION

Component damage hazard. The work area and surfaces where this procedure will be performed must be clean and free of debris that could get into the hydraulic system and cause severe component damage. Dealer service is recommended.

- 1 Disconnect the hydraulic hoses from the drive motor and plug them.

⚠ CAUTION

Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Remove the drive motor mounting bolts.
- 3 Slide the drive motor shaft out of the brake and then remove it.

Torque specifications

Drive motor mounting bolts	75 ft-lbs 102 Nm
----------------------------	---------------------

16-2 Torque Hub

How to Remove a Drive Torque Hub

- 1 Remove the drive motor. See 16-1, *How to Remove a Drive Motor*.
- 2 Disconnect the hydraulic hose from the brake and plug it. Then remove the hydraulic fitting and the bleed valve.
- 3 Loosen the wheel lug nuts. Do not remove them.
- 4 Center a lifting jack under the non-steering axle. Raise the machine and place blocks under the drive chassis to support it.
- 5 Remove the wheel lug nuts, then the tire and wheel assembly.
- 6 Place a second lifting jack under the torque hub for support.
- 7 Remove the bolts that attach the torque hub to the chassis, then remove the torque hub.

⚠ CAUTION

Crushing hazard. The torque hub will fall if it is not properly supported when the mounting bolts are removed.

Torque specifications

Lug nut	125 ft-lbs 169.5 Nm
Drive torque hub mounting bolts	120 ft-lbs 163 Nm
Drive motor mounting bolts	75 ft-lbs 102 Nm



This page intentionally left blank.

2WD Drive Manifold

17-1

2WD Drive Manifold Components


Index No.	Description	Schematic Item	Function	Torque
1	Relief valve, 250 psi (17 bar)	A	Charge pressure	15-18 ft-lbs / 20-24 Nm
2	Flow regulator valve	G	RR flow control in reverse	15-18 ft-lbs / 20-24 Nm
3	Flow regulator valve	K	RR flow control in forward	15-18 ft-lbs / 20-24 Nm
4	Flow regulator valve	F	LR flow control in reverse	15-18 ft-lbs / 20-24 Nm
5	Flow regulator valve	J	LR flow control in forward	15-18 ft-lbs / 20-24 Nm
6	Flow control valve	H	RR flow regulator in reverse	15-18 ft-lbs / 20-24 Nm
7	Flow control valve	E	LR flow regulator in reverse	15-18 ft-lbs / 20-24 Nm
8	Flow control valve	L	RR flow regulator in forward	15-18 ft-lbs / 20-24 Nm
9	Flow control valve	I	LR flow regulator in forward	15-18 ft-lbs / 20-24 Nm
10	Shuttle valve	B	Charge pressure circuit	15-18 ft-lbs / 20-24 Nm

Plug Torque Specifications

Description	Hex size	Torque
SAE No. 2	$\frac{1}{8}$	50 in-lbs / 6 Nm
SAE No. 4	$\frac{3}{16}$	13 ft-lbs / 18 Nm
SAE No. 6	$\frac{1}{4}$	18 ft-lbs / 24 Nm

Description	Hex size	Torque
SAE No. 8	$\frac{5}{16}$	50 ft-lbs / 68 Nm
SAE No. 10	$\frac{9}{16}$	55 ft-lbs / 75 Nm
SAE No. 12	$\frac{5}{8}$	75 ft-lbs / 102 Nm

2WD DRIVE MANIFOLD



2WD DRIVE MANIFOLD

17-2**Valve Adjustments**

How to Adjust the Charge Pressure Relief Valve


- 1 Connect a 0 to 600 psi (0 to 41 bar) pressure gauge to the test port located on the drive manifold.

▲ CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Start the engine from the platform controls.
- 3 Drive the machine slowly in either direction and observe the pressure reading on the pressure gauge.
- 4 Turn the engine off. Hold the relief valve and remove the cap (index 1).
- 5 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Then install the valve cap.
- 6 Restart the engine. Drive the machine in either direction and recheck the valve pressure.
- 7 Turn the engine off, then remove the pressure gauge.

Relief valve specifications

Pressure	250 psi
17 bar	



This page intentionally left blank.


4WD Drive Manifold

18-1

4WD Drive Manifold Components

Index No.	Description	Schematic Item	Function	Torque
1	Flow regulator valve	S	RF flow control in forward	15-18 ft-lbs / 20-24 Nm
2	Flow regulator valve	R	RR flow control in forward	15-18 ft-lbs / 20-24 Nm
3	Flow regulator valve	O	RF flow control in reverse	15-18 ft-lbs / 20-24 Nm
4	Flow regulator valve	N	RR flow control in reverse	15-18 ft-lbs / 20-24 Nm
5	Flow regulator valve	K	LF flow control in forward	15-18 ft-lbs / 20-24 Nm
6	Flow regulator valve	J	LR flow control in forward	15-18 ft-lbs / 20-24 Nm
7	Flow regulator valve	G	LF flow control in reverse	15-18 ft-lbs / 20-24 Nm
8	Flow regulator valve	F	LR flow control in reverse	15-18 ft-lbs / 20-24 Nm
9	Flow control valve	Q	RR flow regulator in forward	15-18 ft-lbs / 20-24 Nm
10	Flow control valve	M	RR flow regulator in reverse	15-18 ft-lbs / 20-24 Nm
11	Flow control valve	I	LR flow regulator in forward	15-18 ft-lbs / 20-24 Nm
12	Flow control valve	E	LR flow regulator in reverse	15-18 ft-lbs / 20-24 Nm
13	Relief valve, 250 psi (17 bar)	A	Charge pressure	15-18 ft-lbs / 20-24 Nm
14	Shuttle valve 3 position 3 way	B	Charge pressure circuit	15-18 ft-lbs / 20-24 Nm
15	Flow control valve	H	LF flow regulator in reverse	15-18 ft-lbs / 20-24 Nm
16	Flow control valve	L	LF flow regulator in forward	15-18 ft-lbs / 20-24 Nm
17	Flow control valve	P	RF flow regulator in reverse	15-18 ft-lbs / 20-24 Nm
18	Flow control valve	T	RF flow regulator in forward	15-18 ft-lbs / 20-24 Nm

4WD DRIVE MANIFOLD



4WD DRIVE MANIFOLD

Plug Torque Specifications

Description	Hex size	Torque
SAE No. 2	$\frac{1}{8}$	50 in-lbs / 6 Nm
SAE No. 4	$\frac{3}{16}$	13 ft-lbs / 18 Nm
SAE No. 6	$\frac{1}{4}$	18 ft-lbs / 24 Nm
SAE No. 8	$\frac{5}{16}$	50 ft-lbs / 68 Nm
SAE No. 10	$\frac{9}{16}$	55 ft-lbs / 75 Nm
SAE No. 12	$\frac{5}{8}$	75 ft-lbs / 102 Nm

- 6 Restart the engine. Drive the machine in either direction and recheck the valve pressure.
- 7 Turn the engine off, then remove the pressure gauge.

Relief valve specifications

Pressure	250 psi
17 bar	

18-2**Valve Adjustments****How to Adjust the Charge Pressure Relief Valve**

- 1 Connect a 0 to 600 psi (0 to 41 bar) pressure gauge to the test port located on the drive manifold.

CAUTION Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

- 2 Start the engine from the platform controls.
- 3 Drive the machine slowly in either direction and observe the pressure reading on the pressure gauge.
- 4 Turn the engine off. Hold the relief valve and remove the cap (index 13).
- 5 Adjust the internal hex socket. Turn it clockwise to increase the pressure or counterclockwise to decrease the pressure. Then install the valve cap.



Genie North America

18340 NE 76th Street
P.O. Box 97030
Redmond, Washington
98073-9730

Distributed By:



Genie Europe

Brunel Drive
Newark
Nottinghamshire
NG24 2EG England